




# Ai Thinker TB-05 BLE5.0 Mesh Bluetooth Module Owner's Manual

[Home](#) » [Ai-Thinker](#) » Ai Thinker TB-05 BLE5.0 Mesh Bluetooth Module Owner's Manual 



**TB-05 Specification**  
**Version V1.0.0**  
**Copyright ©2022**

## Contents

- [1 TB-05 BLE5.0 Mesh Bluetooth Module](#)
- [2 Product overview](#)
- [3 Main parameters](#)
- [4 Appearance dimensions](#)
- [5 Pin definition](#)
- [6 Schematic](#)
- [7 Antenna parameters](#)
- [8 Design guidance](#)
- [9 Storage conditions](#)
- [10 Reflow Welding Curve](#)
- [11 Product packaging information](#)
- [12 Contact us](#)
- [13 Disclaimer and Copyright Notice](#)
- [14 Notice](#)
- [15 Documents / Resources](#)
  - [15.1 References](#)

## TB-05 BLE5.0 Mesh Bluetooth Module

### Document resume

Version	Date	Develop/revise content	Edition	Approve
V1.0.0	2022.11.8	First Edition	Jingran Xiao	Ning Guan

## Product overview

TB-05 is a BLE5.0 low-power consumption Tmall Genie Mesh Bluetooth module based on TLSR8250 chip. The Bluetooth module supports the direct control of Tmall Genie and has the function of Bluetooth mesh networking. The devices communicate through peer-to-peer star network and Bluetooth broadcast, which can ensure timely response in case of multiple devices. It is mainly used in intelligent light control, which can meet the requirements of low power consumption, low delay and short-range wireless data communication.

### 1.1. Characteristics

- It can be directly controlled by the Tmall Genie without a gateway
- 1.1mm pitch SMD-20 package
- 6 PWM outputs
- Onboard antenna, compatible with half-hole pad/through-hole pad
- Brightness (duty cycle) adjustment range 5%-100%
- Factory default cold color warm color duty cycle 50%
- PWM output frequency 1KHz
- With night light function
- Color temperature switching function with wall switch

## Main parameters

**Table 1 Description of Main Parameters**

<b>Model</b>	TB-05
<b>Size</b>	12.2*18.6*2.8(±0.2)MM
<b>Package</b>	SMD-20
<b>Wireless standard</b>	Bluetooth 5.0
<b>Frequency</b>	2400~2483.5MHz
<b>Maximum Tx power</b>	Maximum 10.5dBm
<b>Receiving Sensitivity</b>	-93dBm
<b>Interface</b>	GPIO/PWM/SPI/ADC
<b>Operating temperature</b>	-40 °C ~ 85 °C
<b>Storage environment</b>	-40 °C ~ 125 °C , < 90%RH
<b>Power supply</b>	The power supply voltage is 2.7V ~ 3.6V, and the power supply current is ≥ 50mA
<b>Power consumption</b>	Deep sleep pattern: 0.8 μA
	Sleep mode: 1.8 μA
	TX:21.56mA
<b>Transmission distance</b>	Outdoor open sight distance: ≥ 100 m

### 2.1. Static electricity requirements

TB-05 is an electrostatic sensitive equipment and requires special precautions during handling



**Figure 2 ESD anti-static diagram**

### 2.2. Electrical characteristics

**Table 2 Table of Electrical Characteristics**

Parameters		Condition	Min.	Typical value	Max.	Unit
Supply voltage		VDD	2.7	3.3	3.6	V
I/O supply voltage		VCCIO	-0.3	–	3.6	V
I/O	VIL	–	–	–	0.3*VDDIO	V
	VIH	–	0.7*VDDIO	–	VDDIO	V
	VOL	–	–	–	0.1*VDDIO	V
	VOH	–	0.9*VDDIO	–	VDDIO	V
Operating			-40	–	+85	°C
Storage			-40	–	+125	°C

### 2.3. BLE RF performance

**Table 3 BLE RF Performance Table**

Description	Typical value			Unit
Spectrum range	2400~2483.5MHz			MHz
Output power				
Rate mode	Min.	Typical value	Max.	Unit
1Mbps	7.1	8.5	10.5	dBm
Receiving sensitivity				
Rate mode	Min.	Typical value	Max.	Unit
1Mbps sensitivity @ 30.8% PER	—	-93	—	dBm

### 2.4. Power consumption

The following power consumption data is based on a 3.3V power supply, ambient temperature of 25°C, and measured using an internal voltage regulator.

- All measurements are completed at the antenna interface with a filter.
- All transmission data are measured in the continuous transmission mode based on the duty cycle of the 100%.

**Table 4 Power consumption table**

Mode	Min.	Average	Max.	Unit
Tx power consumption (10.5dBm)	–	21.56	–	mA
Rx consumption	–	6.4	–	mA
Standby power consumption	–	3	–	mA
Superficial sleep	–	1.8	–	μA
Deep sleep	–	0.8	–	μA

Appearance dimensions




Figure 3 (for reference only)




Figure 4 dimension diagram (unit: mm)

Pin definition

TB-05 module has a total of 20 interfaces. As shown in below pin diagram, the pin function definition table is the interface definition.




Figure 5 Pin Top View

Table 5 Pin Function Definition Table

No.	Name	Function
1	D2	SPI chip selection (active low)/PWM3 output/GPIO PD2
2	D3	PWM1 reverse output/GPIO PD3
3	D4	GPIO PD4/single-wire host/PWM2 reverse output
4	D7	GPIO PD7/SPI clock (I2C_SCK)
5	A1	GPIO PA1
6	SWS	Single-wire slave
7	TXD	PWM4 output/UART_TX/SAR ADC input/GPIO PB1
8	RXD	PWM0 reverse output/UART_RX/GPIO PA0
9	GND	Ground
10	3V3	3.3V power supply
11	B4	PWM4 output/SAR ADC input/GPIO PB4
12	B5	PWM5 output/SAR ADC input/GPIO PB5
13	B6	SPI data input (I2C_SDA)/UART_RTS/SAR ADC input/GPIO PB6
14	B7	SPI data output/UART_RX/SAR ADC input/GPIO PB7
15	C0	I2C serial data/PWM4 reverse output/UART_RTS / GPIO PC0
16	C1	I2C serial clock/PWM1 reverse output/pwm0 output/GPIO PC1
17	C4	PWM2 output/UART_CTS/PWM0 reverse output/SAR ADC input
18	NC	NOT CONNECTED
19	RST	Reset pin
20	ANT	Antenna interface

## Schematic




Figure 6 Schematic diagram

## Antenna parameters

### 6.1. Schematic of Antenna Test Prototype



**Figure 7** schematic diagram of antenna test prototype

### 6.2. Antenna S parameter







Figure 8 Antenna S parameters

### 6.3. Antenna Gain and Efficiency

Table 6 Antenna Gain and Efficiency

Frequency ID	1	2	3	4	5	6	7	8	9	10	11
Frequency(MHz)	2400	2410	2420	2430	2440	2450	2460	2470	2480	2490	2500
Gain(dBi)	0.11	0.19	0.53	0.66	0.90	1.31	1.52	1.60	1.64	1.51	1.28
Efficiency(%)	27.64	28.55	31.13	32.06	33.47	36.26	36.85	37.13	36.93	36.74	35.69


### 6.4. Antenna field type diagram



**Figure 9 antenna field type diagram**


## Design guidance

### 7.1. Application guidance circuit



**Figure 10 Application Guidance Circuit**


### 7.2. Recommended PCB package size



**Figure 11 Recommended PCB Package Size (Unit: mm)**

### 7.3. Antenna layout requirements

- In the installation position on the motherboard, the following 2 methods are recommended:  
 Scheme 1: Place the module on the edge of the main board, and the antenna area extends out of the edge of the main board  
 Scheme 2: Place the module on the edge of the motherboard, and the edge of the motherboard hollowed out an area at the antenna position
- In order to meet the performance of the on-board antenna, it is forbidden to place metal parts around the antenna, away from high-frequency devices



**Figure 12 Antenna Layout**

### 7.4. Power supply



be baked before it can be put on line again.

## Reflow Welding Curve




Figure 15 reflow welding diagram

## Product packaging information

TB-05 module is packaged in a tape, 1350pcs/reel. As shown in the below image



Figure 16 Package and packing diagram

## Contact us

[Ai-Thinker official website](http://ai-thinker.com)

- - [ai-thinker.com](http://ai-thinker.com)

[Hotspots | ai-thinker.com](http://ai-thinker.com)

[Sign In | LinkedIn](#)

[Tmall shop](#)

[Taobao shop](#)

[Shenzhen Anxinke Technology Co., Ltd. – IoT wireless module, ESP8266/ESP32 modules \(alibaba.com\)](#)

Technic support email [support@aithinker.com](mailto:support@aithinker.com)

Domestic business cooperation [sales@aithinker.com](mailto:sales@aithinker.com)

Overseas business cooperation [overseas@aithinker.com](mailto:overseas@aithinker.com)

Company Address Room 403,408-410, Block C, Huafeng Smart Innovation Port, Gushu 2nd Road, Xixiang, Baoan District, Shenzhen.

Tel: 0755-29162996



Wechat mini program

<http://weixin.qq.com/r/Rjp4YNrExYe6rZ4D929U>



WeChat official account

## Disclaimer and Copyright Notice

The information in this article, including the URL address for reference, is subject to change without notice.

The document is provided “as is” without any warranty, including any warranty of merchantability, suitability for a particular purpose or non-infringement, and any warranty mentioned elsewhere in any proposal, specification or sample. This document is not responsible for any infringement of any patent rights arising from the use of the information in this document. This document does not hereby grant any license for the use of intellectual property, whether express or implied, by estoppel or otherwise.

The test data obtained in this paper are all obtained by the laboratory test of Ai-Thinker, and the actual results may be slightly different.

It is hereby declared that all trade names, trademarks and registered trademarks mentioned in this article are the property of their respective owners.

The final interpretation right belongs to Shenzhen Ai-Thinker Technology Co., Ltd.

## Notice

The contents of this manual may change due to product version upgrades or other reasons.

Shenzhen Ai-Thinker Technology Co., Ltd. reserves the right to modify the contents of this manual without any notice or prompt.

This manual is only used as a guide. Shenzhen Ai-Thinker Technology Co., Ltd. makes every effort to provide accurate information in this manual. However, Shenzhen Ai-Thinker Technology Co., Ltd. does not ensure that the contents of the manual are completely error-free, and all statements, information and suggestions in this manual do not constitute any express or implied guarantee.

### **Integration instructions for host product manufacturers according to KDB 996369 D03 OEM Manual v01**

#### **2.2 List of applicable FCC rules**

The TB-05 is an BT Module with GFSK modulation. It operates on the 2402MHz~2480MHz band and, therefore, is within U.S.

FCC part 15.247 standard

#### **2.3 Specific operational use conditions**

The EUT is a BT Module

BLE:

Operation Frequency: 2402-2480MHz for BLE;

Modulation Type: GFSK

Number Of Channel: 40 channels

Antenna Designation: PCB Antenna

Antenna Gain: 1.64dBi

Support BLE5.1,rate support: 1Mbps,2Mbps Own 64KB SRAM 256KB flash,96 KB ROM 256bit efuse



Support UART/GPIO/ADC/PWM/I2C/SPI/PDM/DMA interface Adopt SMD-22 package  
Support multiple sleep modes, deep sleep current is less than 1uA  
Support for serial local upgrade and remote Firmware upgrade(FOTA)  
Universal AT instructions can be used easy and quickly  
Support for secondary development, with an integrated Windows development environment

#### **2.4 Limited module procedures**

not applicable; Single Modular Approval Request

#### **2.5 Trace antenna designs**

Not applicable;

#### **2.6 RF exposure considerations**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

#### **2.7 Antennas**

The TB-05 is an BT Module beams signals and communicates with its antenna, which is PCB Antenna. The PCB Antenna gain is 1.64dBi. Antenna could not be in no-load state when module is working. During debugging, it is suggested to add 50 ohms load to the antenna port to avoid damage or performance degradation of the module under long-time no-load condition.

#### **2.8 Label and compliance information**

The final end product must be label in a visible area with the following  
Host must Contains FCC ID: 2ATPO-TB05. If the size of the end product is larger than 24x16mm, then the following FCC part 15.19 statement has to also be available on the label: This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference and
2. this device must accept any interference received, including interference that may cause undesired operation.

#### **2.9 Information on test modes and additional testing requirements**

Data transfer module demo board can control the EUT work in RF test mode at specified test channel.

#### **2.10 Additional testing, Part 15 Subpart B disclaimer**

The module without unintentional-radiator digital circuit, so the module does not required an evaluation by FCC Part 15 Subpart B. The host should be evaluated by the FCC Subpart B.

#### **ATTENTION**

This device is intended only for OEM integrators under the following conditions:

1. The antenna must be installed such that 5 mm is maintained between the antenna and users, and
2. This device and its antenna(s) must not be co-located with any other transmitters except in accordance with FCC multi-transmitter product procedures. Referring to the multi-transmitter policy, multiple transmitter(s) and module(s) can be operated simultaneously without C2P.
3. For all products market in US, OEM has to limit the Operating Frequency: 2402-2480MHz by supplied firmware programming tool. OEM shall not supply any tool or info to the end-user regarding to Regulatory Domain change.

#### **USERS MANUAL OF THE END PRODUCT:**

In the user manual of the end product, the end user has to be informed to keep at least 5mm separation with the antenna while this end product is installed and operated. The end user has to be informed that the FCC radio-frequency exposure guidelines for an uncontrolled environment can be satisfied. The end user has to also be informed that any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this equipment.

If the size of the end product is smaller than 8x10cm, then additional FCC part 15.19 statement is required to be available in the users manual: This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference and
2. this device must accept any interference received, including interference that may cause undesired operation.

## FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.


This equipment generate, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Copyright © 2022 Shenzhen Ai-Thinker Technology Co., Ltd  
All Rights Reserved**

---

## Documents / Resources

	<a href="#">Ai Thinker TB-05 BLE5.0 Mesh Bluetooth Module</a> [pdf] Owner's Manual 2ATPO-TB05, 2ATPOTB05, tb05, TB-05 BLE5.0 Mesh Bluetooth Module, TB-05, TB-05 Bluetooth Module, BLE5.0 Mesh Bluetooth Module, BLE5.0 Bluetooth Module, Mesh Bluetooth Module, Bluetooth Module, Module
---	--

## References

-  [-](#)
-  [Shenzhen Anxinke Technology Co., Ltd. - IoT wireless module, ESP8266/ESP32 modules](#)
-  [-](#)
-  [Hotspots |](#)