




aigo ICE2DD PRO Cpu Cooler Instruction Manual

[Home](#) » [aigo](#) » aigo ICE2DD PRO Cpu Cooler Instruction Manual 

Contents

- [1 aigo ICE200 PRO Cpu Cooler Instruction Manual](#)
- [2 PART LIST](#)
- [3 INTEL INSTALLATION](#)
[\(1156/1155/1151/1150/775/1700\)](#)
- [4 DOWNLOAD](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)






aigo ICE200 PRO Cpu Cooler Instruction Manual





INSTRUCTION MANUAL

Support : Intel LGA1156/1155/1151/1150/775/1700
AMD AM5/AM4/AM3+/AM3/AM2+/AM2

PART LIST

A  Module*1	B  Fan*1	C  Buckle*1	D  Cable buckle*2
F  Intel_PBT buckle*1	G  Push_pin*4	H  Intel buckle*4	I  Thermal grease*1

INTEL INSTALLATION (1156/1155/1151/1150/775/1700)




STEP-1


Insert the PBT buckle into the corresponding holes on mainboard; fix the motherboard and PBT buckle by Push_pin.

STEP-2


Insert the Intel buckle into the holes of PBT buckle; fix motherboard and the buckle.




Remove the PE protective film at the bottom of the CPU cooler




Apply the thermal grease on the motherboard CPU chip.




Remove the PE protective film at the botto of the CPU cooler.




Apply the thermal grease on the motherboard CPU chip.




Fasten the left and right of the CPU cooler buckie with the PBT buckie.




Connect the fan connector to the CPU_fan Pin



Fasten the left and right of the CPU cooler buckie with the PBT buckie.




Connect the fan connector to the CPU_fan Pin



DOWNLOAD

aigo ICE200 PRO Cpu Cooler Instruction Manual – [[Download PDF](#)]



[aigo ICE2DD PRO Cpu Cooler](#) [pdf] Instruction Manual
ICE2DD PRO, ICE2DD PRO Cpu Cooler, Cpu Cooler, Cooler

References

- [User Manual](#)