

AIGOSTAR 284-ES LED String Light User Manual



ITALIA MARKET SRL
VIA DELLE INDUSTRIE, 9/1
20883 MEZZAGO(MB), ITALIA
P.IVA: IT10502730962
[HTTP://WWW.AIGOSTAR.COM](http://www.aigostar.com)
MADE IN CHINA



Contents

- 1 LED STRING LIGHT**
 - 1.1 I. PRODUCT DESCRIPTION**
 - 1.1.1 Introduction to function change:**
 - 1.2 II. INSTALLATION:**
 - 1.3 III. WARNINGS**
- 2 Documents / Resources**
 - 2.1 References**
- 3 Related Posts**

LED STRING LIGHT

I. PRODUCT DESCRIPTION

1. Press the button to switch between 8 dynamic functions.
2. Press and hold the button for 3 seconds until the green light comes on, indicating a timed state (Light on for 6 hours and off for 18 hours, repeating automatically every day.). Press and hold the button for 3 seconds until the green light goes out, indicating that the timer has been canceled.
3. Automatic access to the last set function after power failure and re-powering.

Introduction to function change:

1. Combination. Automatic continuous change of various functions.
2. In Waves. Automatically change backwards and forwards (two speed changes).

3. Sequential. Auto change (four speed changes).
4. SLO-GLO. A single light fade (three speed changes).
5. Chasing/Flash. Automatic change of the star flashing.
6. Slow Fade. Two lights fade at the same time (three speed changes).
7. Twinkle/Flash. Automatic twinkle.
8. Steady On. The LED is always on.

II. INSTALLATION:

Schematic diagram

Button



Connect the end connector of the light string to the power controller connector and tighten the knob.




1. Button
2. Access points for products

III. WARNINGS

1. Do not connect the chain to the supply while it is in the packaging.
2. Use only the transformer for the product, and do not connect the string light to the circuit of other string lights.
3. Please hang them out of the reach of children to prevent choking accidents.
4. Please discard at the end of the service life in accordance with the municipal waste.
5. The lamps are not replaceable.
6. Warning-risk of electric shock if lamps are broken or missing.
7. The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.

Documents / Resources



[AIGOSTAR 284-ES LED String Light](#) [pdf] User Manual
284-ES LED String Light, 284-ES, LED String Light, String Light, Light

References

- [User Manual](#)