



AiM MyChron5S GPS Lap Timer and Water Temperature Sensor Instruction Manual

[Home](#) » [AiM](#) » AiM MyChron5S GPS Lap Timer and Water Temperature Sensor Instruction Manual



MyChron5S GPS Lap Timer and Water Temperature Sensor FAQ Instruction Manual

Contents [[hide](#)]

- [1 Configuring](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

Configuring

Setting temperatures in “Manual” mode


Question:

Can I configure the temperature setting in Manual mode on MyChron5/5S?

Answer:

You can only configure this setting on MyChron5S.


To configure the temperature setting in manual mode, you have to access the main menu of the device – System Setting – Temperature Setup.



Harness Type: indicate the extension of the sensors connected to the MyChron5S, it could be:


- **TC/TR** – Thermocouple – Thermo-resistor
- **TR/TR** – Thermo-resistor – Thermo-resistor
- **TC/TC** – Thermocouple – Thermocouple

Temperature IN1/IN2: configure the two sensors by inserting the correct labels.



Release 1.00 – July 5th, 2022

Documents / Resources

	<p>AiM MyChron5S GPS Lap Timer and Water Temperature Sensor [pdf] Instruction Manual MyChron5S GPS Lap Timer and Water Temperature Sensor, MyChron5S, GPS Lap Timer and Water Temperature Sensor</p>
---	--

