



AIPHONE TW-20B-A Dual Intercom Tower User Guide

[Home](#) » [AIPHONE](#) » AIPHONE TW-20B-A Dual Intercom Tower User Guide 

Contents

- [1 AIPHONE TW-20B-A Dual Intercom Tower](#)
- [2 Product Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Frequently Asked Questions \(FAQ\)](#)
- [5 PRODUCT DIMENSION](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)



AIPHONE TW-20B-A Dual Intercom Tower



Product Specifications

- Product Name: TW Series
- Model: TW-MKL
- Compatibility: TW-20B/A and TW-23B/A Modular Towers
- Installation Template Dimensions: 5.80" x 4"
- Wood Thickness Recommendation: 1/2" to 1"

Product Usage Instructions

Step 1: Gather Required Materials

Before starting the installation, make sure you have the following materials:

- TW-MKL Installation Template
- A piece of wood with a thickness of 1/2" to 1"
- Anchor bolts (not included)

Step 2: Prepare the Wood Template

To ensure proper anchor bolt placement, it is recommended to transfer the template onto a piece of wood. Follow these steps:

1. Place the TW-MKL Installation Template on top of the wood.

2. Securely attach the template to the wood using tape or clamps.
3. Trace the outline of the template onto the wood using a pencil or marker.

Step 3: Anchor Bolt Placement

Now that you have prepared the wood template, follow these steps to determine anchor bolt placement:

1. Position the wood template in the desired location for the TW-20B/A or TW-23B/A Modular Tower installation.
2. Ensure the template is aligned correctly according to your installation requirements.
3. Mark the locations of the anchor bolts on the wood template.

Step 4: Installation

Once you have determined the anchor bolt placement, proceed with the installation of the TW-20B/A or TW-23B/A Modular Tower following the tower's user manual or instructions.

Frequently Asked Questions (FAQ)

Q: What is the purpose of the TW-MKL Installation Template?

A: The TW-MKL Installation Template is designed to assist in proper anchor bolt placement for the TW-20B/A and TW-23B/A Modular Towers.


Q: Can I use any wood thickness for the template?

A: It is recommended to use a piece of wood with a thickness of 1/2" to 1" to ensure the template's stability and accuracy.

Q: Are anchor bolts included with the TW-MKL Installation Template?

A: No, anchor bolts are not included. You will need to purchase them separately based on your specific installation requirements.

PRODUCT DIMENSION




NOTE: It is recommended to transfer this template to a piece of wood (1/2" to 1" thickness) to ensure proper anchor bolt placement

TW Modular Series – TW-MKL Installation Template 10/23 Pg.1 of 1

Aiphone Corporation
www.aiphone.com
 (800) 692-0200

Documents / Resources



[AIPHONE TW-20B-A Dual Intercom Tower](#) [pdf] User Guide
 TW-20B-A Dual Intercom Tower, TW-20B-A, Dual Intercom Tower, Intercom Tower, Tower

References

- [User Manual](#)