



## AirTrack Configuration Guide for CellarTracker User Guide

[Home](#) » [AirTrack](#) » AirTrack Configuration Guide for CellarTracker User Guide 

### Contents


- [1 AirTrack Configuration Guide for CellarTracker](#)
- [2 Documents / Resources](#)
  - [2.1 References](#)
- [3 Related Posts](#)



### AirTrack Configuration Guide for CellarTracker

For your new AirTrack scanner to work with CellarTracker, you need to configure it to read Interleaved 2 of 5 barcodes. Scan the following barcodes, in order, to configure your scanner. Additionally, if you would like to disable the scanner from always being enabled while placed in the stand, scan configuration barcode #3. If you need further assistance connecting the scanner to your computer or configuring it, please contact AirTrack support at (888) 622-4982. Each purchase includes 30 days of free technical support.

## 1. Enter Scanner Configuration Mode




## 2. Enable Interleaved 2-of-5 (6-10 digits)



### 3. *OPTIONAL*: Disable Auto Recognition in Stand



### 4. Exit Scanner Configuration Mode



#### **Bluetooth Configuration Notes (AirTrack S2-BT only)**

To pair the scanner directly with your computer via Bluetooth, please follow the instructions in the Quick Reference Guide ([https://airtrack.com/wpcontent/uploads/2017/03/AirTrack-S2-BT\\_qrg\\_eng.pdf](https://airtrack.com/wpcontent/uploads/2017/03/AirTrack-S2-BT_qrg_eng.pdf)) starting on page 11. Choose the option to Link to PC in HID mode. The default PIN code, which you may need to enter on your computer, is 1234.


#### **Wired Configuration Notes (AirTrack S2 only)**

In most scenarios, the wired scanner should be configured in USB Keyboard mode with a standard key configuration. When following the instructions in the Quick Reference Guide ([https://airtrack.com/wp-content/uploads/2017/03/AirTrack-S2-QRG\\_updated.pdf](https://airtrack.com/wp-content/uploads/2017/03/AirTrack-S2-QRG_updated.pdf)) starting on page 4, scan the last barcode on page 8 to Select USB Keyboard mode.

#### **Full Manual**

The full user manual for the device is available to download at the following location:  
<https://cdn.datalogic.com/Download?iddwnfile=16149>

#### **Documents / Resources**

	<p><a href="#">AirTrack Configuration Guide for CellarTracker</a> [pdf] User Guide Configuration Guide for CellarTracker, Configuration Guide, CellarTracker</p>
---	--

## References

-  [cdn.datalogic.com/Download?iddwnfile=16149](https://cdn.datalogic.com/Download?iddwnfile=16149)

Manuals+.