



AIRZONE DFCI250BMTE Circular Diffuser User Manual

[Home](#) » [AIRZONE](#) » AIRZONE DFCI250BMTE Circular Diffuser User Manual 



**DFCI250BMTE Circular Diffuser
User Manual**



Contents

- [1 DFCI250BMTE Circular Diffuser](#)
- [2 COMPATIBLE ACCESSORIES](#)
- [3 INSTALLATION](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

DFCI250BMTE Circular Diffuser






FLOW TOOL

Visit [Flowtool](#) to calculate/select your installation.

AIRZONE CIRCULAR DIFFUSER

DFCI circular diffuser which facilitates airflow supply in 4 directions. Central part can be removed to facilitate assembly and maintenance. Designed for installation in a ceiling.



DFCI xxx B C

DFCI [XXX] [X] [X]

X : Without regulation

R : With regulation


C : With neck and regulation

A : Aluminum



B : RAL 9010 - White

Ø : 150 / 200 / 250 / 300 / 350 mm


EJ. DFCI [200][B][C]: DFCI measuring 200 mm in diameter in white with neck and regulation.



DFCI xxx B X



DFCI xxx B R





COMPATIBLE ACCESSORIES

- TFxx (DFCIxxxBC)


REGULATION

The airflow is regulated by means of a butterfly damper, which allows manual regulation of the airflow of the diffuser. In position **1** (open), 100% of the airflow can pass through. In position **2** (closed), 0% of the airflow can pass through.




INSTALLATION

1. Insert the diffuser next to the assembly bridge until the diffuser is supported; use the assembly bridge adjusting screw to secure it.



Documents / Resources

	<p>AIRZONE DFCI250BMTE Circular Diffuser [pdf] User Manual DFCI250BMTE Circular Diffuser, DFCI250BMTE, Circular Diffuser, Diffuser</p>
---	--

Manuals+.