



AIRZONE DFLI Linear Diffuser User Manual

[Home](#) » [AIRZONE](#) » AIRZONE DFLI Linear Diffuser User Manual 

AIRZONE DFLI Linear Diffuser User Manual




Contents

- [1 AIRZONE LINEAR DIFFUSER](#)
- [2 COMPATIBLE ACCESSORIES](#)
- [3 INSTALLATION](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

AIRZONE LINEAR DIFFUSER

DFLI long-range linear diffuser with 1-to-4 slot output, which facilitates airflow supply in two directions via mobile slats. Designed for installation in a ceiling.

It is fixed by means of the assembly bridge or plenum. At least one of these accessories is required.



COMPATIBLE ACCESSORIES

DFLI [X] [XXXXX] [X] [X]

X : Full sections

C : Central sections

T : Head sections

A : Aluminum

B : White

L (DFLIxxxxxxx**X**): 500 - 2000 mm

L* (DFLIxxxxxxx**T**): 1000 - 2000 mm

L* (DFLIxxxxxxx**C**): 1500, 2000 mm

1 : 1 slot

2 : 2 slots,


3 : 3 slots,

4 : 4 slots

For combinations in which $L > 2000$ mm.

INSTALLATION


1. If required, join the sections using the tabs provided. It includes the heads in the final sections (already included in DFLIxxxxxxxT and DFLIxxxxxxxX).



2. FIXING (by one of the following options)


A) AZ0DFLIFIXx

To assemble it, pass the fixing screws through the slots in the diffuser and thread onto the assembly bridge. Take the whole thing to the opening in the ceiling and, using the assembly bridges in the false ceiling, tighten the screws.



B) PLEN


Fix the plenum to the ceiling using the fixing brackets. Pass the fixing screws through the slots in the diffuser and thread them onto the plenum until it is fixed to the false ceiling



Note: Don't forget to regulate the airflow via the butterfly damper.



Documents / Resources



[AIRZONE DFLI Linear Diffuser](#) [pdf] User Manual
DFLI Linear Diffuser, DFLI, Linear Diffuser, Diffuser

Manuals+.