



AIRZONE ZS6 Interfaces User Guide

[Home](#) » [AIRZONE](#) » AIRZONE ZS6 Interfaces User Guide 

Contents

1

AIRZONE ZS6 Interfaces

2

Screensaver

3

Main Screen

4

Basic functions

5

Documents / Resources

5.1

References

6

Related Posts



AIRZONE ZS6 Interfaces




Screensaver


- **A.** Date*
- **B.** Zone status
- **C.** Main screen / Confirm
- **D.** On / Off
- **E.** Control bar

Main Screen

- **F.** User mode
- **G.** Operation mode
- **H.** Room temperature / Relative humidity
- **I.** Settings menu
- **J.** Local ventilation
- **K.** Main screen / Confirm
- **L.** On / Off
- **M.** Timer
- **N.** Set point temperature
- **O.** Control bar
- **P.** Zone
- **Q.** Airflow Control





If the system has Webserver, weather information will also appear.



Basic functions

- **A.** On / Off
- **B.** Lower temperature
- **C.** Raise temperature



User's Manual



Marie Curie, 21 29590 Málaga Spain.
airzonecontrol.com.

Documents / Resources

	AIRZONE ZS6 Interfaces [pdf] User Guide ZS6 Interfaces, ZS6, Interfaces
--	--

References

- [A Airzone | Leaders in HVAC control solutions](#)