

aiwa®
aiwa ASP-A200BK Speaker Sets



aiwa ASP-A200BK Speaker Sets User Guide

[Home](#) » [Aiwa](#) » aiwa ASP-A200BK Speaker Sets User Guide 

Contents

- [1 aiwa ASP-A200BK Speaker Sets](#)
- [2 Product Usage Instructions](#)
- [3 Instruction](#)
- [4 SPECIFICATIONS](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

aiwa®

aiwa ASP-A200BK Speaker Sets



Product Usage Instructions

Power On/Off

To power on the device, press the power button located on the front panel. To turn off, press and hold the same button until the device shuts down.

Volume Control

Adjust the volume by turning the dedicated knob clockwise to increase and counterclockwise to decrease the sound output.

Input Selection

Select the input source by using the input selection button on the device. Cycle through the available options until you reach your desired input source.

EQ Settings

Customize the sound output by adjusting the equalizer settings. Refer to the user manual for detailed instructions on how to modify bass, treble, and other sound parameters.

Frequently Asked Questions (FAQ)

- **Q: How do I connect external devices to this product?**
 - A: You can connect external devices such as smartphones or MP3 players using the provided audio input ports on the back of the device. Make sure to use compatible cables for optimal performance.
- **Q: Can I use this product with Bluetooth-enabled devices?**
 - A: Yes, this product supports Bluetooth connectivity. Enable Bluetooth mode on your device and pair it with the product to enjoy wireless audio streaming.

SAFETY PRECAUTIONS

Thank you for purchasing ASP-A200

This is your assurance of quality, performance and value. Our engineers have included many useful and

convenient features in this product. Please be sure to read this instruction Manual completely to make sure you are getting the maximum benefit from each feature.

This product was manufactured using the highest quality components and standards of workmanship. It was tested by inspectors and found to be in perfect working order before it left our factory.

Instruction

IMPORTANT

Read these safety instructions before using your device.

The safety and operating instructions should be retained for future reference.

1. Do not use this apparatus near water – The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool or similar environments.
 2. Put this product and its accessories somewhere out of the reach of children, to avoid danger or their inappropriate use.
 3. You must use the provided power cord to connect the device, otherwise it may cause damage to the unit.
 4. Only use attachments/accessories specified by the manufacturer.
 5. Protect the power cord from being walked on or pinched particularly at the plugs, convenience receptacles, and at the point where they exit from the apparatus.
 6. When connected the cord should always be readily accessible.
 7. Do not store near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
 8. The device is intended for use only in a temperate climate.
 9. It shouldn't be stored or used at temperatures below -10°C (14 F) or above 40°C (104 F) which may damage the set.
 10. Do not expose the unit directly to the sunlight nor heat radiation.
 11. Do not expose the unit to strong magnetic or electronic interferences.
 12. The unit should be installed on stable and horizontal surface.
 13. Cleaning
 - Turn Off the unit if it's On and unplug before cleaning.
 - Do not use liquid cleaners or aerosol cleaners.
 - Clean only with dry cloth.
 14. Do not attempt to repair this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Damages that need repair must be refer all to qualified service personnel.
-
- The packaging needs to be destroyed in accordance with relevant local laws and regulations on waste disposal. Cartons and paper need to be sorted as recyclable paper and platinum as a recyclable resource (potential recycling resource). When the crossed-out wheeled bin symbol is attached to a product, it means the product is covered by the European Directive 2012/19/EC.
 - All electrical and electronic products including batteries should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
 - The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.

SPECIFICATIONS

- **Output Power:** 50W RMS at <1% THD (25W x 2 channels)
- **Freq. Response:** 40Hz – 20KHz, SNR ≤ 85dB
- **Drivers:** 4" (40HM) X2 + 1.25" (4 Ω)
- **INPUT :** 100-240V~ 50/60Hz 1.0A Max
- **OUT PUT:** 19.0V 1.89A 35.91W
- **Sources:** BT 5.0 +OPTICAL+ RCA+ USB-MP3 +HDMI(ARC) + COAX
- **Audio Control:** Rotary VOL + BASS + TREBLE and Push-Button PRESET EQ(3 modes)
- **Indicator:** Multi Color RGB LED
- **Dimensions:** 150 x 223 x 169mm per speaker box (x2)

Due to continual revision and improvement of our products, design and specifications are subject to change without further notice.

Documents / Resources



[aiwa ASP-A200BK Speaker Sets](#) [pdf] User Guide
ASP-A200BK, ASP-A200, ASP-A200BK Speaker Sets, ASP-A200BK, Speaker Sets, Sets

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.