



AJAX LeaksProtect Wireless Leakage Detector User Manual

[Home](#) » [ajax](#) » **AJAX LeaksProtect Wireless Leakage Detector User Manual** 



LeaksProtect User Manual
Updated January 25, 2022



LeaksProtect is a wireless leakage detector that notices both in case of a leak and when the water dries out. Developed only for indoor use.

LeaksProtect connects to the Ajax security system via the protected radio protocol. The communication range is up to 1300 meters in line of sight.

Also, LeaksProtect can be connected to third-party security systems using the or Jeweller Ajax UART bridge Ajax Oxbridge Plus integration modules.

Users can configure LeaksProtect via the Ajax app for macOS, Windows, iOS, or Android. The system notifies users of all events through push notifications, SMS, and calls (if activated).


The user can connect the Ajax security system to the central monitoring station of a security company.

Buy leakage detector LeaksProtect

Contents

- [1 Functional Elements and Indication](#)
- [2 Indication](#)
- [3 Turned-on detector indication](#)
- [4 Selecting the Location](#)
- [5 Detector Testing](#)
- [6 Maintenance](#)
- [7 Tech specs](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)

Functional Elements and Indication



1. LED indicator
2. Water sensor contacts
3. QR code with the device registration key
4. On/off button

Operating Principle

At the bottom of its body, LeaksProtect is equipped with four pairs of water-sensitive contacts. If at least one contact pair gets wet, the detector immediately transmits an alarm signal to the hub, notifying the user and security company. Also, the detector notifies users if the water dries out.

i When switched on, LeaksProtect is always active and monitors the situation regardless of the security model: disarmed or armed.

If the leak is detected, LeaksProtect not once, and the next alarm is transmitted when the contacts have dried out and gotten wet again.

Connecting the detector to the Ajax security system

Detector connection to the hub

Before connecting:

1. Following the hub user manual, install the Ajax app. Create an account, add the hub to the app, and create at least one room.
2. Check the internet connection (via Ethernet cable and/or GSM network).
3. Check the hub status in the app: make sure that it is disarmed and does not update.



Only users with administrator rights can add the device to the hub.

How to pair the detector with the hub:

1. Select Add Device in the Ajax app.
2. Name the device, scan or enter the QR Code (located on the body and packaging), and select the location room.
3. Select Add — the countdown will begin.
4. Switch on the device.



LeaksProtect has a rigid “ON” button: press it with force to switch the detector on.

For the detection and pairing to occur, the device should be located within the wireless coverage area of the hub (at the same facility).

Request for connection is transmitted for a short time at the moment of switching on the device.

If the connection failed, LeaksProtect switches off after 6 seconds. To retry the connection, you do not need to reboot the device. If LeaksProtect is paired with another hub, switch the detector off, then retry the standard adding procedure.

The detector connected to the hub is displayed in the list of devices in the app.


The update of the detector status in the list depends on the device inquiry time set in the hub settings (the default value is 36 seconds).

Connecting to the third-party security systems

To connect the detector to a third-party security central unit using the or cartridge Oxbridge Plus integration module, follow the recommendations in the manual of the respective device.



The detector is always active. When connecting LeaksProtect to third-party security systems, it is appropriate to place the detector in a permanently active protection zone.

States

1. Devices 
2. LeaksProtect

Parameter	Value
Temperature	The temperature of the detector is measured on the processor and changes gradually
Jeweller Signal Strength	Signal strength between the hub and detector
Battery Charge	The battery level of the device. Displayed as a percentage How battery charge is displayed in Ajax apps
Lid	The state of the tamper, which reacts to the body being disassembled or damaged
ReX	Displays the status of using a radio signal range extender
Connection	Connection status between the hub and detector
Leakage detected	Alarm if the water sensor contacts wet
Temporary Deactivation	Shows the status of the device: active, completely disabled by the user, or only notifications about triggering the device tamper buttons are disabled
Firmware	Detector firmware version
Device ID	Device identifier

Settings

1. Devices 
2. LeaksProtect
3. Settings 

Setting	Value
First eld	
Room	
Alert with a siren if leakage is detected	
Jeweler Signal Strength Test	
Temporary Deactivation	
User Guide	
Delete Device	

Indication

The LeaksProtect LED indicator may light up red or green depending on the device status.
Indication when pressing the power button

Event	Indication
Pressing the power button (detector is switched on)	Lights up red while the button is held down
Switching on	Lights up green while the device is switching on
Switching off	Initially lights up red, then blinks three times

Turned-on detector indication

Event	Indication	Note
Detector connection to the, and hub Oxbridge Plus cartridge	Lights up green for a few seconds	
Hardware error	Blinks red continuously	The detector requires repair, please contact Support Service
Leakage detected	Lights up red for about one second	
Battery needs replacing	During the alarm, it slowly lights up red and slowly goes out	Replacement of the detector the battery is described in the
		Battery replacement manual

Functionality Testing

Ajax security system allows conducting tests for checking the functionality of connected devices.

The tests do not start straight away but within a period of 36 seconds when using the standard settings. The test time start depending on the settings of the detector scanning period (the paragraph on “Jeweller” settings in the hub settings).

Jeweler Signal Strength Test Attenuation Test

Selecting the Location

When selecting the device location, please take into account its remoteness from the hub (up to 1300 meters) and the absence of any obstacles between the devices hindering the radio signal transmission: walls, doors, or large objects located in the room.



The device was developed only for indoor use.



Check the Jeweller signal strength level at the installation place.

If the signal level is low (one bar), we cannot guarantee the stable operation of the device. Take all possible measures to improve the signal strength. At least, move the device: even a 20 cm shift can significantly improve the quality of signal reception.

If after moving the device still has a low or unstable signal strength, use a radio signal range extender
Install LeaksProtect in the place of potential leakage: on the or under the bath, sink, washing machine, etc.

Do not install the detector:

- outside the premises (outdoors);
- nearby any metal objects or mirrors causing attenuation and screening of the signal;
- within any premises with the temperature beyond the range of permissible limit;
- on conductive surfaces;
- closer than 1 m to the hub.

Detector Testing

When the liquid gets on the detector contacts, it closes the electrical circuit. It is enough to close one contact pair to activate the alarm.

1. To check LeaksProtect, close one contact pair with a wet finger for 3 seconds (the delay prevents false triggering). If water is detected, the detector LED will light up red for 1 second.
2. Wipe the contacts with a dry napkin. When the electrical circuit is open, LeaksProtect switches on its LED red for 1 second and notices that the water dried out.

If you drown the detector with soapy water, it may continue signal coding after getting dry. The issue is about the soapy film closing the contacts. To eliminate the problem, wipe the detector contacts with a napkin moistened with pure water and then dry them up.

Maintenance

Check the LeaksProtect operational capability on a regular basis. We recommend cleaning the detector contacts as it gets dirty, at least, once every 2-3 months. Use an alcohol solution for cleaning the contacts.

Clean the detector body from dust, spider webs, and other contaminants as they appear: they can conduct electricity and cause false actuation. Use a soft dry napkin suitable for equipment maintenance.

Do not use any substances containing alcohol, acetone, gasoline, and other active solvents for cleaning the detector body.

The batteries installed in the detector ensure up to 5 years of autonomous operation on average (with the inquiry frequency by the hub of 1 minute). If the detector batteries are low, the security system sends the notification and the detector LED smoothly lights up and goes out green every hour if the device is triggered.

To replace the batteries, turn off the detector, loosen the screws and remove the LeaksProtect front panel. Change the batteries with new ones type AAA, adhering to polarity.

How long do Ajax devices operate on batteries, and what affects this Battery replacement?

Tech specs

Radio communication protocol	Jeweler Learn more
Radiofrequency band	866.0 – 866.5 MHz 868.0 – 868.6 MHz 868.7 – 869.2 MHz 905.0 – 926.5 MHz 915.85 – 926.5 MHz 921.0 – 922.0 MHz Depends on the region of sale.
Compatibility	Operates with all Ajax, hubs radio signal, range extenders Oxbridge Plus cartridge
Maximum RF output power	Up to 20 mW
Modulation of the radio signal	GFSK
Radio signal range	Up to 1,300 m (any obstacles absent) Learn more
Power supply	2 × AAA batteries
Power supply voltage	3 V (batteries are installed in pairs)
Battery life	Up to 5 years
Dust and moisture protection class	IP65
Installation method	Indoors
Operating temperature range	From 0°C to +50°C
Operating humidity	Up to 100%
Overall dimensions	56 × 56 × 14 mm
Weight	40 g
Service life	10 years

Compliance with standards

Complete Set

1. LeaksProtect
2. Batteries AAA (pre-installed) — 2 pcs
3. Quick Start Guide

Warranty

Warranty for the “AJAX SYSTEMS MANUFACTURING” LIMITED LIABILITY COMPANY products is valid for 2 years after the purchase and does not apply to the pre-installed battery.

If the device does not work correctly, you should rst contact the support service — in half of the cases, technical issues can be solved remotely!




The full text of the warranty

User Agreement

Technical support: support@ajax.systems






Subscribe to the newsletter about safe life. No spam
Email **Subscribe**

Documents / Resources

	AJAX LeakProtect Wireless Leakage Detector [pdf] User Manual LeakProtect, Wireless Leakage Detector, LeakProtect Wireless Leakage Detector
	AJAX LeakProtect Wireless Leakage Detector [pdf] User Manual LeakProtect, Wireless Leakage Detector, Leakage Detector, LeakProtect, Detector
	AJAX LeakProtect Wireless Leakage Detector [pdf] User Manual LeakProtect, Wireless Leakage Detector, Leakage Detector, Wireless Detector, Detector, Leak sProtect

References

- [End user agreement - Ajax Systems](#)
- [Jeweller radio technology | Ajax Systems](#)
- [Security system control panels | Ajax Systems](#)
- [LeakProtect — Wireless flood detector | Ajax Systems](#)
- [ocBridge Plus — Module for Ajax devices integration with wired systems](#)
- [Signal range extenders in the security system | Ajax Systems](#)
- [Alarm sirens for Ajax security systems](#)
- [uartBridge — Module for Ajax devices integration with third-party wireless alarms systems](#)
- [Jeweller and Wings radio protocols in the Ajax security system](#)
- [Software | Ajax Systems](#)
- [Ajax devices standards compliance list](#)
- [Warranty - Ajax Systems](#)
-  [How battery charge is displayed in Ajax apps | Ajax Systems Support](#)
-  [How long Ajax devices operate on batteries, and what affects this | Ajax Systems Support](#)

-  [How to temporarily deactivate a device without removing it from the system | Ajax Systems Support](#)
-  [How to change batteries in the LeaksProtect | Ajax Systems Support](#)
-  [Jeweller radio protocol: technology and capabilities | Ajax Systems Support](#)
-  [What is Attenuation Test | Ajax Systems Support](#)
-  [What is Jeweller Signal Strength Test | Ajax Systems Support](#)

Manuals+.