

AKAI CS2 GLOW Portable Bluetooth Speaker User Manual

Home » AKAI » AKAI CS2 GLOW Portable Bluetooth Speaker User Manual

AKAI CS2 GLOW Portable Bluetooth Speaker



Contents

- **1 PACKING CONTENTS**
- **2 IMPORTANT NOTICE:**
- **3 SPEAKER DESCRIPTION**
- **4 PREPARATION BEFORE USE:**
- **5 HOW TO PAIR**
- 6 TWS PAIRING 2 SPEAKERS CS2 GLOW
- **7 TECHNICAL SPECIFICATIONS:**
- **8 CLEANING AND MAINTENANCE:**
- 9 PROBLEM SOLVING
- 10 DISPOSAL OF ELECTRICAL AND ELECTRONIC

EQUIPMENT

- 11 Documents / Resources
- 11.1 References
- **12 Related Posts**

PACKING CONTENTS

- LED Bluetooth Speaker*1
- Type-C charging cable*1
- 3.5mm AUX IN Cable*1
- User manual*1
- Warranty card *1


IMPORTANT NOTICE:

Read the instruction carefully before first use. Keep the manual in a safe place for future consultation. When

passing the product to another person, be sure include this manual.

- * Unpack the device carefully. Make sure there are no accessories left in the box.
- * Keep the product out of reach of children.
- * Do not expose it to rain, liquids or moisture.
- * Avoid dropping it, do not expose it to strong shocks.
- * Do not clean with solvents or alcohol-based cleaners.
- * Do not use in extremely hot, cold and dusty places.
- * Do not disassemble the product. For any operating problem, contact only qualified personnel.
- * Do not use the device while charging.

SPEAKER DESCRIPTION



- 1. Power On/Off button
 - a. Long press: turn on/off the speaker
 - b. Short press: reject a call
 - c. Double press: enter TWS function.

In wireless connection mode, if there are two speakers CS2 GLOW power on both of them, double press power on/off button to activate TWS mode, they will connect to each other automatically and play same song.

- 2. LED button
 - a. Long press: LED Light on/off b. Short press: change LED light effect
- 3. Microphone
- 4. Volume -/Previous track a. Short press: previous track b. Long press: volume down
- 5. Mode button: a. Long press: change input mode(BT/TF/USB host/Aux in)
 - b. Short press: Play /Pause/Pick up/Hang off a call
 - c. Double press: Disconnect in BT mode.
- 6. Volume +/Next track
 - a. Short press: next trackb. Long press: Volume up
- 7. TY PE- C (for charging)
- 8. 3.5mm Aux-in port.
- 9. Indicator light a. Red light constant: Charging b. Blue light blinking: ready to pair c. Blue light constant: paired 1
- 10. USB Host
- 11. Micro SD card

PREPARATION BEFORE USE:

Attention! The built-in battery must be charged completely prior to the application. Connection the speaker with the charging cable included in the box to a USB charger or a PC. The correct voltage is 5V.

HOW TO PAIR

- Turn on the product, the wireless mode will be activated automatically.
- Activate the Bluetooth function of your smart phone. -Search the device named "CS2 GLOW" and connect.
- When paired, you will hear a sound.

TWS - PAIRING 2 SPEAKERS CS2 GLOW

This speaker is equipped with TWS technology. TWS (True Wireless Stereo) is a technology that allows you to pair two audio devices wireless, allowing you to transmit the L(left) channel and the R(right) channel separately, by activating TWS you can fully enjoy your playlist. Paring: turn on the 2 speakers, in wireless connection, double press the "Power on/ off" button of either of the 2 speakers. The connection between the two devices will be done automatically.

TECHNICAL SPECIFICATIONS:

- Power source: 5V, 1A
- Power consumption: 7W
- Control buttons: Power On/Off, LED light, Previous track/Volume down, Mode, Next track/Volume up.

- Built- in microphone, hands-free function.
- Bluetooth version: V5.0
- · Bluetooth channel emission power: 2dbm
- Bluetooth frequency: 2,402 GHZ- 2,480 GHZ Bluetooth action range up to more than 10 meters. Speaker unit: 1 x 10W.
- Battery 3.7V, 2600mAh.
- Frequency response:70Hz 15KHz.
- Sensitivity: 82 db (+/- 3 dB).
- Micro SD port + USB host (support 64G max) reads only MP3 files
- Jack 3.5mm connection
- Playing time: 4hours with LED on, 70% volume
- · Charging time: 4.5 hours
- Dimensions of the speaker:210 x 94 x 94 mm.
- · Weight of the speaker: 611g.

CLEANING AND MAINTENANCE:

Make sure the unit is unplugged from the AC outlet before cleaning. Make sure the unit is completely cool before cleaning. Clean the outside of the machine with a cloth. Do not use solvents (such as alcohol, benzene, diluents, etc.) as these may damage the unit.

PROBLEM SOLVING

- A. Cannot connect the speaker to a device
- 1) Make sure the speaker is on.
- 2) Ensure that the speaker is at a distance to about 10 meters from the tablet, the Smartphone.
- **3)** Make sure the speaker battery is charged. 4) Make sure that the BT function of the tablet, Smartphone is activated. **B.** Cannot load the speaker
- 1) Make sure the charging cable is securely connected to the speaker and the USB PC / charger (not supplied)
- 2) Make sure the computer is turned on

Warning! If you use a USB charger to charge the speaker, make sure that the maximum power of the charger does not exceed 5V / 1A to avoid damaging your speaker.

DISPOSAL OF ELECTRICAL AND ELECTRONIC EQUIPMENT

This symbol on the product or packaging means that the product should not be treated as household waste. Do not throw garbage at the end of its life, but take it to a collection center for recycling. in this way you will help to protect the environment and be able to prevent any negative consequences that it would have on the environment and human health. To find your nearest collection center:

- · Contact local authorities
- Access the website: www.mmediu.ro
- Request additional information from the store where you purchased the product.



Documents / Resources



AKAI CS2 GLOW Portable Bluetooth Speaker [pdf] User Manual CS2 GLOW Portable Bluetooth Speaker, CS2 GLOW, Portable Bluetooth Speaker, Bluetooth Speaker

References

- SEKOL » asekol
- © ASEKOL SK » ASEKOL reprezentuje ČR v kategórii ekologicky zodpovedných firiem na prestížnej celoeurópskej súťaži
- **(4)** ДАМТН
- O Home | Ministerul Mediului
- Ministerstwo Ašrodowiska- Portal Gov.pl

Manuals+,