
$\underline{\textbf{Manuals+}} \ - \ \textbf{User Manuals Simplified}.$



AKAI S950RE RAM Expansion Module Installation Guide

Home » AKAI » AKAI S950RE RAM Expansion Module Installation Guide 🖔

AKAI S950RE RAM Expansion Module



Contents

- 1 INSTALLATION GUIDE
- 2 Documents /


Resources

2.1 References

INSTALLATION GUIDE

STEP 1 – FLIP IT OVER

Flip your sampler and remove the bottom RAM cover lid




STEP 2 – INSERT THE PLASTIC THING

If your sampler's board does not have the small plastic PCB holder, one is included with your RAM module; insert it to the board – just push it softly into the hole



STEP 3 – INSERT THE RAM MODULE

The RAM modules are keyed, they can't be inserted backwards – just push them into the socket



STEP 4 - FIX IT WITH THE PLASTIC WASHER AND M2.5 NUT

A plastic washer and M2.5 nut is also included with each RAM module; just tighten it with hand, that should be enough

Documents / Resources



AKAI S950RE RAM Expansion Module [pdf] Installation Guide S950RE RAM Expansion Module, S950RE, RAM Expansion Module, Expansion Module, Module e

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.