



3087 V3
User Manual
Quick Start Guide


Thank you for supporting Akko

To provide you with a better user experience, please read this manual carefully before using the product.

Contents [[hide](#)]

- [1 Product Overview](#)
- [2 Packing List](#)
- [3 Connectivity Method](#)
- [4 Akko Warranty and Service Statement](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)

Product Overview



LED Indicator

LED Indicator 1	Caps	Steady White
LED Indicator 2	System Indicator	Mac OSX (Steady White)
LED Indicator 3	Lock Win	Steady White

Packing List




System Requirement

Windows XP/Vista/7/8/10 or higher version

Connectivity Method

Connect the keyboard to your computer by plugging in the USB cable into an available USB port to start using it.


3087 V3 Hotkeys



Fn+F1	File Explorer
Fn+F2	E-mail
Fn+F3	Windows Search


Fn+F4	Browser Homepage
Fn+F5	Multimedia Player
Fn+F6	Play/Pause
Fn+F7	Previous Song
Fn+F8	Next Song
Fn+C	Calculator
Fn +M	Mute
Fn+<	Decrease Volume
Fn+>	Increase Volume
Fn+W	Swap WASD with↑↓← →

3087 V3 System Commands (Windows)




Press Fn and left Win Key	Lock Win key
Hold down left Win and press right Winkey for 5S	Restore factory settings
Hold down Fn and press right Ctrl for 3S	Revert Ctrl into Menu (APP) key
Hold down Fn and press Q key for 3S	Enter Windows system
Hold down Fn and press O key for 3S	Enter Mac system

3087 V3 System Commands (Mac)



F1	Decrease display brightness
F2	Increase display brightness
F3	Open mission control
F4	Activate Siri
Right Alt	Command
Right Win	Option
F7	Skip back (Audio)
F8	Pause/Play (Audio)
F9	Skip forward (Audio)
F10	Mute
Fn+ (F1~F12)	F1~F12
F11	Volume down
F12	Volume up
Left Win	Option
Left Alt	Command

3087 V3 Backlight Settings (for models with backlight)



Fn+-	Slower Animation
Fn+=	Faster Animation
Fn+L	Light On / Off
Fn+ ↑	Bright
Fn+←	Set animation direction to left
Fn+→	Set animation direction to right
Fn+↓	Dim
Fn+Del	Steady (default), Effect 2, Effect 3, Effect 4, Effect 5, Effect 6, Effect 7, Effect 8, Effect 9, Effect 10, Effect 11, Effect 12, Effect 13, Effect 14, Effect 15, Effect 16, Effect 17, Effect 18, Effect 19

Akko Warranty and Service Statement

1. Akko provides One-Year warranty for customers in mainland China. For other regions, please contact your seller (Akko distributor) for specific warranty policy.
2. If the warranty window expires, customers need to pay for repairs. Akko will also provide instructions if users prefer to repair the keyboard by themselves. However, users shall take full responsibility for any loss happened during self-repair.
3. Defects resulting from disassembly of our product, improper usage and incorrect installation are not covered by warranty.
4. The return and warranty policy may vary in different platform sand are subject to the specific distributor at the time of purchase.

Company: Shenzhen Yancheng Technology Co., Ltd

Address: 33 Langbi Rd, Bitou Community 1st Industrial Zone, Bao'an District, Shenzhen, China

Tel: 0755-23216420

Website: www.akkogear.com

Origin: Shenzhen, China

 **WARNING:**

Water and Beverages can't be poured into the Keyboard.



'Made in China

Precautions

Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive forces, etc.



www.akkogear.com

		
	http://weixin.qq.com/r/oRETC_DECb12raRo90Sz	http://qr.weibc

Documents / Resources



[Akko 3087 V3 Mechanical Keyboard \[pdf\]](#) User Manual

3087 V3 Mechanical Keyboard, 3087 V3, Mechanical Keyboard, Keyboard

References

- [User Manual](#)

📄 3087 V3, 3087 V3 Mechanical Keyboard, AKKO, Keyboard, Mechanical

📁 AKKO keyboard

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.