



# AKKO 5075 VIA Wireless Keyboard User Manual

[Home](#) » [AKKO](#) » AKKO 5075 VIA Wireless Keyboard User Manual 



Contents

1

5075 VIA Wireless Keyboard

2

LED Indicator

3

Packing List

4

Installation Guide

5

AKKO Warranty and Service Statement

6

Documents / Resources

6.1

References

## 5075 VIA Wireless Keyboard

**Thank you for supporting Akko**  
To provide you with a better user experience, please read this manual carefully before using the product.

### LED Indicator

LED Indicator 1	Caps	Steady White
LED Indicator 2	System Indicator	Mac OSX (Steady White) / Windows (OFF)
LED Indicator 3	Lock Win	Steady White



Press the Knob = Mute;


Turn the encoder counterclockwise = Volume -;

Turn the encoder clockwise = Volume +.

Press FN key + Knob = Switch to a different lighting effect;

Press FN + Turn the knob counterclockwise = Backlight Brightness -;

Press FN + Turn the knob clockwise = Backlight Brightness +.




Left: Windows

Center: Windows

Right: MAC

## Packing List




## System Requirement

Windows®XP / Vista / 7 / 8 / 10 or higher version

## Installation Guide


Plug the USB cable of the keyboard into a USB port on your computer to start using it.

**5075 VIA HotKeys**




Fn+	F1	=	My Computer
	F2		E-mail
	F3		Windows Search
	F4		Browser Homepage
	F5		Multimedia Player
	F6		Play/Pause
	F7		Previous Song
	F8		Next Song
	I		Ins
	P		Print SCR
	C		Calculator
	M		Mute
	<		Decrease Volume
	>		Increase Volume
	w		Swap W A S D with ↑ ↓ ← →

5075 VIA System Commands (Windows)



<b>Lock Win Key</b>	<b>Restore Factory Settings</b>
Press Fn and left Win key	Hold down Fn and ~ key for 3s


## 5075 VIA System Commands (Mac)



F1	Decrease display brightness	F7	Skip back (Audio)	F11	Volume down
F2	Increase display brightness	F8	Pause/Play (Audio)	F12	Volume up
F3	Open mission control	F9	Skip forward (Audio)	Left Win	Option
F4	Activate Siri	F10	Mute	Left Alt	Command
				Right Alt	Command

$$\mathbf{F}_n + (\mathbf{F}_1 \quad \mathbf{F}_{12})$$

## 5075 VIA Backlight Settings



FN+	Slower Animation	FN+↑	Bright	FN+←	Color saturation-
FN+=	Faster Animation	FN+↓	Dim	FN+→	Color saturation+
FN+L	Light On / Off	FN+ \	18 different lighting effects will be changed		

## AKKO Warranty and Service Statement

1. Akko provides One-Year warranty for customers in mainland China. For other regions, please contact your seller (Akko distributor) for specific warranty policy.
2. If the warranty window expires, customers need to pay for repairs. Akko will also provide instructions if users prefer to repair the keyboard by themselves.  
However, users shall take full responsibility for any loss happened during self-repair.
3. Disassembling the keyboard without manufacturer/seller's instruction will immediately void the warranty.
4. The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd, Bitou Community 1st Industrial Zone, Bao'an District, Shenzhen, China

Tel: 0755-23216420

Website: [www.akkogear.com](http://www.akkogear.com)

Origin: Shenzhen, China



**WARNING:** Water and Beverages can't be poured into the Keyboard.



Made in China



[instagram.com/akkogear](https://www.instagram.com/akkogear)



[facebook.com/akkogear](https://www.facebook.com/akkogear)




[tiktok.com/@akkogear](https://www.tiktok.com/@akkogear)

## Precautions

Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive forces, etc.



Documents / Resources

	<a href="#">AKKO 5075 VIA Wireless Keyboard</a> [pdf] User Manual 5075VIA Windows, 5075VIA Mac, 5075 VIA Wireless Keyboard, 5075 VIA, Wireless Keyboard, Keyboard
---	--

References

- [Instagram \(@akkogear\) • Instagram photos and videos](#)
- [Akko \(@akkogear\) | TikTok](#)
- [Akko 5075 VIA Wireless Keyboard User Manual](#)