



5098B Three Mode Keyboard



AKKO 5098B Three Mode Keyboard User Manual

[Home](#) » [AKKO](#) » AKKO 5098B Three Mode Keyboard User Manual 

Contents


- 1 AKKO 5098B Three Mode Keyboard
- 2 Products
- 3 Connectivity Method
- 4 LED Indicator Overview
- 5 Function Keys
- 6 Power Switch
- 7 System Commands (Windows)
- 8 System Commands (Mac)
- 9 Backlight Settings
- 10 Key/Lighting Effects Customization instruction
- 11 Wireless/Wired Connection Guide
- 12 Bluetooth Pairing
- 13 2.4G Pairing
- 14 Akko Warranty and Service Statement
- 15 Precautions
- 16 Documents / Resources
 - 16.1 References



AKKO 5098B Three Mode Keyboard



Products



Packing List



What's in the package

Windows®XP / Vista / 7 / 8 / 10 or higher version

Connectivity Method


Connect the keyboard to your computer by plugging in the USB cable into an available USB-A port to start using it.

LED Indicator Overview

State	Indicator	Re-Connecting	Pairing	Connected
Bluetooth device 1	LED for key E	Blue light blinks slowly	Blue light blinks fast	On for 2s and then of
Bluetooth device 1	LED for key R	Blue light blinks slowly	Blue light blinks fast	On for 2s and then off
Bluetooth device 1	LED for key T	Blue light blinks slowly	Blue light blinks fast	On for 2s and then off
2.4G wireless device	LED for key Y	Green light blinks slowly	Green light blinks fast	On for 2s and then off
Wired mode	LED for key U	N/A	N/A	Red light On for 2s and then off

Status	Indicator	Indicating mode
Low Battery	The third indicator light	Red Light Blinks Slowly
Charge	The third indicator light	Steady Red
Fully Charged	The third indicator light	LED OFF
Caps	The first indicator light	Steady White
Num	The second indicator light	Blue light is always on
Lock Win	Win key indicator	Steady White


Function Keys



Fn+	W	=	Swap W A S D with ↑ ↓ ← →
	F1		My Computer
	F2		E-mail
	F3		Windows Search

Fn+	F4	=	Browser Homepage
	F5		Multimedia Player
	F6		Play/Pause
	F7		Previous Song
	F8		Next Song

Power Switch




5098B LCD Screen Features Encoder Wheel

- Scroll Up: Volume
- Scroll Down: Volume-
- Press: Play/Pause
- Fn + Press: Switch to screen control mode
 - Scroll Up/Down: Switch between screen functions
 - Press: Confirm the selection and return to the previous level

Volume Control	Volume up, Volume down
Lighting Effects	Effect1, Effect2, Effect3, Effect4, Effects, Effect6, Effect7, Effects, Effect9, Effect10, Effect11, Effect12, Effect13, Effect14, Effect15, Effect16, Effect17, Effect18, Effect19, Effect20
Light Color	Rainbow, Red, Green, Blue, Orange, Purple, Yellow, Custom (White)
Light brightness	0 – 25% – 50% – 75% – 100%
Light Speed	0 – 25% – 50% – 75% – 100%
Side light effect	Neon, Wave, Marquee, Steady, Breathing, Off
Language Selection	CN, DE, EN, RU, VN
Connection	Bluetooth device 1, Bluetooth device 2, Bluetooth device 3 2.4G wireless device, Wired mode, Return


System Commands (Windows)



Fn+	~	=	Press and hold for 3 seconds to restore to factory settings
-----	---	---	---

Fn+	L_Win	=	Lock Windows Key
-----	-------	---	------------------

System Commands (Mac)




Fn+	F1	=	Decrease display brightness
	F2		Increase display brightness
	F3		Open mission control
	F4		Activate Siri
	F7		Skip back (Audio)
	F8		Pause/Play (Audio)
	F9		Skip forward (Audio)

Fn+	F10	=	Mute
	F11		Volume down
	F12		Volume up

L_Win	=	L_Option
L_Alt		L_Command
R_Alt		R_Command

Backlight Settings




Fn+	Del	=	Effect1、 Effect2、 Effect3、 Effect4、 Effect5、 Effect6、 Effect7 、 Effect8、 Effect9、 Effect10、 Effect11、 Effect12、 Effect13 、 Effect14、 Effect15、 Effect16、 Effect17、 Effect18、 Effect19、 Effect20
	↑		Bright
	↓		Dim
	←		Set animationdirection to left
	→		Set animationdirection to right
	?		Slower Animation
	,		Faster Animation
	#		This shortcut allows you to set the backlightcolor to 7 single color with RGB loop effect
	Y		Adjust side LED brightness (5 levels)
	X		Adjust side LED animation speed (5 levels)
	L		Light Off/On
	Left Ctrl		Adjust side LED mode, including Lights OFF (6 levels)
	Left Alt		Side LED mode: This shortcut allows you to set the light to 7 single colors with an RGB loop effect

Key/Lighting Effects Customization instruction

1. The keys can be remapped and RGB can be programmed in the driver in any of the connection mode.
2. Keyboard lighting can be coordinated with the driver to achieve audio visualizer
3. Please download the Akko Cloud driver on our website
4. Users can download the driver via www.akkogear.eu

Wireless/Wired Connection Guide



Fn+	E	=	Bluetooth Device 1
	R		Bluetooth Device 2
	T		Bluetooth Device 3
	Z		2.4G Wireless Device
	U		Wired Mode

Short press to reconnect
 Long press to pair

Bluetooth Pairing

After the keyboard is turned on, press Fn+E/R/T to enter Bluetooth mode. Press and hold the Fn+E/R/T key combination for 3 seconds, and the keyboard will enter the pairing state. The blue indicator light will flash quickly, and the indicator light will stay on for 2 seconds after connecting. If the device is not connected, the indicator light will go out and the keyboard will enter sleep mode.

2.4G Pairing

After turning on the keyboard, press FN+Y to enter 2.4G mode. Then press and hold the FN+Y Key combination for 3 seconds to enter pairing mode. Then insert in the receiver, and the indicator light will flash quickly. Once the pairing is successful, the LED indicator will stay on for 2 seconds. If no available device is found within 30 seconds, the LED indicator will turn off and the keyboard will enter sleep mode.

Battery Level Check

In wireless mode, press the Fn+Space key combination to check the battery power. When the battery is below 30%, the space key will light up red; 30-50% will light up orange, 50-70% will light up purple, 70-90% will light up yellow, 90-100% will light up green.

Low 30%	Low 50%	Low 70%	Low 90%	Low 100%
Red Light	Orange Light	Purple Light	Yellow Light	Green Light

Akko Warranty and Service Statement

1. Ako provides a One-Year warranty for customers in mainland China, For other regions, please contact your seller (Ako distributor) for a specific warranty policy.
2. If the warranty window expires, customers need to pay for repairs, Akkowill also provides instructions if users prefer to repair the keyboard by themselves, However, users shall take full responsibility for any loss happened during self-repair.
3. Defects resulting from disassembly of our product, improper usage and incorrect installation are not covered by warranty.
4. The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.

Company: Shenzhen Yinchon Technology Co., Ltd

Address: 33 Langbi Rd, Bitou First Industrial Zone, Bao'an District, Shenzhen, China

Tel: 0755-23216420

Website: www.akkogear.eu

Origin: Shenzhen, China

Precautions


Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive forces, etc.

- www.akkogear.eu



- [@akkogear.eu](https://www.instagram.com/akkogear.eu)
- [akkogear.eu](http://www.akkogear.eu)

Documents / Resources



[AKKO 5098B Three Mode Keyboard](#) [pdf] User Manual
5098B Three Mode Keyboard, 5098B, Three Mode Keyboard, Mode Keyboard, Keyboard

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.