



Home » AKKO » AKKO 5108 B-PLUS Wireless Full Size Keyboard User Manual 📆

Contents [hide]

- 1 AKKO 5108 B-PLUS Wireless Full-Size Keyboard
- 2 LED Indicators
- 3 Bluetooth Pairing
- 4 Pairing
- 5 Battery Level Check
- 6 Key/Lighting Effects Customization Instruction
- 7 AKKO Warranty and Service Statement
- 8 Precautions
- 9 Frequently Asked Questions
- 10 Documents / Resources
 - 10.1 References



AKKO 5108 B-PLUS Wireless Full-Size Keyboard



Specifications

• Model: 5108B Plus

• Connectivity: USB, Bluetooth 1-3, 2.4G wireless

Compatibility: Windows, Mac

Connectivity

• Connect the keyboard to your computer by plugging in the USB cable into an available USB port to start using it.

LED Indicators

- **Bluetooth Device Indicators:** Blue light blinks slowly when pairing, blinks fast when connected, and is off for 2 seconds when not connected.
- **2.4G Wireless Indicator:** Green light blinks slowly when pairing, blinks fast when connected, and stays on for 2 seconds when fully connected.
- Battery Status Indicator: White light blinks slowly for low battery, steady white when charging, and off when fully charged.
- Caps Lock Indicator: Steady white light.

HotKeys

- Windows HotKeys: Various functions, including File Explorer, Email,
 Search, Browser, and Media control, are available using specific key combinations.
- System Commands (Windows and Mac): Includes commands to lock the Windows key, restore factory settings, and revert the Ctrl key to the Menu key.
- **Backlight Settings:** Adjust volume, brightness, animation speed, and direction using specific key combinations.

Reverting System Settings

• To revert system settings or restore factory settings, follow the specific key

combinations mentioned in the user manual.

Thank you for supporting Akko

To provide you with a better user experience, please read this manual carefully before using the product.

Packing List



System Requirement

Windows @XP/Vista/7/8/10 or higher version


Connectivity Method

Connect the keyboard to your computer by plugging in the USB cable into an available USB port to start using it.


LED Indicators

State	Indicator	Re-Connecting	Pairing	Connected	
Bluetooth device 1	LED for Key E	Blue light blinks slowly	Blue light blinks fast	The blue light is off 2s	
Bluetooth device 2	LED for Key R	Blue light blinks slowly	Blue light blinks fast	The blue light is off 2s	
Bluetooth device 3	LED for Key T	Blue light blinks slowly	Blue light blinks fast	The blue light is off 2s	
2.4G wireless device	LED for Key Y	Green light blinks slowly	Green light blinks fast	The green light is on for 2 seconds	
Wired mode	LED for Key U	N/A	N/A	The red light turns off for 2 seconds	
Chatan		Indicating mode			
Status	Indicator		Indicating mo	ode	
Low Battery	Indicator Side LED Indicator 3		Indicating mo		
				slowly	
Low Battery	Side LED Indicator 3		White light blinks s	slowly	
Low Battery Charge	Side LED Indicator 3 Side LED Indicator 3		White light blinks s Steady white	slowly	
Low Battery Charge Fully Charged	Side LED Indicator 3 Side LED Indicator 3 Side LED Indicator 3		White light blinks s Steady white LED OFF	slowly	


5108B Plus HotKeys



5108B Plus System Commands (Windows)




5108B Plus System Commands (Mac)





F1	Decrease display brightness	F7	Skip back (Audio)	F11	Decrease Volume
F2	F2 Increase display brightness		Pause/Play (Audio)	F12	Increase Volume
F3	F3 Open mission control		Skip forward (Audio)	Left Win	Option
F4	F4 Activate Siri		Mute	Left Alt	Command
Right Alt Command Fn + (F1 ~ F12)					
Right	t Win Option		F1 ~ F12		


5108B Plus Backlight Settings



5108B Plus Connection Usage Guide







- After turning on the keyboard, press Fn+E/R/T to enter Bluetooth mode.
 Press and hold the Fn+E/R/T combination key for 3 seconds to put the keyboard in pairing mode, with the blue indicator light flashing quickly.
- After successful pairing, the keyboard will enter a low-power sleep mode after being idle for 2 minutes. The keyboard will enter the hibernate state 15 minutes after entering the low-power sleep mode.

Pairing

- After turning on the keyboard, press Fn+Y to enter 2.4G mode. Then press and hold the Fn+Y combination key for 3 seconds to enter pairing mode. Then insert the receiver, and the indicator light will flash quickly. After successful pairing, the keyboard will enter a low-power sleep mode after being idle for 2 minutes.
- The keyboard will enter the hibernate state 15 minutes after entering the low-power sleep mode.

Battery Level Check

• Press the Fn + Space combination keys to check the battery level. If the battery level is below 30%, the space key will show a red light. If it's between 30-50%, the space key will show an orange light. If it's between 50-70%, the space key will show a purple light. If it's between 70-90%, the space key will show a yellow light. If it's 90-100%, the space key will show a green light.

Key/Lighting Effects Customization Instruction

- 1. The driver can be connected, and the lighting and key can be customized under the three working modes of the keyboard.
- 2. The three working modes of the keyboard can be matched to drive the music rhythm.m
- 3. Please download the Akko Cloud driver from our website
- 4. Users can download the driver via en.akkogear.com

AKKO Warranty and Service Statement

- Akko provides a One-Year warranty for customers in mainland China. For other regions, please contact your seller (Akko distributor) for the specific warranty policy.
- 2. If the warranty window expires, customers need to pay for repairs. Akko will also provide instructions if users prefer to repair the keyboard by themselves.
- 3. However, users shall take full responsibility for any loss that occurs during self-repair.
- 4. Disassembling the keyboard without the manufacturer/seller's instructions will immediately void the warranty.
- 5. The return and warranty policy may vary on different platforms and are subject to the specific distributor at the time of purchase.

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd, Bitou Community 1st Industrial Zone, Bao'an District,
 Shenzhen, China Tel: 0755-23216420

• Website: <u>www.akkogear.com</u>

• Origin: Shenzhen, China

CE FC & X

Precautions

 Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive forces, etc.

www.akkogear.com



Frequently Asked Questions

How do I pair a Bluetooth device?

To pair a Bluetooth device, ensure the keyboard is in pairing mode and follow the device's instructions for Bluetooth pairing. The indicator light will blink slowly during the pairing process.

How do I adjust the backlight settings?

To adjust the backlight settings, use the specific key combinations mentioned in the user manual to control brightness, animation speed, and direction.

What are the system commands for Windows and Mac?

The system commands include functions like locking the Windows key, restoring factory settings, and changing key functionalities. Refer to the manual for detailed key combinations.

Documents / Resources



AKKO 5108 B-PLUS Wireless Full Size Keyboard [pdf] User Manual 5108 B-PLUS, 5108 B-PLUS Wireless Full Size Keyboard, Wireless Full Size Keyboard, Full Size Keyboard, Keyboard

References

- User Manual
- AKKO

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name		
Email		
Website		
Save my name, email, and website in this browser for the next time I com	ment.	
Post Comment		
Search:		
e.g. whirlpool wrf535swhz	Search	

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.