



# AKKO PC75B Plus Mechanical Keyboard User Manual

[Home](#) » [AKKO](#) » AKKO PC75B Plus Mechanical Keyboard User Manual 

## AKKO PC75B Plus Mechanical Keyboard



### Contents


- [1 Technical Specifications](#)
- [2 HotKeys](#)
- [3 System Commands \(Windows\)](#)
- [4 System Commands\(Mac\)](#)
- [5 Backlight Settings](#)
- [6 Bluetooth Feature Overview](#)
- [7 Bluetooth Setup Instruction 1](#)
- [8 Key/Lighting Effects Customization Instruction](#)
- [9 Akko Warranty and Service Statement](#)
- [10 CUSTOMER SERVICE](#)
- [11 Documents / Resources](#)
  - [11.1 References](#)
- [12 Related Posts](#)

## Technical Specifications

- **Dimensions** Approximately 331\*115\*46mm
- **Weight** Approximately 1kg
- **Country of Origin** China
- **Type** Mechanical Keyboard
- **Keycap** PBT Material

- **Connection** Bluetooth/USB/2.4Ghz
- **Interface** Type-C To USB
- **Battery Capacity** 3000mAh
- **Multimedia Keys** YES
- **N-Key Rollover** YES
- **Key/Lighting Effects Customization** The keyboard can only be customized with driver in wired mode

### HotKeys




Fn+	F1		File Explorer
	F2		E-mail
	F3	=	Windows Search
	F4		Browser Homepage
	F5		Media

Fn+	F6		Pause /Playback
	F7		Previous Song
	F8	=	Next Song
	I		Insert
	C		Calculator


Fn+	M	Mute
	<	Decrease Volume
	> =	Increase Volume
	w	Swap W A S D with ↑↓ ← →

### System Commands (Windows)




Lock Windows Key	Press Fn and left Win key
Restore Factory Settings	Hold down Fn and press  key for 5S
Revert Ctrl into Menu (APP) key	Hold down Fn and press right Ctrl for 3S

Adjust volume / light brightness



### System Commands(Mac)




Back Switch Indicator

Users can switch to Mac mode by pushing the toggle on the back to the right.

- F1 Decrease display brightness
- F2 Increases display brightness
- F3 Open mission control
- F4 Activate Siri
- F7 Skip back (Audio)
- F8 Pause/Play (Audio)
- F9 Skip forward (audio)
- F10 Mute
- F11 Volume down
- F12 Volume up
- Left Win Option
- Left Alt Command
- Right Alt Command
- **Fn + F1 F12**  
F1 F12

## Backlight Settings

Caps Lock Battery Level Indicator Lock Win




Fn+	Home		Effect 1 Effect 2 Effect 3 Effect 4 Effect 5
	PgUp		Effect 6 Effect 7 Effect 8 Effect 9 Effect 10
	PgDn	=	Effect 11 Effect 12 Effect 13 Effect 14 Effect 15
	End		Effect 16 Effect 17 Effect 18 Effect 19 Effect 20
	L		Light On / Off
	\		In all lighting effects with RGB color mode, this shortcut allows you to set the backlight color to 7 single color with RGB loop effect.

Fn+	“↑”		Bright
	“↓”		Dim
	“←”	=	Set animation direction to left
	“→”		Set animation direction to Right
	“_”		Slower Animation
	“+”		Faster Animation

<b>Fn+Z</b>
PC Case Light Brightness Change
<b>Fn+X</b>
PC Case Light Animation Speed Change
<b>Fn+ Left Ctrl</b>
PC Case Light Effect Change

**Bluetooth Feature Overview**



Fn+	E	=	Bluetooth device 1		Short press to connect with slow flashing blue LED; Press and hold to pair device with fast flashing blue LED.
	R		Bluetooth device 2		
	T		Bluetooth device 3		Short press to connect with slow flashing green LED; The lighting effect will be restored when pairing succeeds.
	Y		2.4G wireless device		
	U		Wired mode		



Back Switch Indicator

**Left :** Windows

**Middle:** Switch to USB mode and stop charging. (Windows)

**Right:** Mac

## Bluetooth Setup Instruction 1

### Switch to Bluetooth mode

1. When the keyboard remains unplugged, users can push the switch on the back to the left/right to enter Windows/Mac mode correspondingly. Then long press and hold Fn + E / R / T to start pairing with Bluetooth devices. The keyboard will enter Bluetooth pairing mode when the blue LEDs under E / R / T keys flash quickly.
2. When the Keyboard is plugged into the computer through USB interface, it will enter Bluetooth mode automatically without having to push the switch on the back. Users can directly long press and hold Fn + E / R / T to enable Bluetooth pairing. The keyboard will enter Bluetooth pairing mode when the blue LEDs under E / R / T keys flash quickly.

### Set the Bluetooth profile

To help user recognize individual Bluetooth device, the keyboard is equipped with both Bluetooth 5.0 and 3.0 frameworks. The device name under the Bluetooth 5.0 framework is Akko PC75 BT-1 / Akko PC75 BT-2 / Akko PC75 BT-3 while the device name under Bluetooth 3.0 is AKK0 PC75 BT3.0. Once the devices are paired through Fn + E/R/T, the system will by default memorize the last connected device before you turn off the Bluetooth mode.

### **Bluetooth Pairing**

The keyboard can be paired with PC, Pad, smartphone and other devices with Bluetooth turned on. When you first try to search Bluetooth devices, two groups of device names shall appear with Akko PC75 BT3.0 (Bluetooth 3.0) and Akko PC75-1 (Bluetooth 5.0). Select a Bluetooth group based on your preferences (Note: some devices can only search for the Bluetooth 5.0 group).

### **Switch the Bluetooth device**

After 4 Bluetooth devices have been paired with the keyboard, press Fn+E / Fn+R / Fn+T / Fn+Y for at least 3 seconds to quickly switch between them.

### **Shut off the keyboard**

Turn the power off on the keyboard back panel while unused for power saving;

If the keyboard remains unused for over 10 mins, it would go to sleep mode and you can activate it by pressing any key.

**Note:** The battery saver mode for Windows system would affect/delay the sleep activation time of the keyboard.

### **Reset the keyboard**

If you forgot the specific paired front-end device or if there remains disorder in Bluetooth connection and communication, you'll need to clear the computer's Bluetooth cache by removing the PC75 keyboard from the list of connected device.

## **Key/Lighting Effects Customization Instruction**

1. The key/lighting effects customization can be programmed by Akko driver.
2. In wired mode, the lighting effects can also achieve audio visualizer effects with Akko driver.
3. Please download the Akko Cloud driver on our website.
4. Users can download the driver via [en.akkogear.com](http://en.akkogear.com)

## **Akko Warranty and Service Statement**

1. Akko provides 1-yr warranty for customers in mainland China. For other regions, please contact your seller (Akko distributor) for specific warranty policy.
2. If the warranty window expires, customers need to pay for repairs. Akko will also provide instructions if users prefer to repair the keyboard by themselves. However, users shall take full responsibility for any loss happened during self-repair.
3. Disassembling the keyboard without manufacturer/seller's instruction will immediately void the warranty.
4. The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.

**Precautions** Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive

forces, etc.

## CUSTOMER SERVICE

[www.akkogear.com](http://www.akkogear.com)

@akkogear



SCAEN ME



Documents / Resources



[AKKO PC75B Plus Mechanical Keyboard](#) [pdf] User Manual  
PC75B Plus Mechanical Keyboard, PC75B Plus, Mechanical Keyboard, Keyboard

## References

- [Akko® 34%... 1/2" «™ | 1/2" — 1/4" Akko® 34%... 1/2"](#)
- [Akko | Designer for Mechanical Keyboards](#)
- [Akko® 34%... 1/2" «™ | 1/2" — 1/4" Akko® 34%... 1/2"](#)