



AKKO PC98B B Plus Multi-Modes Keyboard User Manual

[Home](#) » [AKKO](#) » AKKO PC98B B Plus Multi-Modes Keyboard User Manual 

AKKO PC98B B Plus Multi-Modes Keyboard User Manual



Contents

- [1 Technical Specifications](#)
- [2 HOTKEYS](#)
- [3 System Commands\(Windows\)](#)
- [4 System Commands\(Mac\) I](#)
- [5 BLUETOOTH FEATURE OVERVIEW](#)
- [6 Bluetooth Setup Instruction](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

Technical Specifications

- **Dimensions:** Approximately 386x136x41mm
- **Weight:** Approximately 1.2kg
- **Country of Origin:** China
- **Type:** Mechanical Keyboard
- **Keycap:** PBT Material
- **Connection:** Bluetooth/USB/2.4Ghz
- **Interface:** Type-C To USB
- **Battery Capacity:** 3000mAh

- **Multimedia Keys:** YES
- **N-Key Rollover:** YES
- **Key/Lighting Effects Customization:** The keyboard can only be customized with driver in wired mode

HOTKEYS

Note: The following features are realized by the combination of “Fn” + corresponding key

- **F1** File Explorer
- **F2** E-mail
- **F3** Windows Search C Calculator
- **F4** Browser Homepage M Mute
- **F5** Media < Decrease Volume
- **F6** Pause / Playback > Increase Volume
- **F7** Previous Song W Swap W A S D with i 1 <— —>}
- **F8** Next Song


System Commands(Windows)

- **Lock Windows Key:** Press Fn and left Win key
- **Restore Factory Settings:** Hold down Fn and press – key for 5S
- **Enter Windows system:** Hold down Fn and press Q key for 3S
- **Enter Mac system:** Hold down Fn and press 0 key for 3S

System Commands(Mac) I

F1 Decrease display brightness F7 Skip back (Audio) left Win Option
 F2 Increases display brightness F8 Pause/Play (Audio) left Alt Command F3 Open mission control F9 Skip forward (audio) right Alt Command
 F4 Activate Siri F10 Mute Fn + (F1 ~ F12) F5 N/A F11 Volume down F1- F12 F6 N/A F12 Volume up

BLUETOOTH FEATURE OVERVIEW



Bluetooth Setup Instruction

1. Switch to Bluetooth mode

When the keyboard remains unplugged, turn the back switch to ON. Then long press and hold Fn + E / R / T to start pairing with Bluetooth devices. The keyboard will enter Bluetooth pairing mode when the blue LEDs under E / R / T keys flash quickly. 0 When the Keyboard is plugged into the computer through USB interface, it will

enter Bluetooth mode automatically without having to push the switch on the back. Users can directly long press and hold Fn + E / R / T to enable Bluetooth pairing. The keyboard will enter Bluetooth pairing mode when the blue LEDs under E / R / T keys flash quickly.

2. Set the Bluetooth profile

To help user recognize individual Bluetooth device, the keyboard is equipped with both Bluetooth 5.0 and 3.0 frameworks. The device name under the Bluetooth 5.0 framework is PC98BP-1/PC98BP-2/PC98BP-3 while the device name under Bluetooth 3.0 is Akko PC98BP BT3.0. Once the devices are paired through Fn + E / R / T, the system will by default memorize the last connected device before you turn off the Bluetooth mode.

QR Code



Documents / Resources



[AKKO PC98B B Plus Multi-Modes Keyboard](#) [pdf] User Manual
PC98B, 2A4K8-PC98B, 2A4K8PC98B, PC98B B Plus Multi-Modes Keyboard, PC98B, B Plus Multi-Modes Keyboard, Keyboard