



## Alcatel F685 Voice Smart Call Block User Guide

[Home](#) » [Alcatel](#) » Alcatel F685 Voice Smart Call Block User Guide 

### Contents

- 1 Alcatel F685 Voice Smart Call Block
- 2 BEFORE 1st USE
  - 2.1 Display icons
  - 2.2 Using the phone
  - 2.3 Phonebook settings: 100 entries
  - 2.4 To register in phonebook
  - 2.5 General settings
- 3 SAFETY
- 4 Documents / Resources
- 5 Related Posts

# Alcatel

**Alcatel F685 Voice Smart Call Block**



## BEFORE 1st USE

### Connecting your phone:

- Connect plugs in corresponding sockets in the base station. Plug the telephone line into telephone socket and insert power plug in an electrical outlet.
- Insert batteries in Handset Before you start to use your telephone, charge batteries continuously for 15 hours.

Use only plug adapter and rechargeable batteries supplied with your phone.

### Handset/ Base Station Keys











1. OK/Menu key
2. key\*  
\* To block calls, it is necessary to subscribe to the Calling Number Presentation service. Contact your landline operator. In standby mode: Direct access to the Call blocking menu 2. 3&
3. Navigation key
4. Hang-up/Exit key
5. M1, M2 keys Star key Long press 0 key Recall (flash) to access to operator services\* 1.
6. Talk key/ Loudspeaker
7. Back/Mute/Intercom key
8. Paging key To locate handset/ to start registration procedure.

Subject to subscription and availability of the service from the fixed line operator.

## Display icons

- Indicates that the Call Blocking function is activated. (See the attached Call Blocking addendum)
- Indicates battery is fully charged. Indicates battery is fully discharged.
- Indicates that an external call is connected or held. Icon blinks when receiving an incoming call.
- Indicates you have a new voice mail message
- Indicates you have new missed calls
- Displays when the alarm clock is activated,
- Displays when handsfree is activated.
- Displays when ringer volume is turned off.
- Indicates that the handset is registered and within range of the base station.
- Icon disappears when the handset is out of range or is searching for a base.













## Set language and flashtime to operate correctly on your network:

- ok menu  or  or select REGL. COMB/ ok menu  or  select LANGUAGE or select your desired language ok menu .
- ok menu  or  or select BS SETTINGS/ ok menu  or  or select FLASH TIME ok menu  or  or select SHORT/ MEDIUM or LONG ok MENU ok menu.

## Using the phone

### Receive and end a call

#### Make a call

-  either before or after dialing your number
- From redial list:  /  or  / 
- From call log list\*: ok menu CALL LIST ok menu  or    
Note: You need to subscribe to Caller Line Identification service to be able to see the caller's number or name in the call log.
- From direct memories: long press on KEY 1 or KEY 2 or KEY 3 or short press M1 or M2 keys in idle mode.
- From phonebook:  /  or  / 
- or/ -During a call, to activate/deactivate handsfree:
- To make an internal call -If only 2 registered handsets: C/NT. If more than 2 registered handsets: c/NT/ enter the handset number.

## To make a three-party conference call:

### During call

- Press ok menu select INTERCOM ok menu enter handset number.



- Press on the called handset to answer.
- Long press ..\*on the calling handset to establish conference call.







### Phonebook settings: 100 entries

#### To register in phonebook



ok menu select ADD / ok menu/ enter name of contact/ ok menu/ enter number of contact/ ok menu / select melody / ok menu.





To register the direct memories in keys M1, M2, 1, 2 & 3

ok menu  or  select HS SETTINGS ok menu  or  select DIRECT MEM ok menu   
or  select M1, M2, KEY 1, KEY 2 & KEY 3 /ok menu /edit or enter the number/ ok menu .

For Duo and Trio models, the phonebook, call log list and redial number saved in the ne are common to all handsets.

### General settings

This phone can be customized according to your preferences, to access the different -possibilities press:

- To customize handset {name, melody, language, ... )  or  select HS SETTINGS/ ok menu.
- To change PIN, registration handset, reset:  or  select BS SETTINGS/ ok menu\_

As a general rule, if a problem occurs, remove the batteries from all handsets for about 1 minute, then disconnect and reconnect the power supply to the base and reinstall the handset batteries. For more information, you can download full user guide or get on-line assistance [www.alcatel-home.com](http://www.alcatel-home.com)

## SAFETY

This telephone is not designed for Emergency calls when the main power fails. Do not use your telephone to notify a gas leak or other potential explosion hazard. t open your device or its power supply to avoid risk of electrical shock. Do not attempt too open the batteries, as they contain hazardous chemical substances telephone must be located in a dry place away from hot, humide and direct sunlight condition. To avoid radio signal interference

## ENVIRONMENT

This symbol means that your inoperative electronic appliance must be collected

A separately and not mixed with the household waste. The European Union has implemented a specific collection and recycling system for which producers are responsible.

**Help us protect the environment in which we live!**

## Documents / Resources



[Alcatel F685 Voice Smart Call Block](#) [pdf] User Guide  
F685 Voice Smart Call Block, F685, Voice Smart Call Block