



Alecto DBX-80BU Expansion Unit Instruction Manual

[Home](#) » [Alecto](#) » Alecto DBX-80BU Expansion Unit Instruction Manual 

Alecto DBX-80BU Expansion Unit



Contents

[1 Installation instructions extra baby unit DBX-B0BU](#)

[2 Documents / Resources](#)

[2.1 References](#)

[3 Related Posts](#)

Installation instructions extra baby unit DBX-B0BU

1. Insert the baby unit into the wall socket.
2. Briefly press the   button and use the ▲ or ▼ button to set the send channel.
3. Briefly press the   button and use the ▲ or ▼ button to set the sub code.
4. Briefly press the   button and use the ▲ or ▼ button to set the VOX sensitivity.
5. Briefly press the   button and use the ▲ or ▼ button to enable or disable the 'Auto Monitor' function.
6. Briefly press the   button to save your settings and to finish the setup.



For the second baby unit, set a channel other than the channel of the first baby unit as the transmission channel. In the other settings, you are free to choose your own channel. When the nightlight function of the baby unit is enabled, you CANNOT change the settings. First press the ▲ or ▼ or   button to switch off the nightlight.

DECLARATION OF CONFORMITY

Hereby, Hesdo declares that the radio equipment type Alecto DBX-B0BU is in compliance with directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:
<http://DOC.hesdo.com/DBX-80-DOC.pdf>

Hesdo BV Azielaan 12 5232 BA, 's-Hertogenbosch The Netherlands
www.alectobaby.nl



Documents / Resources

	Alecto DBX-80BU Expansion Unit [pdf] Instruction Manual DBX-80BU, DBX80BKBU, Expansion Unit
---	--

References

-  [Alecto Baby | Babyfoons & Babycare](#)