




Alecto DVM-140C Expansion Camera Instruction Manual

[Home](#) » [Alecto](#) » Alecto DVM-140C Expansion Camera Instruction Manual 

Alecto DVM-140C Expansion Camera Instruction Manual

DVM-140C



Alecto®

REGISTERING CAMERA

Contents

1 REGISTERING

CAMERA:

2 Documents / Resources

2.1 References

3 Related Posts

REGISTERING CAMERA:

1. Connect the power adaptor of the new camera (baby unit) and insert the adapter into a 230V wall outlet; turn the camera on by sliding Switch to position 1 (to below).
2. Open the menu on the parent unit, select the 'Settings' option, press the OK button and then select 'Camera'. Press the OK button.
3. Use the or navigation button to add a new camera ('Add Camera' column) and press the OK button.
4. The parent unit now starts a countdown from 30 to 0, within these 30 seconds briefly press the PAIR- button at the rear of the new baby unit. After several seconds the parent unit and the new baby unit will detect each other and the view of the new baby unit is immediately shown on the screen of the parent unit. The camera is now registered and ready for use.

"Information Power Adapter:

Manufacturers name and address : Shenzhen Guanjin Technology Co., LTD, Building 8, Qiaoxin garden, No.33, Hexin South Road, Guangming street, Guangming District, Shenzhen, China

Model Identifier : CYHA050100VWEU

Input voltage : 100-240VAC

Input AC frequency : 50/60 Hz

Output voltage : 5.0V DC

Output current : 1.5 A

Output Power : 7.5 W

Average active efficiency : 77.0 %

Efficiency at low 10% load : –

No load Power consumption : 0.076 W


DECLARATION OF CONFORMITY

Hereby, Hesdo declares that the radio equipment type Alecto DVM-140 is in compliance with directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <http://DOC.hesdo.com/DVM-140-DOC.pdf> Use of this equipment is allowed in all countries of the EU. In France, Italy, Russia and Ukraine, only indoor use is allowed.



WWW.ALECTO.NL
SERVICE@ALECTO.NL

Documents / Resources



References

- [DOC.hesdo.com/](https://www.doc.hesdo.com/)
- [Alecto.nl | alectonl](https://www.alecto.nl/)

Manuals+.