



EL-13-R Control With External Switch



ALEKO EL-13-R Control With External Switch Instructions

[Home](#) » [ALEKO](#) » ALEKO EL-13-R Control With External Switch Instructions 

Contents

- [1 ALEKO EL-13-R Control With External Switch](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Operation](#)
- [5 EL-13-R CONTROL WITH EXTERNAL SWITCH](#)
- [6 INSTALL OUTSIDE OF SAUNA](#)
- [7 Frequently Asked Questions](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



ALEKO EL-13-R Control With External Switch



Specifications

- **Model:** EL-13-R Control with External Switch
- **Special Order:** Yes
- **Maximum Wire Length:** 200-300 feet
- **Compatibility:** External start/stop switch (included)
- **Not Compatible with:** Alexa, Google Home, or similar wireless connections

Product Usage Instructions

Installation

1. Ensure that the EL-13-R control with the external switch is placed outside of the sauna.
2. Connect the control to the external start/stop switch (included) using an 18/3 wire (not included).
3. Install the external switch in a one-gang box (not included).
4. Run the wire from the switch to the control, ensuring it does not run next to line voltage wiring.

Operation

1. The external switch button will turn the sauna on and off.

2. An LED light on the control will indicate when the sauna is operating (on) or off.

Compatibility


The EL-13-R control with an external switch does not support wireless connectivity with devices such as Alexa, Google Home, or similar systems.

EL-13-R CONTROL WITH EXTERNAL SWITCH


NOTE


EL-13-R is a special order. You cannot add the external switch to standard control. The wiring shown is just for the external switch. See separate control/heater diagrams.

INSTALL OUTSIDE OF SAUNA



Connect control to external start/stop switch (included) (wire not included). Install the external switch in the one-gang box (not included). Run 18/3 from switch to control. Wire can be 200-300 hundred feet. Do NOT run low voltage wire next to line voltage. The button will switch the sauna on & off. The LED light will come on when the sauna is operating. It will go off when the sauna is off. Will not connect wirelessly via Alexa, Google Home or similar.






Frequently Asked Questions

Q: Can I use the EL-13-R control with an external switch wirelessly with Alexa or Google Home?

A: No, this product does not connect wirelessly via Alexa, Google Home, or similar devices.

Documents / Resources



[ALEKO EL-13-R Control With External Switch \[pdf\] Instructions](#)

EL-13-R Control With External Switch, EL-13-R, Control With External Switch, External Switch, Switch

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.