

Alereon AL5804 UWB USB Interface Module User Manual

[Home](#) » [Alereon](#) » Alereon AL5804 UWB USB Interface Module User Manual 

Alereon AL5804 UWB USB Interface Module User Manual

Contents

- [1 ALER03 Compliance Statement for Impact AL5804](#)
- [2 OEM INTEGRATION INSTRUCTIONS](#)
- [3 Validity of using the module certification](#)
- [4 Upgrade Firmware](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

ALER03 Compliance Statement for Impact AL5804

FCC ID: U9YAL5804

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator & your body.

OEM INTEGRATION INSTRUCTIONS

This device is intended only for OEM integrators under the following conditions:

The module must be installed in the host equipment that must be handheld, i.e., they are relatively small devices that are primarily handheld while being operated and do not employ a fixed infrastructure and the transmitter module may not be co-located with any other transmitter or antenna. The module shall be only used with the internal on board antenna that has been originally tested and certified with this module. External antennas are not supported. As long as these 3 conditions above are met, further transmitter tests will not be required.

However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed (for example, digital device emissions, PC peripheral requirements, etc.). The end product may need Verification testing, Declaration of Conformity testing, a Permissive Class II Change or new Certification. Please involve a FCC certification specialist in order to determine what will be exactly applicable for the end-product.

Validity of using the module certification

In the event that these conditions cannot be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization for this module in combination with the host equipment is no longer considered valid and the FCC ID of the module cannot be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization. In such cases, please involve a FCC certification specialist in order to determine if a Permissive Class II Change or new Certification is required.

Upgrade Firmware

The software provided for firmware upgrade will not be capable to affect any RF parameters as certified for the FCC for this module, in order to prevent compliance issues.

End product labeling: This transmitter module is authorized only for use in device where the antenna may be installed such that 0 cm may be maintained between the antenna and users. The final end product must be labeled in a visible area with the following: "Contains FCC ID: U9YAL5804".

Information that must be placed in the end user manual


The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module. The end user manual shall include all required regulatory information/warning as show in this manual.

This device is authorized under 47 CFR 15.519 (the FCC Rules and Regulations).

The operation of this device is subject to the following restriction: This UWB device shall transmit only when it is sending information to an associated receiver. This UWB device shall cease transmission within 10 seconds unless it receives an acknowledgement from the associated receiver that its transmission is being received. An acknowledgement of reception must continue to be received by the transmitting device at least every 10 seconds of operation or the UWB device must cease transmitting



Documents / Resources

	<p>Alereon AL5804 UWB USB Interface Module [pdf] User Manual AL5804, U9YAL5804, AL5804 UWB USB Interface Module, UWB USB Interface Module</p>
---	---