



Alfred DB2S Smart Home Touchscreen Deadbolt User Guide

[Home](#) » [Alfred](#) » Alfred DB2S Smart Home Touchscreen Deadbolt User Guide 



Hello I am
DB2S Smart Home Touchscreen Deadbolt
User Guide



Contents

- [1 DB2S Smart Home Touchscreen Deadbolt](#)
- [2 INSTALLATION](#)
- [3 LOCK SETUP](#)
- [4 LOCK OPERATION](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

DB2S Smart Home Touchscreen Deadbolt

Congratulation on your New Smart Home Touchscreen Deadbolt

Hello,

Thank you for joining the Alfred family. We wrote this to make sure your smart lock is as easy to set up as it is to use. Alfred owners are provided with security, peace of mind, and ease of use. Here are a few quick tips to get you started:

INSTALLATION

Installing Alfred is easy. With our partnership with mobile app BILT you are able to get step by step visual installation procedures which you can follow along on your phone. The BILT app will show you how to install your latch and how to set your handing switch correctly. Go to the Apple App Store or Google Play to download BILT and search "Alfred".



<https://sj83t.app.goo.gl/wNNE>

LOCK SETUP

STEP 1

Download the Alfred Home App on either iOS or Android devices to quickly be able to set up and program your new Alfred Smart lock and accessories. Or proceed to step 2 and 3 if you prefer to set up your new Smart Lock without your mobile device.



STEP 2

CHANGE DEFAULT MASTER PIN CODE

1. Touch the screen with your hand to activate.
2. Enter "*" twice and the 8-digit default Master PIN Code (12345678) followed by "✓".
3. Enter "1" to change Master DB2S Series PIN code.
4. Enter new 4-10 digit Master PIN code followed by "✓".
5. Repeat step 4 one more time.



The Master PIN Code must be changed before any further programming can begin.

STEP 3

ADD NEW USER PIN CODES

1. Touch the screen to wake up the lock.
2. Enter "***" then your new Master Pin Code followed by "✓".
3. Enter "2" to enter Add User Menu.
4. Enter new 4-10 Digit User Pin Code followed by "✓".
5. Repeat step 4 to confirm your PIN Code.
6. To continue adding new users Repeat step 3-5.

* to assign member name to each user pin code please open Alfred Home App.



For your security, we have created a Simple PIN Code rule. Both Master and User PIN Codes cannot have the following attributes:

1. Consecutive numbers: for example: 123456 or 654321.
2. Duplicated numbers: for example: 111111 or 222222.
3. Include or be included within other existing PIN codes.

LOCK OPERATION

HOW TO LOCK

Press and hold any key on the keypad for 2 seconds.



You can also lock your door from the inside by pressing the multi-function button,



or by turning the thumbturn to the horizontal position.

HOW TO UNLOCK

Place your palm over the lock to wake up the keypad. Input User PIN code or Master PIN code and press "✓" to confirm.



Or By using your RFID Card by tapping it on the Alfred Logo in the center of the lock



You can also unlock your door from the inside by turning the thumbturn to the vertical position.



Still have Questions about your new Alfred Smart Lock?
Please don't return it to the store! Let us help you first!
Call us toll-free at 1-833-4-ALFRED (1-833-425-3733).


Or, email us at support@alfredinc.com.

ALFREDINC.COM

You will love our short educational
videos to help guide you in almost any
situation. Check our YouTube Channel.



Documents / Resources

	<p>Alfred DB2S Smart Home Touchscreen Deadbolt [pdf] User Guide</p> <p>DB2S, DB2S Smart Home Touchscreen Deadbolt, Smart Home Touchscreen Deadbolt, Home Touchscreen Deadbolt, Touchscreen Deadbolt, Deadbolt</p>
---	---