

ALLEN HEATH XONE-96 Audio Firmware User Manual

Home » ALLEN HEATH » ALLEN HEATH XONE-96 Audio Firmware User Manual



ALLEN&HEATH®

Contents

- 1 XONE-96 Audio Firmware
- **2 PLEASE FOLLOW INSTRUCTIONS FOR INSTALLATION CAREFULLY**
- 3 Documents / Resources
 - 3.1 References
- **4 Related Posts**

XONE-96 Audio Firmware





AUDIO FIRMWARE v1.0.2 MAINTENANCE RELEASE

XONE:96 AUDIO FIRMWARE v1.0.2

This maintenance release implements reconfiguration of the DAC codec for your XONE:96 This bundle includes v1.0.2 Audio Firmware for Windows PC

PLEASE FOLLOW INSTRUCTIONS FOR INSTALLATION CAREFULLY

Xone Product XONE:96 Audio Firmware v1.0.2 PC Device Drivers v4330 [Xone96AudioFirmware1.0.2.bin]


Operating System:	Compatible	Support Active
Microsoft Windows10	~	~
Microsoft Windows8	✓	~
Microsoft Windows7	✓	~

see p.3 for software changelog

Installing XONE:96 Audio Firmware


! **IMPORTANT:** Ensure current ASIO* compatible <u>allen-heath.com/media/X96_SRN_4330_1.pdf</u> on the host PC ! Ensure you download & install the correct Device Software for your operating system;

- Go to <u>www.allen-heath.com/ahproducts/xone96</u>
- Click PC DEVICE SOFTWARE
- Download the 'current' Audio Firmware bundle: X96_AFW102_PC.zip
- Move the X96_AFW102_PC.zip to your system desktop and extract the Audio Firmware file; Xone96AudioFirmware1.0.2.bin






Connect the PC to the mixer's USB 1 port and power the Xone:96 ON



- ! **IMPORTANT:** the host must connect to the USB 1 port during installation.
- If the PC is connected to USB 2 the installer application will not find the Xone:96
- Check that the mixer is correctly connected and visible via the PC's Sound dialogue;
- Search > Sound (Control Panel) to open the dialogue







And that the Xone:96 mixer is not selected for sound playback and recording during the install.

XONE:96 AUDIO FIRMWARE v1.0.2

PLEASE FOLLOW INSTALL & UPDATE INSTRUCTIONS CAREFULLY


Xone Product XONE:96


Audio Firmware v1.0.2 PC

Device Driver v4330


[Xone96AudioFirmware1.0.2.bin] Installing XONE:96 Audio Firmware continued...


- Close all Audio and MIDI applications before running the install.
- Browse to the install directory of the Device Driver;
- the default is:
- (C):\Program Files\Allen & Heath\XONE USB Driver\XONE 96\W10_x64 Select the Xone96Dfu.exe application.
- Click Open to run the installer






- The Audio Firmware currently installed is displayed next to Current Firmware:
- If Current Firmware displays v1.0.2;
- ! you do not need to run the install.
- Click EXIT to close the application.
- Power-cycle the Xone:96 mixer (turn OFF/ ON) before further use.
- If Current Firmware displays v1.0.0;







- Click the Browse tab in the installer application and navigate to the desktop
- Select the Xone96AudioFirmware1.0.2.bin file and click Open
- Click the Start tab to install the new Audio Firmware
- Installation takes a few seconds during which various messages are displayed.
- After the installation is complete, click EXIT to close the installer application.
- Power-cycle the Xone:96 mixer (turn OFF/ ON) before further use
- The Audio Firmware update is now complete.

Software Changelog

Xone Product: XONE:96 Audio Firmware v1.0.2

Operating System: MS Windows [PC] [Xone96AudioFirmware1.0.2.bin] v1.0.2 Audio Firmware maintenance update implementing DAC codec reconfiguration





XONE96-25 FIXED: de-emphasis filter status @ 44.1kHz / 48kHz sample rates

If you experience a problem during installation, please contact A&H Product Support: http://support.allen- heath.com

> X96 WDSRN_ Issue 1 X96 AFW102 PC 11/18

* ASIO is a trademark and software of Steinberg Media Technologies GmbH

Documents / Resources



ALLEN HEATH XONE-96 Audio Firmware [pdf] User Manual XONE-96 Audio Firmware, XONE-96, Audio Firmware, Firmware

References

- & XONE:4D | Allen & Heath
- & Xone:96 | Allen & Heath
- O Log in with Atlassian account
- MH Search Manual-Hub.com

Manuals+,