



# ALLIMITY NH800UP MT26R Remote Control User Manual

[Home](#) » [allimity](#) » ALLIMITY NH800UP MT26R Remote Control User Manual 

# ALLIMITY

## USER MANUAL

### Contents

- [1 Pairing New Remote method:](#)
- [2 Connected new remote with a Paired Remote:](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

### Pairing New Remote method:

1. Press the [Power] key to turn on the [TV]



2. Press and Hold [VOL-] key and [Home] key together for 3-5 seconds, the indicator light flashes and enters the pairing state. After the pairing is successful, the indicator light will go out.

### Connected new remote with a Paired Remote:

1. Press the [Home] key, then select [Setting — Remotes & accessories]
2. Select [Add accessory], then press the [OK] key to confirm to pair.



3. Press and Hold [VOL-] key and [Home] key together for 3-5 seconds, the indicator light flashes and enters the pairing state. After the pairing is successful, the indicator light will go out.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction

Documents / Resources

<div><div>USER MANUAL</div><div><div>Putting New Remote method:</div><div>1 Press [Power] for 5s, then wait 10s. 2 Press the red [OK] key and [7]. This operation for 5s, wait 10s, the infrared light will flash for 3s, then the power is on. After the power is on, the infrared light will flash. 3 Press the [Power] key for 5s, then wait 10s. 4 Press the red [OK] key and [7]. This operation for 5s, wait 10s, the infrared light will flash for 3s, then the power is on. After the power is on, the infrared light will flash.</div></div><div><div>Connected your remote with a third device:</div><div>1 Press the [Power] key for 5s, then wait 10s. 2 Press the red [OK] key and [7]. This operation for 5s, wait 10s, the infrared light will flash for 3s, then the power is on. After the power is on, the infrared light will flash.</div></div></div>	<div><div><a href="#">ALLIMITY NH800UP MT26R Remote Control</a> [pdf] User Manual</div><div>NH800UPURMT26R, 2A4GHNH800UPURMT26R, NH800UP MT26R Remote Control, NH800UP MT26R, Remote Control</div></div>
---	--