

[Skip to content](#)

Manuals+

User Manuals Simplified.



ALORAIR Sentinel HD90 Dehumidifier Instructions

July 29, 2022 July 29, 2022 [Leave a comment on ALORAIR Sentinel HD90 Dehumidifier Instructions](#)

[Home](#) » [Alorair](#) » ALORAIR Sentinel HD90 Dehumidifier Instructions 

Contents [hide](#)

[1 ALORAIR Sentinel HD90 Dehumidifier](#)

[2 Documents / Resources](#)

[2.1 Related Manuals / Resources](#)



ALORAIR Sentinel HD90 Dehumidifier



- Model NO: Sentinel HD90Power
- Supply: 110/120VAC, 60 Hz, 5.56 Amps
- Thermally Protected Motors
- Refrigerant: R410a, 21.9 Ounces
- Maximum Design Pressure: 35 Bar High Side 15 Bar Low Side
- Capacity: 90 PPD 80°F, 60% RH
- Serial Number: S01060 Made in P.R.C.



Documents / Resources



[ALORAIR Sentinel HD90 Dehumidifier \[pdf\] Instructions](#)
 Sentinel HD90 Dehumidifier, Sentinel HD90, Dehumidifier

Related Manuals / Resources

[ALORAIR Sentinel HDi90 Dehumidifier Instructions](#)



PureAiro HEPA Max 770 Air Scrubber Instruction Manual Model#: Sentinel HDi90 Power Supply: 110/120VAC, 60 Hz, 5.5-Amps Thermally...

[ALORAIR HD55 Sentinel Dehumidifier User Manual](#)

HD55 Sentinel Dehumidifier AlorAir Solutions INC. Specifications subject to change without notice. 1 Identification green. Central Control light...

[AlorAir Sentinel HD55 Instruction Manual](#)

AlorAir Sentinel HD55

[ALORAIR Storm SLGR 850X Commercial Dehumidifier User Manual](#)

Storm SLGR 850X Commercial Dehumidifier Circuit Wheel

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

Save my name, email, and website in this browser for the next time I comment.

[Manuals+](#),

- [home](#)
- [privacy](#)