

Alpatronix B01D2AKVZ8 AX600 Bluetooth Speaker User **Manual**


Home » Alpatronix » Alpatronix B01D2AKVZ8 AX600 Bluetooth Speaker User Manual



Contents

- 1 B01D2AKVZ8 AX600 Bluetooth
- **Speaker**
- 2 Layout and Functions
- 3 Step-I:
- **4 Functions**
- **5 TWS Function**
- **6 Power Bank Function**
- 7 Caring for your AX600
- 8 Troubleshooting
- 9 Technical Specification
- 10 Documents / Resources
- 11 Related Posts

B01D2AKVZ8 AX600 Bluetooth Speaker



User Manual

100% Satisfaction Guaranteed

Alpatronix is the trademark of SaritekTechnical Solutions Inc.
All other brands are registered trademarks of their respective owners.


To activate the 1-year warranty on your Bluetooth Speaker, visit http://www.alpatronix.com/ and click on the warranty link to register your product by filling out a quick and easy form.

The Alpatronix warranty will fully cover your purchase against all defects in material and/or workmanship for an entire year. Most return policies only allow returns for a period of 14 – 30 days from the date of purchase, so hurry and register your product to give yourself peace of mind knowing Al patron ix has got you covered for a whole year.

CAUTION

- * Never plug in a wet device to an electric outlet for charging.
- * Never use this device to charge another device when wet.

Layout and Functions



Step-I:

Register Your Product

Register your product and benefit from the 1-year warranty. It's quick and easy.

Most return policies only allow for a defective product to be returned within 14 - 30 days after the date of purchase ... and most issues that happen due to defects in material and workmanship have a knack of happening after this return period has ended.

We have seen the sad-puppy look on customers' faces for too long and understand how upsetting it is to spend your hard-earned dollars on something that stops working after a few weeks! That's why Alpatronix's Ironclad Warranty will protect you for a whole year against all defects in material and/or workmanship. So register your product by visiting www.alpatronix.com, and click on the •warranty• on the top menu to register your product and activate your warranty. Rest easy that you are covered no matter what the return policy is where you purchased your product!

If you have a defective product and need us to take care of you, email us at **support@alpatronix.com** and rest assured that our support team will make this a guick and easy process with as little pain as possible.

Notice:


Alpatronix warranty is only valid when you purchase from authorized sellers, and only within the country In which you purchased the product. If you are not sure whether the retailer you are purchasing from is an authorized retailer, please contact us and we will be happy to further assist you. Alpatronix sells directly on Amazon.com, and on the Alpatronix.com website. Alpatronix warranty does not cover user damage. Tampering with your device or user damage also voids the manufacturer warranty.

Functions

	Powering ON/OFF	
Operation	Instructions	LED Indicator
Power ON Power OFF	Press and hold (1) for 2-3 seconds Press and hold (1) for 2-3 seconds	Blue - Flashing OFF
	Pairing	
Operation	Instructions	LED Indicator
Pairing	Automatically enters pairing mode	Blue - Flash every 2 seconds
Paired	Select "Alpatronix AX600" on your phone's list of available bluetooth devices	Indoor: Blue Solid
Un-Pair (disconnect)	Press + and - buttons together	Blue - Flash every 2 seconds
	Modes	
Operation	Instructions	LED Indicator
Equalizer (sound effects)	Press (click) the 👭 button	Indoor: Pulsing Outdoor: Slow flash
Switch modes	Press (click) the U button	
- AUX mode - TF mode - USB Flash	Insert AUX jack (automatic) Insert TF card (automatic) Insert USB flash card (automatic)	Indoor: Green Solid Outdoor: Green - Flashing
-TWS functions	Double-click power button on one speaker	Blue/Green Flashin
See Page 4 for full instructions.	Pairing successful Disconnect TWS	Master: Blue Flash Slave: Blue Solid Press + and - to disconnect. Press again to disconnect phone

	Music Functions	
Operation	Instructions	LED Indicator
Volume up	Press (click) the + button	N/A
Volume down	Press (click) the - button	N/A
Next song	Hold the + button	N/A
Previous song	Hold the - button	N/A
Play/Pause	Press (click) the > button	N/A
	Call Functions	
Operation	Instructions	LED Indicator
Answer	Press (click) the ▷ button. (when receiving call)	N/A
Reject	Hold the ▷ button. (when receiving call	N/A
Hang up	Press (click) the > button. (during the call)	N/A
Call back	Hold the ⊳ button. (when not in call)	Blue - Solid
	Other Functions and Alerts	
Operation	Instructions	LED Indicator
Low battery alarm	Battery lower than 20%	White LED Flashing
Low battery shut down	Battery lower than 10%	LEDs OFF
Charging	Insert USB-C to USB charger (only cable is included)	White LEDs Flashing
Charging completed	N/A	All 3 White LEDs ON
RESET	Insert a toothpick in RESET port	N/A

- 1. Turn on both AX600 speakers. You will notice both devices will have the BLUE LED flashing rapidly.
- 2. Select one of the AX600 units as the MASTER and double click the power button. You will notice the MASTER AX600 will have the BLUE & GREEN LEDs flashing alternately. The MASTER AX600 will detect and pair with the other speaker (SLAVE AX600). Once paired, the MASTER AX600 will have the BLUE LED flash slowly, ready to pair with a phone. The SLAVE AX600 will have a solid blue LED.
- 3. On your phone, go to Settings -> General -> Bluetooth, and then find the MASTER AX600 on the list of available Bluetooth devices. Once paired, you will be able to play music in stereo using b1Dth devices.
- 4. To disconnect TWS, on the MASTER speaker press the+ and buttons together. To ALSO disconnect from the phone, press the + and -buttons together again.



Note: Pairing with computers and laptops

The AX600 will pair easily with any Apple device including Mac computers and laptops, as well as most any Anderoid devices. For pairing with PC computers, please refer to your device's user manual, or download a compatible Bluetooth driver. Bluetooth driver compatibility varies depending on the type of PC computer or laptop you own, so Alpatronix Customer Service staff would not be able to help identify an appropriate driver. When searching for an appropriate driver, look for one that supports HSP, HFP, A2DP and AVRCP standard profiles.

Power Bank Function

You can use the AX600 to charge your digital devices. Packed with a built-in powerbank, this waterproof beauty can be the answer to all your power needs when you are out and about. Simply connect your USB-powered device to the USB charging output of the AX600 and see it charge right back up while you listen to all your favorite tunes and dance the night away!

Note: Never leave a charging device unattended. Always monitor your devices while charging, and disconnect if any signs of heat, fire, or other abnormal behavior appear.

Caring for your AX600

To extend the life of your AX600, please note the following

- Avoid submerging in water. The AX600 is water resistant agaiinst strong jets of water from any direction. Avoid
 exposing the ports to water. Make sure the port cover is secure and completely cov1ering all ports before any
 exposure to water. Dry the unit completely before plugging into power for charging.
- Avoid exposure to extreme temperatures (hot or cold), or exposure to fire or any other heat source, as well as strong magnetic fields.
- Clean the product using a dry and soft cloth. Do not use detergents or chemicals.
- If you intend to store the product longer than 3 months, ple,ase ensure the battery has at least a 50% charge. Always fully charge the battery again after long-term storage (at least once every 6 months) and before use.
- Please only use the charging cable provided with the produict. If you need additional charging cables, please contact Alpatronix for further assistance.

- Do not attempt to fix the product, or to open or disassemble it. It will void the manufacturer's warranty and expose you to risk of severe injury or electric shock. In case of any malfunction, please contact Alpatronix Customer Service for further assistance.
- · Avoid dropping or knocking on hard surfaces.
- Do not use at high volume for extended periods, as this may cause hearing damage.

Troubleshooting

If you are unable to connect the speaker to your device, follow the steps below

- Check if the battery is low. When the battery is low, the speaker may have trouble connecting. Charge the battery fully and try aga1in.
- Check the power switch and make sure it is on.
- Restart the speaker. Turn the power OFF and then turn it back ON again.
- Make sure the Bluetooth on your device is enabled.
- Try removing the pairing by going to the Bluetooth section of your device, choose AX600, and select "ForgetThis Device" (for Android devices: select"Unpair"). Turn Bluetooth off for 3 seconds on your device, and turn it back on. Repeat Step III to attempt to pair again.
- Reset the speaker by inserting a toothpick into the RESET port. This will reset the speaker to original factory settings.

Technical Specification

• Frequency Response: 80Hz - 20KHz

• Bluetooth Profile: VS.0, TWS, NFC, DSP, A2DP, AVRCP

• Transmission Distance: < 33ft (1 Om)

• Waterproof Level: IPX6 (Not Submergible)

• Playback Time: 18-24 hours (50% volume)

11 - 15 hours (70% volume)

6 – 9 hours (MAX volume)

• S/N Ratio: 2 80db ± 3dB

• THD: s 10%

• TF/Flash Card Compatibility: MP3, WAV, WMA, FLAC

• **Dimensions:** 14 x 5 x 7.7 in

35.5 x 12.7 x 19.5 cm
• Weight: 6.4 lbs (2.9 kg)

Al patron ix Gives Back:

Al patron ix donates \$ 1 to charity for every review you leave for our products. We don't care if it's positive or negative, we just think every business needs to do some good in the world. Help us make the world a better place

AND help us and your fellow customers

by giving us your valuable feedback.
Thank you for being a contributing
citizen of this world.





Please remember that your product comes with a 1-year warranty. If there is any problem with your product, please do not hesitate to contact us.

> PO Box 68030, Anaheim, CA 92806 United States of America (888) 407 - 7515

> > support@alpatronix.com

www.alpatronix.com

Documents / Resources



Alpatronix B01D2AKVZ8 AX600 Bluetooth Speaker [pdf] User Manual BT261-2, BT2612, Q8W-BT261-2, Q8WBT2612, B01D2AKVZ8 AX600 Bluetooth Speaker, AX6 00 Bluetooth Speaker

Manuals+,