



## Alpine Style Solution for Audi A4, A5, Q5 Owner's Manual

[Home](#) » [Alpine](#) » Alpine Style Solution for Audi A4, A5, Q5 Owner's Manual 



### Contents


- [1 Alpine Style Solution for Audi A4, A5, Q5](#)
- [2 Getting Started](#)
  - [2.1 Location of Controls](#)
- [3 Connections](#)
- [4 Steering Wheel Remote Control](#)
- [5 Car Settings](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

**Alpine Style Solution for Audi A4, A5, Q5**



## Getting Started

### Location of Controls



**(AUDIO)/(Favorite) button:** Displays the Audio/Visual screen. If the Audio/Visual screen is already displayed, changes the source. Press and hold for at least 2 seconds to recall the Favourite screen.

**VOICE button:** Depending on the connected smartphone, press to recall Siri function or voice recognition mode.

**Button:** Press to seek up/down a station in radio mode or up/ down a track, chapter, etc., in other audio/visual sources.

**MENU/ (Power Off) button:** Recalls the Menu screen. Press and hold this button for at least 5 seconds to turn the power off.

**(NAV) Button:** Recalls the navigation map screen. Press again to switch to Navigation menu screen. Press and hold this button for at least 2 seconds to change to Go Home route screen. (If Home is not set yet, it will change to the Home setting screen.)

For details of navigation operations, refer to “Navigation System OM” in the CD-ROM.


**RESET switch:** The system of this unit is reset.


**(Eject) button (only with DVE-5300X):** Ejects a disc.

**Rotary encoder/MUTE button:** Adjust the volume by turning to the left or right. Press to activate /deactivate MUTE mode.





**Disc Slot (only with DVE-5300X)**

## Connections






## Steering Wheel Remote Control



Button		Radio (DAB/ FM /MW/LW)	iPod/ USB Play-back/ BT Audio	AUX/ HDMI/ CD/ DVD	Incoming Call	Active Call
a		Down	Up	–	–	–
b	Short	Phone	Phone	Phone	Pick Up	–
	Long	–	–	–	Reject	Hang Up
c		Up	Down	–	–	–
d		Source	Source	Source	Source	Source
e		Siri/ Voice Dial	Siri/ Voice Dial	Siri/ Voice Dial	Siri/ Voice Dial	Siri/ Voice Dial
f		Vol +	Vol +	Vol +	Vol +	Vol +
g		Mute	Mute	Mute	Mute	Mute
h		Vol –	Vol –	Vol –	Vol –	Vol –
i		Navigation	Navigation	Navigation	Navigation	Navigation

## Car Settings





Designed by Alpine Electronics (Europe) GmbH  
Printed in Germany

**ALPINE ELECTRONICS MARKETING, INC.**

1-7, Yukigaya-Otsukamachi, Ota-ku,  
Tokyo 145-0067, JAPAN  
Phone: 03-5499-4531


**ALPINE ELECTRONICS OF AMERICA, INC.**

19145 Gramercy Place  
Torrance, California 90501 U.S.A.  
Phone: 1(310)326-8000

**ALPINE ELECTRONICS OF AUSTRALIA PTY. LTD.**

161-165 Princes Highway, Hallam  
Victoria 3803, Australia  
Phone: 61 (3)8787-1200

**Documents / Resources**

	<p><a href="#">ALPINE Alpine Style Solution for Audi A4, A5, Q5</a> [pdf] Owner's Manual</p> <p>Alpine Style Solution for Audi A4 A5 Q5, X703D-A</p>
--	--