

# **ALTECH IMW1200 HydraJolt Everythingproof Wireless Speaker User Guide**

Home » ALTECH » ALTECH IMW1200 HydraJolt Everythingproof Wireless Speaker User Guide 1







PLEASE 1M DO NOT RETURN TO STORE If Verne Having Trouble. We're Here to Help!



Call us 2417 at 1.855-2924087

E-mail us at supportttalteclansing.com or visit us at Altec Lansing.com

## **REGISTER YOUR PRODUCT**

To receive news, exclusive deals, OTA or firmware updates, warranty information, and more please register your product at <u>alteclansingsupport.com</u>





## **12 Month Limited Warranty**

All Altec Lansing products come with a 12-month limited warranty from the date of its original purchase **24 Hour Customer Support** 

We love our customers, and we care about your experience with Altec Lansing. If you need assistance, please call us at 1.855.292.4087 or e-mail <a href="mailto:supporttzalteclansing.com">supporttzalteclansing.com</a>

www.alteclansing.com



## **Contents**

- 1 In the Box
- 2 Charging
- 3 Powering On/Bluetooth


**Pairing** 

- 4 Documents / Resources
- **5 Related Posts**


# In the Box


IMW1200 HydraJolt Everythingproof Wireless Speaker TM	
USB-C Charging Cable	
Carabiner	





# Charging










Turn on the first speaker and connect It with a Bluetooth-compatible device. urn on the second speaker and press the button on that speaker.



Press and hold the button for 2-3 seconds on the first speaker. The first speaker will now connect to the second so they both play in sync. The Link Buttons will illuminate green. To end TWS press & hold the power button on the speaker. There are two modes:

Mode 1: Dual Stereo, both play stereo for parties, etc. Mode 2: Wide Stereo, one plays left and the other right. Briefly presses the button to switch between the modes.


### **Voice Assistant / Reset**



To activate Voice Assistant (Siri or Google Assistant)




Disconnect Bluetooth: Press and hold for five seconds and the speaker will beep Reset All connections: Press and hold for ten seconds and the speaker will power off



Overall battery performance varies depending upon use setting and environmental conditions. For further information, please visit <a href="https://www.alteclansing.com">www.alteclansing.com</a>

## **Light Change Mode**



To toggle between the different light modes:

- 1. Multicolor slow transition
- 2. Single color pulse to music
- 3. Multicolor pulse to music
- 4. Single color slow fade
- 5. Single color
- 6. Multicolor cycle changed

- 7. Multicolor fast changed with background-color
- 8. Multicolor slow fade
- 9. Four-color slow fade
- 10. Four-color rotation with a pulse to music
- 11. Four-color rotation
- 12. Off

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

#### Sakar International Inc.

195 Carter Drive Edison, New Jersey 08817, USA 855-292-4087 www.alteclansing.com

#### **Documents / Resources**



ALTECH IMW1200 HydraJolt Everythingproof Wireless Speaker [pdf] User Guide 00011HJ, SP9-00011HJ, SP900011HJ, IMW1200 HydraJolt Everythingproof Wireless Speaker, HydraJolt Everythingproof Wireless Speaker

Manuals+, home privacy