

ALTOS BrainSphere P130_F7 ME Firmware and System BIOS Update SOP for Windows 10 and 11 User Guide

Home » Altos » ALTOS BrainSphere P130_F7 ME Firmware and System BIOS Update SOP for Windows 10 and 11 User Guide 🖫




Contents


- 1 Upgrade System BIOS in Windows
- 2 Documents / Resources
- **3 Related Posts**

Upgrade System BIOS in Windows Mode


- 1. Please download the Altos BIOS zip file "Altos P130_F7 System BIOS for Windows Update (Version R01-A4).zip" from Altos website.
- 2. Copy and decompress the above zip file into your external USB storage device.
- 3. To run the Command Prompt program as Administrator role in Windows 10 or Windows 11, right-click the icon in your Start menu and select Run as administrator role. (See below picture)



- 4. Please change working directory to "Altos P130_F7 System BIOS for Windows Update (Version R01-A4)\UCP\" on your external USB storage drive.
- 5. Execute the BIOS flash tool 'R01-A4.exe' to start the system BIOS update.




6. Press<Y>, system will be going to shutdown



7. System will auto reboot and flash BIOS.

Important Reminder

Please do not unplug the AC power cord or power off the workstation system during BIOS update process, otherwise, it will cause the system failure and this is not covered by Altos limited warranty.





Documents / Resources



ALTOS BrainSphere P130_F7 ME Firmware and System BIOS Update SOP for Windows 1 0 and 11 [pdf] User Guide

BrainSphere P130_F7 ME Firmware and System BIOS Update SOP for Windows 10 and11, Br ainSphere P130_F7 ME, Firmware and System BIOS Update SOP for Windows 10 and11

Manuals+, home

privacy