

Altronix RBOC7 Open Collector Multiple Relay Module Installation Guide

[Home](#) » [Altronix](#) » Altronix RBOC7 Open Collector Multiple Relay Module Installation Guide 

Contents

- [1 Altronix RBOC7 Open Collector Multiple Relay Module](#)
- [2 Installation Instructions](#)
- [3 Specifications](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

Altronix

Altronix RBOC7 Open Collector Multiple Relay Module

Specifications

Input Voltage:

- 12VDC or 24VDC operation.
- Seven (7) independent (3VDC to 24VDC @ 2mA minimum) positive inputs.


Outputs:

- Seven (7) open collector outputs capable of sinking 100mA each.
- Board Dimensions: (L x W x H approx.): 6.5" x 3.25" x 1" (165.1mm x 82.6mm x 25.4mm).

Warranty

Altronix is not responsible for any typographical errors. 140 58th Street, Brooklyn, New York 11220 USA | phone: 718-567-8181 | fax: 718-567-9056 website: www.altronix.com | e-mail: info@altronix.com | Lifetime Warranty

Documents / Resources

	Altronix RBOC7 Open Collector Multiple Relay Module [pdf] Installation Guide RBOC7, Open Collector Multiple Relay Module, Collector Multiple Relay Module, Multiple Relay Module, Relay Module, RBOC7, Module
--	--

References

-  [Altronix Home](#)