

***Alutel***  
**AM181PRO-C6**  
**Android**  
**Handheld**  
**Terminal**



## Alutel AM181PRO-C6 Android Handheld Terminal User Manual

[Home](#) » [Alutel](#) » Alutel AM181PRO-C6 Android Handheld Terminal User Manual 

### Contents

- [1 Alutel AM181PRO-C6 Android Handheld Terminal](#)
- [2 FAQs](#)
- [3 Accessory List](#)
- [4 illustration of Equipment](#)
- [5 Basic Operation](#)
- [6 Use and Maintenance](#)
- [7 Product Parameter](#)
- [8 Battery Usage](#)
- [9 Battery Installation and Device Directly Charging](#)
- [Instructions](#)
- [10 FCC](#)
- [11 Documents / Resources](#)
  - [11.1 References](#)
- [12 Related Posts](#)

***Alutel***

**Alutel AM181PRO-C6 Android Handheld Terminal**



## FAQs

**Q: How can I know if my device is fully charged?**

A: The device will display a full battery icon or indicate a full charge notification.

**Q: Can I charge the spare battery separately without using the device?**

A: Yes, you can charge the spare battery individually by placing it in the battery card slot of the charging base.

**Q: What should I do if my device fails to power on?**

A: Ensure the battery is properly inserted and charged. If issues persist, contact customer support for assistance.


**Q: Is the device compatible with wireless charging?**

A: No, this device does not support wireless charging. Please use the provided power adapter for charging.

## Accessory List

Item	Quantity	Unit
Type-c cable	1	pc
Power Adapter	1	pc
Battery	1	pc

## illustration of Equipment



1. F1
2. F2
3. Volume
4. Reserved Button
5. USB port
6. Blue Led Indicator
7. Red LED indicator
8. F3
9. F4
10. Power Button
11. Reserved Button
12. Reserved Pogo Pin

13. Front Camera
14. Receiver
15. Rear Camera
16. Label
17. Flashlight
18. RFID Reading Area
19. Battery Cover Locker
20. Battery Cover
21. Wrist Strap Locker
22. Barcode Scan Window
23. Cradle Pogo Pin Connector

### Power on/off Instructions

Power on: Press and hold the power button in the off state until the device sends out vibration feedback. Shut down: Press and hold the power button until the shutdown prompt appears in the power-on state, and click Shut down to confirm. Note: If you do not use the device for a long time, please shut down the device.

### Basic Operation

Button	Description
Power button	Turn on or turn off or sleeping mode
Menu button	Pop-up options menu
Home button	Back to the main interface
Back button	Return to the previous interface
Volume button	Adjust the volume
Reserved button	customize functions when developing software

### Use and Maintenance

1. It is not suitable to use the device or charge the device in an environment where the temperature is too high or too low.
2. Only use the standard charger or charging dock to charge the battery;
3. If you do not use the device temporarily, please store the battery and the device separately. Please do not put the battery into the device and store it together, it is better to store them in a cool, dry, and ventilated environment.
4. For batteries that are not used temporarily, discharge them once every 3 months, and recharge them to 60% or 70% of the power for storage.

## Product Parameter

- Product size: 170\*81\*28±2mm
- Screen: 5.5-inch bright screen
- System: Android 10.0 OS
- Resolution: 720\*1440
- Battery capacity: 5200mAh
- USB type: Type-c data interface
- Working hours: 14 hours
- Communication: 4G, 3G, 2G free switching
- Network: WIFI
- Positioning: GPS/Beidou

## Optional Functions



RFID



NFC



QR Code



PSAM



Camera

## Battery Usage

1. It is forbidden to disassemble the battery cells under any circumstances.
2. It is forbidden to immerse the battery in liquid to prevent moisture.
3. It is forbidden to charge, use, or place the battery near heat sources, such as fire, heater, etc., or under high temperatures (such as strong sunlight or very hot cars), otherwise, it will cause overheating and fire or shorten the life. It is forbidden to sell the battery directly.
4. It is forbidden to heat or throw the battery into a fire or put the battery in a microwave oven or high-pressure container.
5. If the battery leaks or smells (electrolyte), please discard the battery immediately. If the electrolyte leaks and touches the skin, eyes, or other parts of the body, immediately rinse the electrolyte with clean water and seek medical attention.
6. It is forbidden to hit or pierce the battery with sharp parts, such as nails and other sharp objects.
7. It is forbidden to transport or store the battery and metal objects, such as necklaces, hairpins, etc.
8. It is forbidden to hit, step on, or throw the battery with a hammer.
9. The battery is a consumable product, and its capacity will gradually decrease as the use cycle increases. It is recommended that the battery be replaced in time when there is a problem.

## Battery Installation and Device Directly Charging Instructions

### Battery installation:

When installing the battery, please pay attention to the battery installation direction. Put the front of the battery into


the battery slot of the device first, and then push the bottom of the battery to enter the device. Do not use brute force to squeeze the battery and the device. The installed battery compartment is flat and firm.

### **Instructions for using direct charging:**

Insert the TYPE-C data cable into the data port at the bottom of the machine to charge the device. The charging indicator on the device is red when it is charging, and the red light is off when it is fully charged.

### **Instructions for Charging Cradle**

The charging base can charge the device and the spare battery at the same time. When charging the device, insert the device into the host card slot of the charging base directly and hear a slight click sound. When charging the battery separately, lay the battery flat and insert it into the battery card slot of the charging base. Then use the power adapter to power the charging station.



### **Optional Function Instructions**

1. Refer to the built-in demo of the device. If the customer needs secondary development, please contact the technical support engineer; the QR code can scan the barcode of the mainstream symbology, but please pay attention to the clarity of the barcode.
2. High frequency (13.56MHz) Refer to the built-in demo of the device, if you need secondary development, please contact the technical support engineer
3. UHF (860-960MHz) Refer to the built-in demo of the device. If customers need secondary development, please contact technical support engineers.

### **Common Failure Analysis**

If any problems happen during the use of the equipment, please refer to the following instructions to solve them. If the problem persists, please contact the dealer or manufacturer.

1. Can't charge
  - a, the equipment charger is not working well
  - b. The ambient temperature is not suitable
  - c. Poor contact
2. The device cannot be turned on
  - a. Please confirm whether the battery has electricity and whether the battery contacts are in good contact.
3. Unable to scan barcode
  - a. The scanning head cannot emit light and the hardware is damaged;

- b. Confirm whether the barcode is a national standard code;
  - c. Confirm whether the barcode is damaged;
4. high frequency cannot read and write cards
- a. Please first confirm whether the card type is correct, and then confirm whether the card reading position is correct. Otherwise, please contact technical support to confirm whether the hardware is damaged.
5. UHF cannot read and write cards
- a. Please confirm whether the card type is correct, and then confirm whether
  - b. the card reading position is correct. Otherwise, please contact technical support to confirm whether the hardware is damaged.
6. some functions cannot be selected
- a. If this service is not activated or the local network provider does not support the service, please contact the designated repairer, dealer or network operator

## **CE Warning**

1. Risk of explosion if the battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
2. The product shall only be connected to a USB interface of version USB 2.0 or higher.
3. The adapter shall be installed near the equipment and shall be easily accessible.
4. The operating temperature of the device can't exceed 40°C and shouldn't be lower than -20°C.
5. The plug is considered as a disconnect device of the adapter.
6. The device complies with RF specifications when the device is used at 5mm from the body and 0mm from the head.
7. The band 5150-5350MHz indoor use only. Hereby, Shenzhen Handheld-Wireless Co., Ltd. declares that this product is in compliance with essential requirements and other relevant provisions of Directive 2014/53/EU. This product is allowed to be used in all EU member states

## **FCC**

### **FCC Warning**


### **Labeling requirements**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Information to the user. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. - Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. -Consult the

dealer or an experienced radio/TV technician for help. Absorption Rate (SAR) information: This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement The SAR limit of the USA (FCC) is 1.6 W/kg averaging over one gram of tissue. This device was tested for typical body-worn operations with the back of the device kept 10mm from the body and 0mm from the head. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an appropriate separation distance between the user's body and the back of the device. The use of belt clips, holsters, and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements and should be avoided. Use only the supplied or approved antenna.

Documents / Resources

	<a href="#">Alutel AM181PRO-C6 Android Handheld Terminal</a> [pdf] User Manual 2A3JZ-AM181PRO-C6, 2A3JZAM181PROC6
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.