



# Alxum AX-D100B Multi-port Switch Game Card Reader User Manual

[Home](#) » [Alxum](#) » Alxum AX-D100B Multi-port Switch Game Card Reader User Manual 



SKU AX-D100B  
Multi-port Switch Game Card Reader  
with Wireless Remote Control




USER MANUAL

## Contents

- 1 Product Schematic Diagram
- 2 Installation
- 3 Package Content
- 4 Documents / Resources
  - 4.1 References

## Product Schematic Diagram



### LED Light Indicator

- A: 1 Game Card Slot: Red
- B: 2 Game Card Slot: Orange
- C 3 Game Card Slot: Pink
- D: 4 Game Card Slot: Yellow
- E: Wireless Remote Control

## Installation

- Step 1: Snap the Switch Game Card Switcher into the Switch Dock.
- Step 2: Connect the USB C cable to the Switch Dock.
- Step 3: Insert the connecting plug into the game card slot on Switch Console.
- Step 4: Insert the game cards you need into the card slots accordingly.

## Tips

- 1. When multiple game cards are inserted into the switch game card reader, all games will show on the display or TV screen but it can read ONLY one game at one time.

2. When playing the game, please do NOT insert a new game card. Or else it will exit the current game and switch to the new game card automatically.
3. You can switch the different game by using the “switch” button or the attached wireless remote control, Press 1 time the game will be next.
4. Kindly be noted, the wireless remote control is including a CR2032 li-ion battery, Alxum CANNOT replace it, please buy to replace from the online or offline store.

### Note

If the wireless remote control cannot work for the game card reader, Please follow these Steps

1. Long press the switch button of the game card switcher;
2. At the same time, plug the USB-C Power Cable, press and hold the switching button for 4s, at this time the LED lights up yellow.
3. Press and hold the switch button of the remote control for about 2s for pairing, when the LED of the card reader lights up green, it means the pairing is successful.

### Why does the Switch wake up in sleepmode?

The issue occurs exclusively in Switch Docks that use a USB HUB expansion chipset. The solution is to use an additional USB charger instead of plugging the USB cable into the Switch dock's USB port.

### Package Content

1 x Alxum Switch Game Card Reader  
1 x USB A to C Power Cable  
1 x Wireless Remote Control

### Customer Service



Life Time Technical Support



2-Year Warranty



24H-Customer Service Support




[support@alxum.com](mailto:support@alxum.com)



---

### Documents / Resources



## References

**Manuals+, Privacy Policy**