



Home » Support » Amacool D07 Battery Operated Stroller Fan User Manual

Contents [hide]

- 1 Amacool D07 Battery Operated Stroller Fan
- 2 Introduction
- 3 Structure Diagram
- 4 How to use
- 5 Charging
- 6 Technical Parameters
- 7 Warning Tips
- 8 Maintenance
- 9 Troubleshooting
- 10 PROS & CONS
- 11 WARRANTY
- 12 FREQUENTLY ASKED QUESTIONS
- 13 VIDEO PRODUCT OVERVIEW
- 14 References




Amacool D07 Battery Operated Stroller Fan



Introduction


A carefully designed cooling companion for parents and their young children is the Amacool D07 Battery Operated Stroller Fan. This small table fan, which was introduced by AMACOOL, a reputable brand in portable electronics, has a flexible tripod design that attaches to strollers, cribs, car seats, wheelchairs, and treadmills with ease. At only \$21.32, it provides strong airflow at three different speeds while operating at a whisperquiet 30 dB, guaranteeing uninterrupted comfort. Its 2600mAh rechargeable battery lasts 2.5 to 10 hours, which makes it ideal for long rides or day visits to zoos and parks. It stands out for safety and adaptability due to its 360-degree adjustable head, baby-safe fan cover, and built-in LED light. The Amacool D07, which has dimensions of 2.5"D x 5.4"W x 11"H and is lightweight and sturdy, offers contemporary options for cooling while on the go by fusing portability and performance. It is a year-round necessity for families and works well in both indoor and outdoor environments.







Structure Diagram



Warning:

- 1. Don't insert objects or fingers into the product to avoid injury or internal short circuit or leakage.
- 2. The battery is forbidden to be discarded at random. It is necessary to collect used batteries to the designated battery recycling location.

How to use

• Short press "°FAN" on-off key and the fan switches among gear 1, 2, 3 and shutdown;

long press the on-off key to shut down; (the blue light is always on when the fan is on)

- Short press "oLED" on-off key and the light switches among gear 1, 2, 3 and shutdown; long press the on-off key to shut down;
- This product supports operation with USB (no battery).

Charging

- 1. Charging time: 2-3 hours (tested with 5V-2A charger)
- 2. When connected with DC-5V power, the system will automatically turn on the charging function. The red light flashes during charging and stays on after full charge. (Please use the 5V-2A charger. If the charger less than 5V-2A is used, the charging time will be slightly longer);

Technical Parameters

1. **Power:** 10W (Max)

2. Working power: 5W

3. Input voltage: DC-5V

4. Input current: 2A

5. **Product dimension:** 67*137*330mm

6. Executive Standard ASTM F963/CPSIA(US)

Warning Tips

- 1. Do not place the product in a heat source or high temperature environment
- 2. Do not place the product in a damp place
- 3. It is strictly forbidden to put the product into or near the fire source to avoid fire
- 4. Do not disassemble, open, cut or puncture the product
- 5. Stop using the product immediately in case of abnormality during use
- 6. When the product is not used for long time, recharge the batteries every 2-3 months to ensure normal working of the batteries. Long-term shelving can cause the battery to wear out and not to recharged.

Maintenance

Fault

- 1. Power indicator not on
- 2. Can't turn on
- 3. Can't be charged
- 4. Charging process lasts too long

Cause

- 1. Battery runs out or USB connection failure
- 2. batteries run out
- 3. Charger mismatches Charger mismatches
- 4. The output current of charger is less than 2A

Solution

- 1. Recharge or check the connection
- 2. Recharge
- 3. Replace the charger Replace the USB cable
- 4. Replace the charger

Troubleshooting

Issue	Possible Cause	Solution	
Fan not turning on	Battery depleted	Recharge the fan fully using US B cable	
Fan turns off rando mly	Low battery power	Charge the battery and avoid ov eruse	
Low airflow on high speed	Dust in fan blades	Clean blades carefully with a sof t cloth	
Tripod legs feel loo	Overbending or wear	Adjust gently or avoid excessive force	

Issue	Possible Cause	Solution	
LED light not worki	Power button not held long e nough	Hold the button for 2–3 seconds to activate	
Fan making unusua	Loose debris inside	Inspect and clean the fan housin	
Charging takes too long	Low power USB source	Use a higher-output USB charge r (5V/2A)	
Fan won't rotate	Joints may be stiff	Gently rotate by hand to loosen movement	
Battery drains quic	High-speed use continuousl	Use medium speed to extend ru ntime	
Buttons unresponsi ve	Possible moisture or dust int erference	Clean button area and let dry be fore use	

PROS & CONS

PROS:

- Flexible tripod legs fit most strollers and cribs.
- Whisper-quiet operation at only 30 dB.
- LED light with three brightness settings.
- Long-lasting rechargeable battery (up to 10 hours).
- 360-degree head rotation for versatile airflow.

CONS:

- Battery is not replaceable.
- Plastic build may feel less premium.
- Only three speed settings.
- May take time to fully recharge.
- LED light might be unnecessary for some users.

WARRANTY

AMACOOL offers a **12-month replacement warranty** for the D07 Battery Operated Stroller Fan. This warranty covers any manufacturing defects or operational malfunctions under normal usage. Customers can expect prompt support and reliable service during the coverage period, ensuring peace of mind throughout the summer and beyond.

FREQUENTLY ASKED QUESTIONS

How many speed settings does the AMACOOL D07 Battery Operated Stroller Fan have?

The AMACOOL D07 features 3 adjustable speed levels, allowing you to select low, medium, or high airflow depending on your cooling needs.

Is the tripod of the AMACOOL D07 flexible enough to mount on different surfaces?

Absolutely. The flexible tripod legs are designed to wrap around stroller handles, cribs, car seats, bikes, or even treadmill bars.

How long does the AMACOOL D07 Battery Operated Fan run on a full charge?

Depending on the speed setting used, the built-in 2600mAh battery provides 2.5 to 10 hours of runtime.

How do I charge the AMACOOL D07 stroller fan?

Simply connect the fan to a USB power source using the included cable. It works with laptops, power banks, wall adapters, and car chargers.

My AMACOOL D07 fan works only for a short time after charging. What should I do?

This may indicate an incomplete charge or aging battery. Fully charge the unit and avoid draining it completely before recharging.

How can I fix the AMACOOL D07 fan if one of the tripod legs is loose or wont hold

position?

Make sure the leg joints are properly twisted into place. If the leg is worn out,

contact AMACOOL support to use the 12-month replacement warranty.

The AMACOOL D07 LED light isnt working. Is this normal?

Ensure the fan is charged, then cycle through the LED settings using the button. If the light still doesn't respond, a soft reset by turning the fan off/on may help.

VIDEO – PRODUCT OVERVIEW

https://manuals.plus/wp-content/uploads/2025/06/Amacool-D07-

Battery-Operated-Stroller-Fan-User-Manual.mp4

DOWNLOAD PDF: Amacool D07 Battery Operated Stroller Fan User Manual

References

User Manual

AMACOOL, Amacool D07, B085L71L9R, Battery Operated Stroller Fan, D07, user

AMACOOL manual

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name		
Email		
<u> </u>		
Website		
☐ Save my name, email, and website in this browser for the next time I com	ment.	
Post Comment		
Search:		
e.g. whirlpool wrf535swhz	Search	

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.