

amalock L33415 DB701 Wireless Doorbell and Chime Kit **Owner's Manual**

Home » amalock » amalock L33415 DB701 Wireless Doorbell and Chime Kit Owner's Manual



Contents

- 1 amalock L33415 DB701 Wireless Doorbell and Chime
- 2 Usage Instructions
- **3 OVERVIEW**
- **4 Description**
- **5 Features**
- **6 Product Table**
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**



amalock L33415 DB701 Wireless Doorbell and Chime Kit



The AMALOCK DB701 Wireless Doorbell & Chime Kit is a complete package that includes a white CAM200A Wi-Fi video camera, a battery charger, and two rechargeable batteries. It is designed for both residential and commercial entrances and is easy to install.

The camera streams an image to your mobile device whenever motion is detected, allowing you to take action. The built-in 2-way audio intercom allows you to talk to the visitor as they ring the doorbell. No monthly subscription is required, and the kit includes a 16GB memory card.

AMALOCK DB701 Wireless Doorbell & Chime Kit With 1 x White CAM200A Camera, Battery Charger And Rechargeable Batteries

Features:

- Up to 5 users per doorbell and unlimited doorbells per mobile device
- The supplied camera is a white finish
- Works with the Amalock App free to download from the Apple or Android Store
- · IR night vision
- · Supports IOS & Android
- · Works with Alexa and Google Home
- Motion alert to your mobile device
- 2-way audio intercom
- 1080P HD video and live streaming with 16GB SD card
- Kit includes 1 x white CAM200A Wi-Fi video camera

Usage Instructions

- 1. Install the doorbell and plug in the chime.
- 2. Download the Amalock App from the Apple or Android Store.
- 3. Connect the doorbell to your home Wi-Fi network using the Amalock App.
- 4. Insert the included rechargeable batteries into the doorbell.

- 5. Insert the included 16GB memory card into the doorbell.
- 6. Charge the batteries using the included battery charger.
- 7. Place the camera in a suitable location near the entrance.
- 8. Connect the camera to your home Wi-Fi network using the Amalock App.
- 9. Test the doorbell and camera to ensure they are working correctly.

Note: The doorbell and camera will work together to provide you with a comprehensive security solution for your entrance. Whenever someone rings the doorbell or motion is detected, the camera will stream an image to your mobile device. You can then use the 2-way\ audio intercom to talk to the visitor and take appropriate action. The included memory card will store videos and images for future reference.

OVERVIEW



Description

This Amalock DB701 wireless doorbell & plug-in chime kit includes 1 x white CAM200A Wi-Fi video camera, battery charger and 2 rechargeable batteries. It is suitable for both residential and commercial entrances and is easy to install. Whenever a motion is detected the camera streams an image to your mobile device to alert you of any activity at the entrance allowing you to take action. The built-in 2 way audio allows you to talk to the visitor as they ring the doorbell. No monthly subscription is needed and also included is a 16GB memory card.







h An App Battery Backup

Features

- Up to 5 users per doorbell and unlimited doorbells per mobile device
- The supplied camera is a white finish
- Works with the Amalock App free to download from the Apple or Android Store
- IR night vision
- Supports IOS & Android works with Alexa and Google Home
- Motion alert to your mobile device
- 2-way audio intercom
- 1080P HD video and live streaming with 16GB SD card
- Kit includes 1 x white CAM200A Wi-Fi video camera

Product Table

L33415Black DB701- B-KIT



L33413White DB701-W-KIT



Documents / Resources



amalock L33415 DB701 Wireless Doorbell and Chime Kit [pdf] Owner's Manual L33415 DB701 Wireless Doorbell and Chime Kit, L33415, DB701 Wireless Doorbell and Chime Kit, Wireless Doorbell and Chime Kit, Chime Kit, Chime Kit

References

• Amalock

Manuals+,