



amazon basics ABIM13 Wired Gaming Mouse User Manual

[Home](#) » [amazon basics](#) » amazon basics ABIM13 Wired Gaming Mouse User Manual 

amazon basics ABIM13 Wired Gaming Mouse



Contents

- [1 Thank you](#)
- [2 Feature](#)
- [3 Installation](#)
- [4 E-Waste Disposal](#)
- [5 Warranty & Service](#)
- [6 This warranty exclude, or does not apply or become void if](#)
- [7 Instructions of handling the product during and after its use and Do's and Don'ts with respect to handling the product](#)
- [8 Don'ts](#)
- [9 Customer Support](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)

Thank you

Thank you for purchasing the Amazon Basics ABIM13 Wired Gaming Mouse.
In order for you to use this product safely & correctly, please read this user manual carefully.

Feature

- Rating Voltage : 5Vdc, 150 mA
- Total number of keys: 9 Keys
- Cable Length: 150 cm
- Resolution: 800/1600/2400/3200/4800/6400
- Total Weight: approx. 118g
- Dimensions : 12.8 x 8.86 x 4.30 cm approx.

Installation

Follow below process for connecting mouse with U5B Connector:

Plug the USB connector into a USB port on your computer. Your computer automatically finds and install the appropriate driver. When the installation completes, you can use your mouse.

E-Waste Disposal

Be a Responsible User. Recycle or refurbish your old Amazon brand products to help protect the environment. The crossed-out bin symbol on this product or its packaging signifies that this product should be discarded separately from ordinary household waste at its end of life. Be aware that it is your responsibility to dispose-off e-waste in such a manner that no damage to human health and environment occur.

E-waste is generated from electronic and electrical appliances/components which have reached their end-of-life period or are no longer fit for their original intended use and are destined for recovery, recycling or disposal. E-waste when disposed or recycled improperly, can cause severe environmental pollution and adversely affect the human body as they contain toxic chemicals.

Please ensure that the electronic products that are unwanted, not working, and nearing or at the end of- life are disposed-off only through authorized recycling or refurbishing points. Please contact your municipal waste management authority or your house- hold waste disposal service for additional details. This product and the components there of confirm to the provisions of hazardous substances.

Specified under Rule 16 (1) and Rule 16 (4) of E-waste (Management) Rules, 2022 [Chapter VII titled the Reduction in the Use of Hazardous Substances in the manufacture of electrical and electronic equipment and their components or consumables or parts or spares].

Warranty & Service

1. We grant 1 year warranty on the product commencing from the date Of purchase against defects in manufacturing, materials, and assembly.
2. Within the warranty period, we will correct any defects in materials or Workmanship, either by repairing or replacing the complete appliance, As we may choose, free of charge. The warranty is valid to the original Purchase only.
3. For customer service related queries, please contact us: 1800-419-2373 (available Monday to Saturday from 9.30 am to 6:00 pm except national Holidays). For warranty detail, please visit the product page or call Customer service number.
4. Any accessories provided with the product are not covered under warranty.
Any physical and/or water damage to the product shall void any warranty.

This warranty exclude, or does not apply or become void if

1. Damage is cause by improper use, abuse or excessive use outside the Intended purpose.
2. Normal wear or use as well as defects that have a negligible effects on The value or operation of the appliance.

3. Repairs or product modifications have been carried out by unauthorized Organization or person and if original amazon basics part are not used.
4. Consequential damages (including but not limited to loss of data or Loss of income), nor compensation for activities done by yourself.
5. The proof-of-purchase has been altered in any way or is made illegible.
6. The model number, serial number or production date code on the Product has been altered, removed or made illegible.
7. The defects is caused by connecting peripherals, additional equipment Or accessories other than those recommended in the user manual.

Instructions of handling the product during and after its use and Do's and Don'ts with respect to handling the product

Do's:

- **a)** Always look for information in the product's user's guide for end-of-life equipment handling.
- **b)** Ensure that only authorized recyclers handle your electronic products.
- **c)** Always call local authorized e-waste collection centers to dispose products that have reached end-of life phase.
- **d)** When your used electronic products, batteries or accessories reach the end of their life, always dispose them at your nearest authorized e-waste collection center.
- **e)** Wherever possible or as instructed, separate the packaging material according to responsible waste disposal options and sorting for recycling.
- **f)** Always ensure any glass surface is protected against breakage.
- **g)** Kindly ensure that the product is properly packaged as per instructions before handing it over to the authorized Recycler.

Don'ts


- **a)** Do not dismantle your electronic products on your own.
- **b)** Do not throw electronics having "Do not Dispose" symbol on the product package in your regular garbage bins along with municipal waste since it will ultimately reach a landfill.
- **c)** Do not give e-waste to informal and unorganized sectors like local scrap dealers. Be a Responsible User. Recycle your E-Waste for a Greener Planet.

Customer Support

amazon.in/amazonbasics



Documents / Resources

| | |
|---|---|
|  | amazon basics ABIM13 Wired Gaming Mouse [pdf] User Manual ABIM13 Wired Gaming Mouse, ABIM13, Wired Gaming Mouse, Gaming Mouse, Mouse |
|---|---|

References

- [User Manual](#)