

amazon basics B005EJEJH6RW 3 Button USB Wired Mouse Instructions

Home » amazon basics » amazon basics B005EJEJH6RW 3 Button USB Wired Mouse Instructions



Contents

- 1 amazon basics B005EJEJH6RW 3 Button USB Wired
- Mouse
- **2 Important Safety Instructions**
- 3 Explanation of Symbols
- **4 Product Description**
- **5 Operation**
- **6 Cleaning and Maintenance**
- 7 FCC Supplier's Declaration of Conformity
- **8 FCC Compliance Statement**
- 9 Disposal
- 10 Specifications
- 11 Documents / Resources
 - 11.1 References



amazon basics B005EJEJH6RW 3 Button USB Wired Mouse



Important Safety Instructions


CAUTION

Avoid looking directly into the beam.

- Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.
- Protect the product from extreme temperatures, hot surfaces, open flames, direct sunlight, water, high humidity, moisture, strong jolts, flammable gases, vapors and solvents.
- Do not bend or kink the cable.
- This product is intended to be used in dry areas only. SAVE THESE INSTRUCTIONS

Explanation of Symbols

===	Direct current (DC).	
•	USB plug	
CE	This symbol stands for "Conformité Européenne", which declares "Conformity with EU directives, regulations and appplicable standards". With the CE-marking, the manufacturer confirms that this product complies with applicable European directives and regulation.	
UK	This symbol stands for "United Kingdom Conformity Assessed". With the UKCA-marking, the manufacturer confirms that this product complies with applicable regulations and standards within Great Britain.	



- · A Left button
- · B Scroll wheel
- C Right button
- · D USB cable and plug
- E Sensor

Operation

- Left button (A): Left click function according to your computer system settings.
- Right button (CJ: Right click function according to your computer system settings.
- Scroll wheel (B): Rotate the scroll wheel to scroll up or down on the computer screen. Click function according to your computer system settings.

NOTICE The product does not work on glass surfaces.

Cleaning and Maintenance

NOTICE

- During cleaning do not immerse the product in water or other liquids. Never hold the product under running water.
- · Unplug before cleaning.
- To clean the product, wipe with a soft, slightly moist cloth.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.
 Store the product in its original packaging in a dry area. Keep away from children and pets.

FCC - Supplier's Declaration of Conformity

Unique Identifier:

- B00SEJH6RW AmazonBasics 3-Button USB Wired Computer Mouse (Black), 1-Pack
- B01 ND1 K9TT Amazon Basics 3-Button USB Wired Computer Mouse (Black), 30-Pack Bulk
- · Responsible Party

Amazon.com Services LLC.

• U.S. Contact Information

410 Terry Ave N. Seattle, WA 98109, United States

• Telephone Number

(206) 266-1000

FCC Compliance Statement

1. This device complies with Part 1 S of the FCC Rules.

Operation is subject to the following two conditions:

- this device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 1 S of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Canada IC Notice

This Class B digital apparatus complies with Canadian CAN ICES-3(B) / NMB-3(B) standard.

Disposal

The Waste Electrical and Electronic Equipment (WEEE) Directive aims to minimise the impact – of electrical and electronic goods on the environment, by increasing reuse and recycling and by reducing the amount of WEEE going to landfill. The symbol on this product or its packaging signifies that this product must be disposed of separately from ordinary household wastes at its end of life. Be aware that this is your responsibility to dispose of electronic equipment at recycling centers in order to conserve natural resources. Each country should have its collection centers for electrical and electronic equipment recycling. For information about your recycling drop off area, please contact your related electrical and electronic equipment waste management authority, your local city office, or your household waste disposal service.

Specifications

Rated voltage	5 V === , 50 mA
OS compatibility	Windows 7/8/10, Mac OS
USB compatibility	1.1, 2.0, 3.0

Importer Information

	For EU
Postal:	Amazon EU S.à r.l., 38 avenue John F. Kennedy, L-1855 Luxembourg
Business Reg.:	134248
	For UK
Postal:	Amazon EU SARL, UK Branch, 1 Principal Place, Worship St, London EC2A 2FA, United Kingdom
Business Reg.:	BR017427

Documents / Resources



<u>amazon basics B005EJEJH6RW 3 Button USB Wired Mouse</u> [pdf] Instructions B005EJEJH6RW 3 Button USB Wired Mouse, B005EJEJH6RW, 3 Button USB Wired Mouse, B utton USB Wired Mouse, USB Wired Mouse, Wired Mouse, Mouse

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.