

amazon basics B018FCZKR2 Guitar Folding A Frame Stand Instruction Manual


[Home](#) » [amazon basics](#) » amazon basics B018FCZKR2 Guitar Folding A Frame Stand Instruction Manual 

Contents

- [1 azon basics B018FCZKR2 Guitar Folding A Frame Stand](#)
- [2 Important Safeguards](#)
- [3 Intended Use](#)
- [4 Product Description](#)
- [5 Before First Use](#)
- [6 Assembly](#)
- [7 Cleaning and Maintenance](#)
- [8 Disposal](#)
- [9 Importer Information](#)
- [10 Feedback and Help](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)
- [12 Related Posts](#)



azon basics B018FCZKR2 Guitar Folding A Frame Stand



Important Safeguards

Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.


When using the product, basic safety precautions should always be followed to reduce the risk of injury including the following:

- For domestic and professional use.
- Be cautious when opening/closing (folding/unfolding) the product. Keep hands away from the folding mechanisms to prevent fingers from being trapped and pinched.
- Do not let children climb on or play with the product.
- Place and use the product on a firm, level ground.
- Do not use this product if any parts are missing, damaged, or worn.
- To avoid scratching the floor, fold/unfold the product on a soft surface, such as a carpet.
- Regularly examine the product for wear and tear. Stop using the product at first sign of damage or if parts become detached.
- Do not place any items other than guitars on the product.
- The product is not suitable for guitars with nitrocellulose-finish.

Intended Use

- This product is intended to be used as a universal stand for acoustic and electric guitars.
- This product provides a stable and portable solution for musicians, safely minimizing the risk of damage for the guitar.

Product Description



- A Locking device
- B Locking screw
- C Legs
- D Soft foam arms
- E Non-slip rubber cap
- F Stand

Before First Use

DANGER Risk of suffocation!


Keep any packaging materials away from children and pets – these materials are a potential source of danger, e.g. suffocation.

- Remove all the packing materials.
- Remove and review all components before assembly.
- Check the product for transport damages.
- Make sure that all parts are in good condition.

Assembly


Folding/Unfolding

1. To unfold, hold the stand (F) to stabilize the product while pulling the locking device (A) outwards (Fig.1)
2. To fold, hold the stand (F) to stabilize the product while pulling the locking device (A) inwards (Fig.1)




Adjusting Width

1. To adjust the legs (C) to desired width, press and hold the locking screw (B) to unlock the locking device (A) (Fig.2).



2. Release the locking screw (B) to lock the product to the desired width (Fig. 3).

3

Cleaning and Maintenance

Cleaning

- To clean the product, wipe with a soft, slightly damp cloth.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.

Maintenance

- Check the components regularly to make sure all screws and bolts are tightened.
- Store in a cool and dry place away from children and pets, ideally in original packaging.

Disposal

Dispose of the product according to local regulations. If in doubt, consult your local authorities.

Importer Information

- **For EU**
 - **Postal** Amazon EU S.à r.l. 38 avenue John F. Kennedy, L-1855 Luxembourg
 - **Business Reg** 134248
- **For UK**
 - **Postal** Amazon EU SARL, UK Branch 1 Principal Place, Worship St, London EC2A 2FA, United Kingdom
 - **Business Reg** BRO17427

Feedback and Help

We would love to hear your feedback. To ensure we are providing the best customer experience possible, please consider writing a customer review.

- Scan QR Code below with your phone camera or QR reader:

- **US:**




- **UK:** [amazon.co.uk/review/review-your-purchases#](https://www.amazon.co.uk/review/review-your-purchases#)

- If you need help with your Amazon Basics product, please use the website or number below.

- **US:** [amazon.com/gp/help/customer/contact-us](https://www.amazon.com/gp/help/customer/contact-us)
- **UK:** [amazon.co.uk/gp/help/customer/contact-us](https://www.amazon.co.uk/gp/help/customer/contact-us)
- +1 [877-485-0385](tel:877-485-0385) (US Phone Number)

Documents / Resources

 <p>amazon basics</p> <p>Guitar Folding A-Frame Stand Supports guitar & acoustic guitar. Fits all guitar styles. Durable, foldable & easy to store. Adjustable height & angle. Includes a carrying strap. Dimensions: 18" x 18" x 18" Weight: 1.5 lbs Material: Steel</p>	<p>amazon basics B018FCZKR2 Guitar Folding A Frame Stand [pdf] Instruction Manual B018FCZKR2 Guitar Folding A Frame Stand, B018FCZKR2, Guitar Folding A Frame Stand, Folding A Frame Stand, Frame Stand, Stand</p>
--	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.