

amazon basics B075NHVPPN Rectangular Cork Notice Board **User Manual**

Home » amazon basics » amazon basics B075NHVPPN Rectangular Cork Notice Board User Manual



Contents

- 1 amazon basics B075NHVPPN Rectangular Cork Notice
- **2 Product Information**
- **3 Product Using Instructions**
- **4 Installation Instruction**
- **5 Specifications**
- 6 Documents / Resources
 - **6.1 References**



amazon basics B075NHVPPN Rectangular Cork Notice Board



Product Information

The Amazon Basics B075NHVPPN Rectangular Cork Notice Board has the following specifications:

- **Usage**: Ideal for posting information, announcements, photos, and more, suitable for both home and office environments.
- Surface: Features a self-healing cork surface that is compatible with all types of pins.
- Frame: Comes with an aluminium frame that has a silver finish, providing a sturdy and stylish look.
- **Installation**: Can be mounted vertically or horizontally to fit different spaces, and includes a mounting kit for easy installation.
- **Dimensions**: Measures 600 by 900 mm (approximately 23.6 x 35.4 inches.

Product Using Instructions


While the specific instructions were not detailed in the search results, typically, instructions for a cork noticeboard like this one would include the following steps:

- 1. **Unboxing**: Carefully remove the cork noticeboard from its packaging.
- 2. **Check Components**: Ensure all parts are included, such as the cork notice board itself, mounting hardware (screws, wall anchors), and any included tools or accessories.
- 3. **Choose Location**: Decide on the placement of the cork notice board, considering visibility and accessibility. It can be mounted horizontally or vertically, so think about which orientation best suits your space and needs.
- 4. **Mark Drill Points**: Hold the board against the wall in the desired position. Use a level to ensure it's straight. Mark the wall through the mounting holes located on the frame of the corkboard.
- 5. **Drill Holes**: Drill holes at the marked points. If you're drilling into drywall, make sure to use the appropriate size drill bit for the wall anchors included with the notice board.

- 6. Insert Wall Anchors: If included and necessary for your wall type, tap the wall anchors into the drilled holes.
- 7. **Attach the Board to the Wall**: Align the cork board with the drilled holes and insert screws through the mounting holes into the wall anchors or directly into the wall. Tighten the screws until the board is securely mounted but be careful not to overtighten and damage the frame or wall.
- 8. Final Check: Ensure the board is securely attached to the wall and level. Adjust if necessary.
- 9. **Usage**: You can start using the cork board by pinning notices, photos, and other items using push pins or thumbtacks. The self-healing cork surface is designed to accommodate repeated pinning without significant wear.

Aluminum Frame Cork Notice Board 90cm x 60cm

Installation Instruction



Important Safeguards

DANGER Risk of suffocation! Keep any packaging materials away from children – these materials are a potential source of danger, e.g. suffocation.

- Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.
- Do not drill into any pipes or power lines beneath the surface during mounting hole preparation. Use voltage/metal detector.
- · Do not overtighten the fasteners.

Specifications

• Dimensions: 900 x 600 mm

Importer Information

	For EU
Postal:	Amazon EU S.à r.l., 38 avenue John F. Kennedy, L-1855 Luxembourg
Business Reg.:	134248
	For UK
Postal:	For UK Amazon EU SARL, UK Branch, 1 Principal Place, Worship St, London EC2A 2FA, United Kingdom

Documents / Resources



<u>amazon basics B075NHVPPN Rectangular Cork Notice Board</u> [pdf] User Manual B075NHVPPN Rectangular Cork Notice Board, B075NHVPPN, Rectangular Cork Notice Board, Cork Notice Board, Board

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.