



amazon basics B07D7TL9KM Computer Speakers for Desktop or Laptop PC User Guide

[Home](#) » [amazon basics](#) » amazon basics B07D7TL9KM Computer Speakers for Desktop or Laptop PC User Guide 

amazon basics B07D7TL9KM Computer Speakers for Desktop or Laptop PC User Guide



Contents

- 1 **IMPORTANT SAFEGUARDS**
- 2 **Connection**
- 3 **Operation**
- 4 **Using Headphones (not included)**
- 5 **Cleaning and Maintenance**
- 6 **Polarized Plug (US version only)**
- 7 **FCC – Supplier's Declaration of Conformity**
- 8 **FCC Compliance Statement**
- 9 **FCC Interference Statement**
- 10 **Canada IC Notice**
- 11 **Disposal**
- 12 **Warranty Information**
- 13 **Feedback and Help**
- 14 **Documents / Resources**
- 15 **Related Posts**

IMPORTANT SAFEGUARDS

Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

- This product is intended to play audio via a 3.5 mm audio jack connector.
- This product is intended to be used in dry indoor areas only. No naked flame sources, such as lighted candles, should be placed on the apparatus.
- The apparatus shall not be exposed to dripping or splashing and no objects filled with liquid shall be placed on the apparatus. Before connecting the product to the power supply, check that the power supply, voltage and current rating corresponds with the power supply details shown on the product rating label.
- This product is classified as protection class II. This means the product is equipped with reinforced or double insulation between the mains supply circuit and the output voltage or the casing. Therefore it does not require a safety connection to an electrical earth (ground). Regularly check the power plug and power cord for damage. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Long-term exposure to loud music or sounds may cause hearing loss. To prevent possible hearing damage, do not listen at high volume levels for long periods.
- This product should not be used near water.



WARNING

The mains plug is used as disconnect device, the disconnect device shall remain readily operable.

Connection

1. Connect the product's power plug to the appropriate power socket.
2. Connect the 3.5 mm audio jack connector to the audio output jack of your computer

Operation

1. Turn the volume control knob in the clockwise direction to turn the product on. The LED lights up blue.
2. Keep turning in the clockwise direction to increase the volume level.
3. To turn off, turn the volume control knob all the way in the anti-clockwise direction. The LED goes off.

NOTICE

The volume can also be controlled via your computer volume settings. If the product does not play audio, ensure the audio output of your computer is not muted.

Using Headphones (not included)

1. Connect the 3.5 mm audio jack connector of your headphones to the product's audio output jack.
2. The volume can be controlled with the volume control knob.

NOTICE

After connecting the external headphones the product is muted automatically.

Cleaning and Maintenance



WARNING

Risk of electric shock! To prevent electric shock, unplug before cleaning

- To clean, wipe with a soft, slightly moist cloth
- Dry the product after cleaning
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product,

Polarized Plug (US version only)

- This appliance has a polarized plug (one blade is wider than the other) "To reduce the risk of electric shock, this plug will fit only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

FCC – Supplier's Declaration of Conformity

Unique Identifier	B07D7TL9KM, B07D94Z3JH, B07D924NF5 Computer Speakers for Desktop or Laptop, AC-Powered
Responsible Party	Amazon.com Services, Inc
U.S. Contact Information	410 Terry Ave N. Seattle, WA 98109, United States
Telephone Number	(206) 266-1000

FCC Compliance Statement

1. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
 1. this device may not cause harmful interference, and
 2. this device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected,
- Consult the dealer or an experienced radio/TV technician for help.

Canada IC Notice

Disposal



The Waste Electrical and Electronic Equipment (WEEE) Directive aims to minimize the impact of electrical and electronic goods on the environment, by increasing re-use and recycling and by reducing the amount of WEEE going to landfill. The symbol on this product or its packaging signifies that this product must be disposed separately from ordinary household wastes at its end of life. Be aware that this is your responsibility to dispose of electronic equipment at recycling centers in order to conserve natural resources. Each country should have its collection centers for electrical and electronic equipment recycling. For information about your recycling drop off area, please contact your local electrical and electronic equipment waste management authority, your local city office, or your household waste disposal service.

Warranty Information

to obtain a copy of the warranty for this product:



Us: amazon.com/AmazonBasics/Warranty
UK: amazon.co.uk/basics-warranty



UK: +44 (0) 800-279-7234

Feedback and Help

Love 7 Hate t? Lot us know with a custome revie:

AmazonBasics is committed to delivering customer-driven products that five. p to your high standards. We encourage you to write a review sharing your experiences with the product.



Documents / Resources

	<p>amazon basics B07D7TL9KM Computer Speakers for Desktop or Laptop PC [pdf] User Guide</p> <p>B07D7TL9KM Computer Speakers for Desktop or Laptop PC, B07D7TL9KM, Computer Speakers for Desktop or Laptop PC, Speakers for Desktop or Laptop PC, for Desktop or Laptop PC, Desktop or Laptop PC, or Laptop PC, Laptop PC, PC</p>
---	--