




amazon basics B07DDK3W5D USB Powered Computer Speaker With Dynamic Sound User Guide

[Home](#) » [amazon basics](#) » amazon basics B07DDK3W5D USB Powered Computer Speaker With Dynamic Sound User Guide 



Quick Start Guide

USB-Powered Computer Speakers with Dynamic Sound
B07DDK3W5D, B07DDGBL5T,
B07DDGBJON, B07DDDTWDP



Contents

- 1 IMPORTANT SAFEGUARDS
- 2 Connection
- 3 Operation
- 4 Cleaning and Maintenance
- 5 FCC – Supplier's Declaration of Conformity
- 6 Canada IC Notice
- 7 Disposal (for Europe only)
- 8 Specifications
- 9 Symbol Explanation
- 10 Feedback and Help
- 11 Documents / Resources
 - 11.1 References

IMPORTANT SAFEGUARDS

Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

- Nonaked flame sources, such as lighted candles, should be placed on the product.
- The product shall not be exposed to dripping or splashing and that no objects filled with liquid shall be placed on the product.
- This product is intended to be used in dry indoor areas only.
- ong-term exposure to loud music or sounds may cause hearing loss. To prevent possible hearing damage, do not listen at high volume levels for long periods of time.
- This product should not be used near water.

Connection

1. Connect the product's USB cable to the USB slot of your computer. The LEDs light up blue.
2. Connect the 3.5 mm audio jack connector to the audio output jack of your computer or mobile device.

Operation

1. To increase the volume level, turn the volume control knob in the + direction.
2. To decrease the volume level, turn the volume control knob in the – direction.
3. To turn off, disconnect the product's USB cable from the USB slot of your computer. The LEDs go off.

NOTICE

The volume can also be controlled via your computer volume settings. If the product does not play audio, ensure the audio output of your computer is not muted.

Cleaning and Maintenance

- To clean, wipe with a soft, slightly moist cloth.
- Dry the product after cleaning.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.

FCC – Supplier's Declaration of Conformity

Unique Identifier	BO7DDK3W5D, BO7DDGGBL5T, BO7DDGGBJ9N, BO7DDDTWDP USB-Powered Computer Speakers with Dynamic Sound
Responsible Party	Amazon.com Services, Inc
U.S. Contact Information	410 Terry Ave N. Seattle, WA 98109, United States
Telephone Number	(206) 266-1000

5.1 FCC Compliance Statement

1. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
 1. this device may not cause harmful interference, and
 2. this device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

5.2 FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Canada IC Notice

This Class B digital apparatus complies with Canadian CAN ICES-3(B) / NMB-3(B) standard.

Disposal (for Europe only)

The Waste Electrical and Electronic Equipment (WEEE) laws aim to minimise the impact of electrical and electronic goods on the environment and human health, by increasing re-use and recycling and by reducing the amount of WEEE going to landfill.



The symbol on this product or its packaging signifies that this product must be disposed separately from

ordinary household wastes at its end of life. Be aware that this is your responsibility to dispose of electronic equipment at recycling centres in order to conserve natural resources. Each country should have its collection centres for electrical and electronic equipment recycling. For information about your recycling drop off area, please contact your related electrical and electronic equipment waste management authority, your local city office, or your household waste disposal service.

Specifications

Model:	BO7DDK3W5D (Black)	BO7DDGGBL5T (Silver)	BO7DDGGBJ9N (4-pack, Black)	BO7DDDTWDP (4-pack, Silver)
Power source:	5 V USB port			
Power consumption:	5 W			
Output power:	2 x 1.2 W			
Impedance:	40			
Separation:	≥ 35 dB			
S/N Ratio:	≥ 65 dB			
Frequency range:	80 Hz – 20 KHz			

8.1 Importer Information

For EU

Postal	Amazon EU S.ar.l., 38 avenue John F. Kennedy,L-1855 Luxembourg
Business Reg.	134248

For UK

Postal	Amazon EU SARL, UK Branch, 1 Principal Place, Worship St, London EC2A 2 FA, United Kingdom
Business Reg	BRO17427

Symbol Explanation



This symbol stands for “Conformité Européenne”, which declares “Conformity with EU directives, regulations and applicable standards”. With the CE-marking, the manufacturer confirms that this product complies with applicable European directives and regulations.



This symbol stands for “United Kingdom Conformity Assessed”. With the UKCA-marking, the manufacturer confirms that this product complies with applicable regulations and standards within Great Britain.



Direct current (DC)

Feedback and Help

We would love to hear your feedback. To ensure we are providing the best customer experience possible, please

consider writing a customer review.
Scan QR Code below with your phone camera or QR reader:
US:




https://www.amazon.com/review/review-your-purchases/listing/?ref=HPB_UM_CR

 UK: [amazon.co.uk/review/review-your-purchases#](https://www.amazon.co.uk/review/review-your-purchases#)

If you need help with your Amazon Basics product, please use the website or number below.

 US: [amazon.com/gp/help/customer/contact-us](https://www.amazon.com/gp/help/customer/contact-us)

UK: [amazon.co.uk/gp/help/customer/contact-us](https://www.amazon.co.uk/gp/help/customer/contact-us)

 +1 877-485-0385 (US Phone Number)



[amazon.com/AmazonBasics](https://www.amazon.com/AmazonBasics)

MADE IN CHINA
V09-10/23



Documents / Resources





USB Powered Computer Speaker With Dynamic Sound
C1Cz8ByrQ6L, B07DDK3W5D USB Powered Computer Speaker With Dynamic Sound, B07DDK3W5D, USB Powered Computer Speaker With Dynamic Sound, Powered Computer Speaker With Dynamic Sound, Computer Speaker With Dynamic Sound, Speaker With Dynamic Sound, Dynamic Sound, Computer Speaker, Speaker, Speaker B07DDK3W5D

[amazon basics B07DDK3W5D USB Powered Computer Speaker With Dynamic Sound](#) [pdf]

f] User Guide

C1Cz8ByrQ6L, B07DDK3W5D USB Powered Computer Speaker With Dynamic Sound, B07DDK3W5D, USB Powered Computer Speaker With Dynamic Sound, Powered Computer Speaker With Dynamic Sound, Computer Speaker With Dynamic Sound, Speaker With Dynamic Sound, Dynamic Sound, Computer Speaker, Speaker, Speaker B07DDK3W5D

References

-  [Amazon Sign In](#)
-  [Amazon Sign In](#)

- [!\[\]\(2dc8cdc0c918df88cde61039ecf68682_img.jpg\) Amazon Sign-In](#)
- [!\[\]\(793119bf0d613bd9b598fb8668922511_img.jpg\) Amazon Sign In](#)
- [!\[\]\(0a4819029e810ca9d2aba79260b63a4d_img.jpg\) Amazon Sign In](#)
- [!\[\]\(5b78a2fafd05db5e14d20573d68ef9b3_img.jpg\) Connexion Amazon](#)
- [!\[\]\(25fe2c0d7244c22c84de6bda963b471d_img.jpg\) Connexion Amazon](#)
- [!\[\]\(d4bd0dc972749ad3ba477eac47688a0b_img.jpg\) Amazon Iniciar sesión](#)
- [!\[\]\(5eab3de5002abb449199a3fc43c9f414_img.jpg\) Amazon Iniciar sesión](#)
- [!\[\]\(3f2384a64e2c0ffe3eae9a8107dd00c7_img.jpg\) Amazon Sign-In](#)
- [!\[\]\(0a4ab723df2c815236fb0c30cb14280f_img.jpg\) Amazon Sign In](#)
- [!\[\]\(a5e6025d913df625081ab04ab57538d0_img.jpg\) Amazon Sign In](#)
- [!\[\]\(933db2af0bc51ccc9956c85daceec771_img.jpg\) Iniciar sesión en Amazon](#)
- [!\[\]\(aa37c4d902b06a4c60c80e22dbdcae63_img.jpg\) Iniciar sesión en Amazon](#)
- [!\[\]\(305017e3492be9834d83526ded9a5546_img.jpg\) Connexion Amazon](#)
- [!\[\]\(ce93526cc7275dc99a5e28e42c2dec45_img.jpg\) Connexion Amazon](#)
- [!\[\]\(3d8621e1356074fde3f4532b15fe8afa_img.jpg\) Amazon Accedi](#)
- [!\[\]\(871f3967dd06baf62bc0e930d9243f73_img.jpg\) Amazon Accedi](#)
- [!\[\]\(37c6dc81049e8a4c6dd88ffa288e134a_img.jpg\) Inloggen bij Amazon](#)
- [!\[\]\(4d2dd53ee1a5a6f5efa820e745814047_img.jpg\) Inloggen bij Amazon](#)
- [!\[\]\(632644865a98825d4ab6066f88459a98_img.jpg\) Amazon.co.jp](#)