




amazon basics B07LFV6Y8S Tilting Projector Bracket Mount For Ceiling and Wall Installation Guide

[Home](#) » [amazon basics](#) » amazon basics B07LFV6Y8S Tilting Projector Bracket Mount For Ceiling and Wall Installation Guide 

amazon basics B07LFV6Y8S Tilting Projector Bracket Mount For Ceiling and Wall



Contents


- [1 Instruction Video](#)
- [2 Tools Needed](#)
- [3 Delivery Content](#)
- [4 Remove Plastic Cover](#)
- [5 Pre-assemble Ceiling Plate](#)
- [6 Find A Ceiling Joist](#)
- [7 Drill Holes](#)
- [8 Fix To Ceiling](#)
- [9 Assemble The Cover](#)
- [10 Mount To Projector](#)
- [11 Assemble The Mount](#)
- [12 Adjustments](#)
- [13 Documents / Resources](#)
 - [13.1 References](#)
- [14 Related Posts](#)

Instruction Video




Tilting Projector Bracket Mount for Ceiling and Wall

Tools Needed




Delivery Content


- CP (x 1)




- PC (x 2)




- MB (x 1)




- MB2 (x 1)



- MA (x 4)




- IT (x 1)




- TS (x 2)

MG.3 x 63 mm




- A (x4)

M3 x 12 mm




- B (x 4)

M4 x 12 mm




- C (x 4)

M5 x 12 mm




- D (x 4)

M6 x 12 mm




- E (x 8)

M5 x 10 mm




- F (x4)

M6 x 12 mm




- G (x 2)

M5



- H (x 4)

M6



- I (x 4)

M5




- J (x 4)

M4



- K (x4)

M5




- L (x 4)


M5




Remove Plastic Cover




Pre-assembly Ceiling Plate





Do not over-tighten.




Find A Ceiling Joist




Drill Holes



Fix To Ceiling




Assemble The Cover



Mount To Projector




Without adapter


⚠ max. Ø 4.4" (11.2 cm)




A



	 + 	
M3	A	J
M4	B	J
M5	C	I
M6	D	





B







With 1 adapter

⚠ max. Ø 11.21" (28.4 cm)




A


	 + 	
M3	A	J
M4	B	J
M5	C	I
M6	D	






B




With 2 adapters

 max. Ø 19.07" (48.43 cm)







A





B




Assemble The Mount



Adjustments



amazon basics

	<p>amazon basics B07LFV6Y8S Tilting Projector Bracket Mount For Ceiling and Wall [pdf] Installation Guide</p> <p>B07LFV6Y8S, B07LFV6Y8S Tilting Projector Bracket Mount For Ceiling and Wall, Tilting Projector Bracket Mount For Ceiling and Wall, Projector Bracket Mount For Ceiling and Wall, Bracket Mount For Ceiling and Wall, Mount For Ceiling and Wall, Ceiling and Wall, Wall</p>
--	--

References

- [User Manual](#)