



amazon basics B07PHPSDRV Spring Door Stop User Manual



[Home](#) » [amazon basics](#) » amazon basics B07PHPSDRV Spring Door Stop User Manual 



Spring Door Stop

BO7PHPSDRYV,
BO7PFFFFMT,
BO7PDHMH6,
BO7PKWZJWP,
BO7PJV5MVG.

B07PHPSDRV Spring Door Stop



Caution

This product contains small items that could be a choking hazard if swallowed.
Keep these items away from young children.

- Make Sure these instructions are read and completely understood before attempting installation. If you are unsure of any part of this installation, please contact a professional installer for assistance.

Step 1: Position mounting base on the base board / wall and mark the hole using a pencil.

Step 2: Using the spot you marked pre-drill a hole using a 1/16" drill bit.

Step 3: Place the flat side of the mounting plate against the baseboard / wall and secure it using the provide screw.

NOTICE | Do Not Overtighten.

Step 4: Insert the spring into the metal hole and turn clockwise once.

Warranty Information

To obtain a copy of the warranty for this product:



US: amazon.com/AmazonBasics/Warranty

UK: amazon.co.uk/basics-warranty



US: +1-866-216-1072 / UK: +44 (0) 800-279-7234

Feedback and Help

Love it? Hate it? Let us know with a customer review.



US: amazon.com/review/review-your-purchases#

UK: amazon.co.uk/review/review-your-purchases#




US: amazon.com/gp/help/customer/contact-us

UK: amazon.co.uk/gp/help/customer/contact-us



amazon basics

Documents / Resources

	<p>amazon basics B07PHPSDRV Spring Door Stop [pdf] User Manual B07PHPSDRV Spring Door Stop, B07PHPSDRV, Spring Door Stop, Door Stop, Stop</p>
---	---

References

- [User Manual](#)

Manuals+.