



amazon basics B07T2C3QNZ 4 Digit Combination Lock User Manual

[Home](#) » [amazon basics](#) » amazon basics B07T2C3QNZ 4 Digit Combination Lock User Manual 




4-Digit Combination Padlock
B07T2C3QNZ

Contents


- [1 Setting code](#)
- [2 Indicator line](#)
- [3 Unlocking](#)
- [4 Disposal](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)

Setting code


1. Set the wheels to the default (0-0-0-0) code on the indicator line. Pull up the shackle.




2. Rotate the shackle about 90 degrees towards the pin slot.




3. Push and hold down the shackle then rotate it fully to the right side of the lock.




4. Set the wheels to the desired code on the indicator line. Store the new code securely.



5. Rotate the shackle until it pops up.




6. Push the shackle down. Scramble the wheels to lock.




Indicator line

Align code numbers with the indicator line when locking and unlocking.



Unlocking

Set the wheels to the set code on the indicator line. Pull up the shackle.



Disposal



Dispose of the product according to local regulations. If in doubt, consult your local authorities.

Amazon EU SARL, UK Branch, 1 Principal Place,
Worship St, London EC2A 2FA, United Kingdom
BRO17427

Amazon EU S.a r.l., 38 avenue John F. Kennedy,
L-1855 Luxembourg
134248

MADE IN CHINA
V02-12/23

Documents / Resources



[amazon basics B07T2C3QNZ 4 Digit Combination Lock](#) [pdf] User Manual
B07T2C3QNZ 4 Digit Combination Lock, B07T2C3QNZ, 4 Digit Combination Lock, Combination Lock

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)