



## amazon basics B081NXY9KN Event Shelter Instruction Manual

[Home](#) » [amazon basics](#) » amazon basics B081NXY9KN Event Shelter Instruction Manual 

amazon basics B081NXY9KN Event Shelter




## Contents

- [1 Product Overview](#)
- [2 Assembly Instructions](#)
- [3 Symbols](#)
- [4 What is in the Box?](#)
- [5 IMPORTANT SAFETY INSTRUCTIONS](#)
- [6 IMPORTANT, RETAIN FOR FUTURE REFERENCE](#)
- [7 Cleaning and Maintenance](#)
  - [7.1 Cleaning](#)
  - [7.2 Maintenance](#)
- [8 Specifications](#)
- [9 Feedback and Help](#)
- [10 Customer Support](#)
- [11 Documents / Resources](#)
  - [11.1 References](#)
- [12 Related Posts](#)

## Product Overview

1



## Assembly Instructions

2



A (x 4)





B (x 1)




C (x 2)



D (x 4)




3



H (x 1)


4



E (x 1)



F (x 8)



5




F (x 8)




G (x 8)




Symbols




What is in the Box?



A (x 4)




B (x 1)



C (x 2)



D (x 4)




E (x 1)




F (x 16)



G (x 8)



H (x 1)



I (x 1)



## IMPORTANT SAFETY INSTRUCTIONS



Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

When using the product, basic safety precautions should always be followed to reduce the risk of injury including the following:



## WARNING

**Risk of serious injury!** Take special precautions when using a ladder. Use the right type of ladder and ensure it is structurally sound. Use the ladder in accordance with the manufacturer's instruction.



## CAUTION

**Risk of injury!** Do not climb on top of the product. Falling off the product can result in serious injury.



## CAUTION

**Risk of injury or property damage!** Do not use this product in adverse weather conditions, such as strong winds, heavy rains and snow. Disassemble the product when the wind speed exceeds Beaufort scale 5 (>25 mph/ >40 km/h).



## CAUTION

**Risk of cuts!** Some parts may contain sharp edges. Wear protective gloves.

- For domestic outdoor use only.
- This product is designed for occasional use and cannot be used as a permanent structure.
- Never stay under the product in thunderstorms.
- This product must be assembled by 2 competent adults.
- Keep children and pets away when assembling the product.
- Always use the product on a firm, level ground.
- Anchor the product to the ground using provided pegs.
- Do not use this product if any parts are missing, damaged, or worn.

- Regularly examine the product for wear and tear. Stop using the product at first sign of damage or if parts become detached.
- Keep this product away from naked flames and direct sources of heat, such as patio heaters or barbeques. Do not use candles, matches or open flames of any kind in or near the product.
- Do not smoke or store flammable liquids inside the product.
- Build campfire downwind and at least 3 meters away from the product. Fully extinguish the campfire before leaving.
- Do not hang from the ribs, frame or canopy of this product.
- Empty water pockets as soon as they form.

## IMPORTANT, RETAIN FOR FUTURE REFERENCE

### READ CAREFULLY



#### Before First Use

- Check the product for transport damages.
- Remove all the packing materials.



## DANGER

**Risk of suffocation!** Keep any packaging materials away from children – these materials are a potential source of danger, e.g. suffocation.



#### Cleaning and Maintenance

##### Cleaning

- To clean the product, wipe with a soft, slightly moist cloth.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.

##### Maintenance

- Regularly check that all the components and fasteners are tightened.
- Store the product in a cool and dry place away from children and pets, ideally in the provided storage bag.
- Avoid any vibrations and shocks.



#### Specifications

**B081NXY9KN**

**Net weight:** approx. 16 kg

**Dimensions (W x H x D):** approx. 365 x 225 x 365 cm

**B081P15913**

**Net weight:** approx. 21 kg

**Dimensions (W x H x D):** approx. 450 x 240 x 450 cm



**Feedback and Help**

Love it? Hate it? Let us know with a customer review.

AmazonBasics is committed to delivering customer-driven products that live up to your high standards. We encourage you to write a review sharing your experiences with the product.

## Customer Support

[amazon.com/AmazonBasics](https://www.amazon.com/AmazonBasics)





[amazon.co.uk/review/review-your-purchases#](https://www.amazon.co.uk/review/review-your-purchases#)



[amazon.co.uk/gp/help/customer/contact-us](https://www.amazon.co.uk/gp/help/customer/contact-us)



## Documents / Resources

  <small>Event Shelter Get your Event Shelter Event Shelter Event Shelter Event Shelter Event Shelter Event Shelter</small>	<p><a href="#">amazon basics B081NXY9KN Event Shelter</a> [pdf] Instruction Manual B1-l1-woX L, B081NXY9KN, B081NXY9KN Event Shelter, Event Shelter, Shelter</p>
---	--



## References

- [User Manual](#)

Manuals+.