



amazon basics B08BPCWSYW Mini DVD Player with Text To Speech HDMI RCA Connection User Manual

[Home](#) » [amazon basics](#) » amazon basics B08BPCWSYW Mini DVD Player with Text To Speech HDMI RCA Connection User Manual 

Contents

- [1 amazon basics B08BPCWSYW Mini DVD Player with Text To Speech HDMI RCA Connection](#)
- [2 Important Safety Instructions](#)
- [3 Battery Warnings](#)
- [4 Explanation of Symbols](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)



amazon basics B08BPCWSYW Mini DVD Player with Text To Speech HDMI RCA Connection



Important Safety Instructions

Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

When using electrical products, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons including the following:

CAUTION: RISK OF ELECTRIC SHOCK DO NOT OPEN

DANGER: Invisible and hazardous laser radiation when open and interlock failed or defeated. Avoid direct exposure to the beam.

- THIS DIGITAL VIDEO DISC PLAYER EMPLOYS A LASER SYSTEM. TO ENSURE THE PROPER USE OF THIS PRODUCT: THE USE CONTROLS, ADJUSTMENTS, OR THE PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE. TO PREVENT DIRECT EXPOSURE TO THE LASER BEAM, DO NOT TRY TO OPEN THE ENCLOSURE. VISIBLE LASER RADIATION MAY BE PRESENT WHEN THE ENCLOSURE IS OPENED. DO NOT STARE INTO BEAM.
 - No naked flame sources, such as lighted candles, should be placed on the product. The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc. This product is only suitable for use in moderate climates. Do not use it in tropical or particularly humid climates.
 - The product shall not be exposed to dripping or splashing water. No objects filled with liquids, such as vases, shall be placed on the product.
 - The socket-outlet shall be easily accessible.
 - Do not attempt to repair the product yourself. In case of malfunction, repairs are to be conducted by qualified personnel only.
 - Do not open the product casing under any circumstances. Do not insert any foreign objects into the inside of the casing.
 - Keep the product away from any hot surfaces and open flames. Always operate the product on a level, stable, clean, and dry surface. Protect the product against heat (over 35 °C) and cold (under 5°C), dust, direct sunlight, moisture, dripping and splashing water.
 - Only use this product with the supplied power adaptor.
 - The product should only be supplied with a safety extra low voltage corresponding to the marking on the product. When the product is placed near a
 - TV or radio, the playback picture and sound may be distorted. In this case, move the product away from the TV or radio.
 - Do not use the product where moisture or condensation may occur. Using the product in such conditions may damage discs and other internal parts.
 - Moisture or condensation can occur during the following cases:
 - When the product is transported directly from a cold temperature environment to a warm temperature environment.
 - When the product is used in a humid environment.
- To evaporate any moisture or condensation, remove the disc and leave the product ON for 2 – 3 hours.

Battery Warnings

CAUTION












Risk of explosion if the battery is replaced by an incorrect type.

WARNING

- Batteries shall not be exposed to excessive heat such as sunshine, fire, or the like.
- Do not mix old and new batteries or batteries of different types or brands.

- Exhausted batteries should be immediately removed from the product and properly disposed of.
- Keep batteries out of the reach of children.
- Do not dispose of batteries in a fire. Remove batteries from the product if it is not to be used for an extended period unless it is for emergency purposes.
- if the battery leaks avoid contact with skin and eyes. Rinse affected areas immediately with plenty of clean water, then consult a doctor.
- Do not use/charge non-rechargeable batteries.

Explanation of Symbols

-  This symbol stands for “Conformité Européenne”, which means “Conformity with EU-directives”. With the CE-marking, the manufacturer confirms that this product complies with applicable European directives and regulations.
-  This symbol stands for “UK Conformity Assessed”, which means “Conformity with British Standards”. With the UKCA marking the manufacturer confirms that this product complies with applicable British Standards.
-  This product is classified as protection class II. This means the product is equipped with reinforced or double insulation between the main supply circuit and the output voltage or the casing. Therefore it does not require a safety connection to an electrical earth (ground).
-  Direct current (DC).
-  Alternating current (AC).
-  This product is for indoor use only.
-  This is a class 1 laser product. This product works with a collimated laser beam. When the product is open and the safety breaker is disabled, this beam could be a danger to your eyes. The product has a protective measure that will prevent the beam from coming out. These safety measures must not be damaged.
-  To indicate hazards arising from dangerous voltages.
-  USB port pins polarity assignment
-  To indicate that caution is necessary when operating the device or control close to where the symbol is placed, or to indicate that the current situation needs operator awareness or operator action in order to avoid undesirable consequences.
-  DVD system region codes 2 (EU)

Disposal

The Waste Electrical and Electronic Equipment (WEEE) Directive aims to minimize the impact of electrical and electronic goods on the environment, by increasing re-use and recycling and by reducing the amount of WEEE going to landfill. The symbol on this product or its packaging signifies that this product must be disposed of separately from ordinary household wastes at its end of life. Be aware that this is your responsibility to dispose of

electronic equipment at recycling centers to conserve natural resources. Each country should have its own collection centers for electrical and electronic equipment recycling. For information about your recycling drop-off area, please contact your related electrical and electronic equipment waste management authority, your local city office, or your household waste disposal service.


Battery Disposal

Do not dispose of used batteries with your household waste. Take them to an appropriate disposal/collection site.

[amazon.com/AmazonBasics](https://www.amazon.com/AmazonBasics)

MADE IN CHINA

Documents / Resources

 <p>amazon basics</p> <p>Safety Manual Manuel de Sécurité Sicherheitshandbuch Manuale di Sicurezza Manual de Seguridad Veiligheidshandleiding</p> <p>Mini DVD Player with Text-To-Speech Technology, HDMI, RCA Connection and Remote Control B08BPCWSYW</p> <p>Page 1 Page 2 Page 3 Page 4</p>	<p>amazon basics B08BPCWSYW Mini DVD Player with Text To Speech HDMI RCA Connection [pdf] User Manual</p> <p>B08BPCWSYW Mini DVD Player with Text-To-Speech HDMI RCA Connection, B08BPCWSYW, Mini DVD Player with Text-To-Speech HDMI RCA Connection, DVD Player with Text-To-Speech HDMI RCA Connection, Text-To-Speech HDMI RCA Connection, HDMI RCA Connection, RCA Connection, Connection</p>
---	---

References

- [User Manual](#)

[Manuals+](#)