



amazon basics B09SHK2SLH Wireless Presenter User Guide


[Home](#) » [amazon basics](#) » amazon basics B09SHK2SLH Wireless Presenter User Guide 

Contents

- [1 amazon basics B09SHK2SLH Wireless Presenter](#)
- [2 Important Safeguards](#)
- [3 Battery Warnings](#)
- [4 Intended Use](#)
- [5 Product Description](#)
- [6 Operation](#)
- [7 Presentation functions](#)
- [8 Cleaning and Maintenance](#)
- [9 Frequently Asked Questions](#)
- [10 Supplier's Declaration of Conformity](#)
- [11 FCC Interference Statement](#)
- [12 Battery Disposal](#)
- [13 Specifications](#)
- [14 Feedback and Help](#)
- [15 Documents / Resources](#)
- [16 Related Posts](#)



amazon basics B09SHK2SLH Wireless Presenter



Important Safeguards



Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included. When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons including the following:

WARNING Risk of injury

The safety features of this device may not protect the user if not used in accordance with this user manual.

- Do not leave the device unattended. Always prevent access to the device by unauthorized personnel, for example by children.
- Do not attempt repairs or any adjustments. There are no user-serviceable parts.
- Do not open the device. The laser beam is dangerous to the eyes. Has the device been repaired only by a professional?
- Do not use if the device appears damaged or if it is not working properly. If in doubt, replace the device.
- Do not use the device near medical equipment.

Laser beam warnings

The following laser hazard symbol and warning label are used to alert the user to the risk associated with the improper use of a laser pointer. Do not remove explanatory and warning labels.

LASER RADIATION AVOIDS DIRECT EYE EXPOSURE CLASS 2 LASER PRODUCT

- When operating the laser device, always make sure that the laser beam is directed so that no one is in the projection area and that unintentionally reflected beams (for example, from reflective objects) cannot be directed into areas where people are present.
- The laser beam can be dangerous if the laser beam or its reflection enters unprotected eyes. Always familiarize yourself with statutory regulations and operating instructions before using laser device. If a laser beam enters your eyes, close your eyes immediately and move your head away from the beam.

- If your eyes have been irritated by laser radiation, do not continue to carry out tasks with safety implications, such as working with machines, working from great heights or being close to high voltage. Also, do not operate any vehicles until the irritation has completely subsided.
- Never aim a laser beam at the sun or at any aircraft, helicopter or drone.
- The laser beam can distract or flash blind pilots. The laser beam continues to travel even if the light is no longer visible.

CAUTION

- Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Battery Warnings

- This product contains batteries that are non-replaceable.
- Before disposal, the battery must be removed from the product. Contact qualified professional.
- Do not leave the battery charging for a prolonged period of time when the product is not in use.
- Do not charge the battery overnight.
- If the product appears to be bulging or shows other undesirable phenomena (e.g. excess noise), stop using the product immediately.
- Do not cover the product while charging the battery. Charge the product in a well-ventilated environment.
- When in long-term storage, charge the battery to its 70 % capacity once every 3 months to avoid shortening its life.
- Batteries produce heat when charging and discharging. If the product becomes too hot to touch, switch the product off and unplug it immediately.
- Charge the product only with a compatible power source from a reputable manufacturer e.g. power adapter or power bank. The maximum rating should not exceed 5 V 1 A.
- If the battery leaks, avoid contact with skin and eyes. Rinse affected areas immediately with plenty of clean water, then consult a doctor.

Intended Use

- This product is intended for navigation during presentations.
- This product is intended for private use only.
- This product is intended to be used in dry indoor areas only.


Before First Use

Risk of suffocation!

Keep any packaging materials away from children and pets – these materials are a potential source of danger, e.g. suffocation.

- Remove all the packing materials.
- Remove and review all components before use.
- Check the product for transport damages.

Product Description



- battery indicator
- Timer display
- Progress bar
- start/pause button
- set timer button
- next button
- black screen button
- Charging port
- USB dongle
- laser button
- full-screen button
- previous button
- ON/OFF slider

Operation

Charging the product

NOTICE

- The product is out of battery when the
- (A) flashes or if it is unresponsive when a button is pressed.
- When the battery is low, the operating range of the product decreases. It is recommended to charge the product before the power fully runs out.
 1. Connect the USB-A side of a USB-A to a micro-USB charging cable (not provided) to a computer.
 2. Connect the micro-USB side of the charging cable to the charging port (H). The (A) flashes and the product is charging.
 3. It takes approximately 3 hours to fully charge the product. The(A) stays on when the product is charged.

4. After charging, unplug the charging cable from the power source.

Connecting to a computer

1. Take the USB dongle (I) out from the back of the product.
2. Connect the USB dongle (I) to a USB 2.0 USB-A port of a computer.

NOTICE The product supports both Windows and Mac operating systems. For Mac computers, “Keyboard Set Assistant” may pop up, click “Continue” to allow the computer to finish the setup.






Switching on/off

NOTICE

The product automatically switches off after 5 minutes of inactivity. It stays on if a timer has been set.





- To switch on the product, set the ON/ OFF slider (M) to ON.
- To switch off the product, set the ON/OFF slider (M) to OFF.

Presentation functions

| Button | Action | Function |
|---|--------|------------------------------|
|  | Press | Enter/exit full screen mode |
|  | Hold | Activate laser |
|  | Press | Return to previous slide |
|  | Press | Go to the next slide |
|  | Press | Enter/exit black screen mode |

Timer function

A timer can be set to keep a presentation within the planned time. To set a timer:

| Button | Action | Timer |
|---|-------------|---------|
|  | Short press | +1 min |
|  | Short press | -1 min |
|  | Long press | +5 mins |
|  | Long press | -5 mins |

1. Press (D) to start the timer.
2. While the timer is running, it is possible to press (D) to pause/start the timer as desired. The: icon on the timer display (B) flashes when the timer is running and stops flashing when it is paused.

The progress bar (C) reduces in amount while the timer progresses as a visual aid to see how much time is left. The product vibrates as a reminder halfway, 5 minutes left, and when the time is up.

Cleaning and Maintenance

- Switch the product off before cleaning.
- During cleaning do not immerse the product in water or other liquids. Never hold the product under running water.
- To clean the product, wipe with a soft, slightly damp cloth.
- Wipe the product dry after cleaning.
- Never use corrosive detergents, wire brushes, abrasive scourers, or metal or sharp utensils to clean the product.
- Place the USB dongle (I) back into the main unit.
- Store the product in its original packaging in a dry area. Keep away from children and pets.

Frequently Asked Questions

| Problem | Solution |
|---|--|
| The product does not switch on. | The product is low/out of battery. Recharge the product. |
| Computer cannot detect the USB dongle. | Current USB-A port might be faulty. Try another USB-A port. |
| The product is not responding to presses. | <ul style="list-style-type: none"> ▶ The product is out of range. Get closer to the USB dongle and try again. ▶ The product is low/out of battery. Recharge the product. |

Trademarks

Windows is a registered trademark of Microsoft

Corporation

Mac is a registered trademark of Apple Inc.

Supplier's Declaration of Conformity

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: this device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Canada IC Notice

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

1. this device may not cause interference, and
2. this device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian CAN ICES-003(8) / NMB-003(8) standard.

Battery Disposal

Do not dispose of used batteries with your household waste. Take them to an appropriate disposal/collection site.

Specifications

- Voltage/battery type 3.7V 200 mA 400 mAh Li-ion
- Control range 30 m (no obstructions)
- Operating frequency RF 2.4 GHz
- Laser range 200 m
- Laser class 2 (green color)
- Laser wavelength 500 – 552 nm
- Maximum output of <1 mW
- radiation power Windows, Mac
- Compatible operating USB 1.1, 2.0 and 3.0
- USB port requirement -4 Ohm to +122 Ohm
- Storage temperature (-20 °C to +50 °C)


Feedback and Help

We would love to hear your feedback. To ensure we are providing the best customer experience possible, please consider writing a customer review. Scan QR Code below with your phone camera or QR reader:



If you need help with your Amazon Basics product, please use the website or number below.

Documents / Resources



amazon basics

Wireless Presenter
Télécommande de Présentation
sans Fil
Presentador Inalámbrico
B09SHK2SLH

EN Page 2
FR Page 19
ES Página 37

[amazon basics B09SHK2SLH Wireless Presenter](#) [pdf] User Guide

2804, 2A7VC-2804, 2A7VC2804, B09SHK2SLH Wireless Presenter, B09SHK2SLH, Wireless P
resenter, Presenter