



amazon basics B0BFWGLVLX Cable Tidy Box Instruction Manual

[Home](#) » [amazon basics](#) » amazon basics B0BFWGLVLX Cable Tidy Box Instruction Manual 

Contents

- [1 amazon basics B0BFWGLVLX Cable Tidy Box](#)
- [2 important Safeguards](#)
- [3 Cleaning and Maintenance](#)
- [4 Specifications](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

amazon basics

amazon basics B0BFWGLVLX Cable Tidy Box



Cable Tidy Box

important Safeguards



- Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.
- When using the product, basic safety precautions should always be followed to reduce the risk of injury including the following:
 - For domestic use only.
 - This product is not a toy. Keep children and pets away from the product.
 - Do not use this product if any parts are missing, damaged, or worn.
 - Regularly examine the product for wear and tear. Stop using the product at first sign of damage or if parts become detached.
 - Keep the product away from hot surfaces and open flames. Place the product in a way that unintentional pulling of stored power cords or tripping over it is not possible.
 - Keep materials that are sharp or that conduct heat or electricity away from the product.
 - Use the product near an easily reachable outlet so that in case of emergency, any stored power strips and power cords can be unplugged immediately.

Before First Use

- **DANGER:** Risk of suffocation!
Keep any packaging materials away from children and pets – these materials are a potential source of danger, e.g. suffocation.
- Remove all the packing materials.
- Remove and review all components before use.
- Check the product for transport damages.

Cleaning and Maintenance

- **Cleaning**
 - Remove any stored power strips and power cords before cleaning.
 - To clean the product, wipe with a soft, slightly damp cloth. Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.
- **Disposal**
 - Dispose of the product according to local regulations. If in doubt, consult your local authorities.

Specifications


- **Model**
 - BOBFWGLVLX
 - BOBFWKK2SZ

- **Net weight approx.**
 - 1.5 lbs (0.68 kg)
 - approx. 0.79 lbs (0.36 kg)
- **Dimensions**
 - approx. 15.4 x 6.1 x 4.9"
 - approx. 10.5 x 4.8 x 4.2"
- **(W x H x D)**
 - (39 x 15.5 x 12.5 cm)
 - (26.6 x 12.3 x 10.6 cm)


Feedback and Help

- We would love to hear your feedback. To ensure we are providing the best customer experience possible, please consider writing a customer review. Scan QR Code below with your phone camera or QR reader:



-  amazon.co.uk/review/review-your-purchases# If you need help with your Amazon Basics product, please use the website or number below.
- **US:** amazon.com/gp/help/customer/contact-us
- **UK:** amazon.co.uk/gp/help/customer/contact-us
- +1 877-485-0385 (US Phone Number)

Documents / Resources

	amazon basics B0BFWGLVLX Cable Tidy Box [pdf] Instruction Manual B0BFWGLVLX, B0BFWGLVLX Cable Tidy Box, Cable Tidy Box, Tidy Box, Box
---	--

References

- [User Manual](#)

